

---

# **GASOLINE DIRECT INJECTION (GDI)**

**Click on the applicable bookmark to selected the required model year.**

---

# GASOLINE DIRECT INJECTION (GDI)

## CONTENTS

<b>GENERAL INFORMATION</b> .....	<b>3</b>	Intake Air Temperature Sensor Check .....	227
<b>SERVICE SPECIFICATIONS</b> .....	<b>7</b>	Engine Coolant Temperature Sensor Check ..	227
<b>SEALANT</b> .....	<b>7</b>	Throttle Position Sensor Check .....	228
<b>SPECIAL TOOLS</b> .....	<b>7</b>	Accelerator Pedal Position Sensor Check ....	229
<b>TROUBLESHOOTING &lt;M/T&gt;</b> .....	<b>9</b>	Accelerator Pedal Position Switch Check ....	230
<b>TROUBLESHOOTING &lt;A/T&gt;</b> .....	<b>126</b>	Oxygen Sensor Check .....	230
<b>ON-VEHICLE SERVICE</b> .....	<b>219</b>	Injector Check .....	232
Fuel Pump Connector Disconnection (How to Reduce the Fuel Pressure) .....	219	Throttle Valve Control Servo Check .....	232
Fuel Pump Operation (Low Pressure) Check .	220	Clutch Switch Check .....	233
Throttle Body (Throttle Valve Area) Cleaning .	220	Purge Control Solenoid Valve Check .....	233
Throttle Position Sensor Adjustment .....	220	EGR Valve Check .....	233
Accelerator Pedal Position Sensor Adjustment .....	221	<b>INJECTOR</b> .....	<b>234</b>
Fuel Pressure Test .....	222	<b>FUEL PUMP (HIGH PRESSURE)</b> .....	<b>239</b>
Fuel Leak Check .....	225	<b>THROTTLE BODY</b> .....	<b>242</b>
Component Location .....	226	<b>INJECTOR DRIVER</b> .....	<b>245</b>
Engine Control Relay, Fuel Pump Relay, Injector Driver Control Relay and Throttle Valve Control Servo Relay Continuity Check .....	227	<b>ENGINE-ECU, ENGINE-A/T-ECU &lt;A/T&gt;,     THROTTLE VALVE CONTROLLER</b> .....	<b>246</b>

## GENERAL INFORMATION

The Gasoline Direct Injection System consists of sensors which detect the engine conditions, the engine-ECU <M/T> or engine-A/T-ECU <A/T> which controls the system based on signals from these sensors, and actuators which operate under the control of the engine-ECU <M/T> or engine-A/T-ECU <A/T>.

The engine-ECU <M/T> or engine-A/T-ECU <A/T> carries out activities such as fuel injection control, idle speed control and ignition timing control. In addition, the engine-ECU <M/T> or engine-A/T-ECU <A/T> is equipped with several diagnosis modes which simplify troubleshooting when a problem develops.

### FUEL INJECTION CONTROL

The injector drive times and injector timing are controlled so that the optimum air/fuel mixture is supplied to the engine to correspond to the continually-changing engine operation conditions.

A single injector for each cylinder is mounted at the cylinder head. The fuel is sent under pressure from the fuel tank to the fuel pressure regulator (low pressure) by the fuel pump (low pressure). The pressure is regulated by the fuel pressure regulator (low pressure) and the fuel regulated is then sent to the fuel pump (high pressure). The fuel under increased pressure generated by the fuel pump (high pressure) is then regulated by the fuel pressure regulator (high pressure) and is then distributed to each of the injectors via the delivery pipes.

Fuel injection is normally carried out once for each cylinder for every two rotations of the crankshaft. The firing order is 1-2-3-4-5-6. This is called sequential fuel injection.

When the engine is cold or under a severe load, the "open-loop" control keeps the air/fuel ratio at a richer than usual level to maintain driveability. When the engine is under low or medium loads, the air/fuel ratio becomes leaner to reduce fuel consumption. When the engine is running at medium or high loads after having warmed up, the "closed-loop" control uses the signal from the oxygen sensor to keep the air/fuel ratio at the optimum theoretical level.

### THROTTLE VALVE OPENING ANGLE CONTROL

This system controls throttle valve opening angle electronically. The engine-ECU <M/T> or engine-A/T-ECU <A/T> determines how deeply the accelerator pedal is depressed by means of the accelerator position sensor (APS). Then the engine-ECU <M/T> or engine-

A/T-ECU <A/T> sends a target value of the throttle valve opening angle to the throttle valve controller. The throttle valve control servo operates the throttle valve so that it reaches the target opening angle.

### IDLE SPEED CONTROL

This system maintains engine idle speed at a predetermined condition by controlling the air flow that passes through the throttle valve according to engine idling condition and engine loads at idling.

The engine-ECU <M/T> or engine-A/T-ECU <A/T> operates the throttle valve control servo

so that engine speed is maintained within a map value. The map value is predetermined according to engine coolant temperature and air-conditioning load.

### IGNITION TIMING CONTROL

The power transistor located in the ignition primary circuit turns ON and OFF to control the primary current flow to the ignition coil. This controls the ignition timing in order to provide the optimum ignition timing with respect to the engine operating conditions. The ignition timing

is determined by the engine-ECU <M/T> or engine-A/T-ECU <A/T> from the engine speed, intake air volume, engine coolant temperature, atmospheric pressure and injection timing (intake stroke or compression stroke).

**SELF-DIAGNOSIS FUNCTION**

- When an abnormality is detected in one of the sensors or actuators related to emission control, the engine warning lamp (check engine lamp) illuminates or flashes as a warning to the driver.
- When an abnormality is detected in one of the sensors or actuators, a diagnosis code corresponding to the abnormality is output.
- The engine-ECU records the engine operating condition when the diagnosis code is set. This data is called “freeze

frame” data.

This data can be read by using the MUT-II, and can then be used in simulation tests for troubleshooting. <Only vehicles with M/T>

- The RAM data inside the engine-ECU <M/T> or engine-A/T-ECU <A/T> that is related to the sensors and actuators can be read by means of the MUT-II. In addition, the actuators can be force-driven under certain circumstances.

**OTHER CONTROL FUNCTIONS**

1. Fuel Pump Control  
Turns the fuel pump relay ON so that current is supplied to the fuel pump while the engine is cranking or running.
2. A/C Relay Control  
Turns the compressor clutch of the A/C ON and OFF.



3. Purge Control Solenoid Valve Control  
Refer to GROUP 17.
4. EGR Control Servo Control  
Refer to GROUP 17.

**GENERAL SPECIFICATIONS**

Items		Specifications
Throttle body	Throttle bore mm	65
	Throttle position sensor	Variable resistor type
	Throttle valve control servo	Brushless DC-motor type
Engine-ECU <M/T>	Identification model No.	E2T79271 <RHD> E2T79272 <LHD>
Engine-A/T-ECU <A/T>	Identification model No.	E2T76277 <RHD> E2T76278 <LHD>

Items		Specifications
Sensors	Air flow sensor	Karman vortex type
	Barometric pressure sensor	Semiconductor type
	Intake air temperature sensor	Thermistor type
	Engine coolant temperature sensor	Thermistor type
	Oxygen sensor	Zirconia type
	Accelerator pedal position sensor (1st and 2nd channels)	Variable resistor type
	Accelerator pedal position switch	Rotary contact type, within accelerator pedal position sensor (1st channel)
	Vehicle speed sensor	Magnetic resistive element type
	Inhibitor switch	Contact switch type
	Camshaft position sensor	Hall element type
	Crank angle sensor	Hall element type
	Detonation sensor	Piezoelectric type
	Fuel pressure sensor	Metallic membrane type
	Power steering fluid pressure switch	Contact switch type
Actuators	Engine control relay type	Contact switch type
	Fuel pump relay type	Contact switch type
	Injector driver control relay	Contact switch type
	Injector type and number	Electromagnetic type, 6
	Injector identification mark	DIM 1070
	Throttle valve control servo relay	Contact switch type
	Throttle valve control servo	Brushless DC-motor type
	EGR valve	Stepper motor type
	Purge control solenoid valve	Duty cycle type solenoid valve
Fuel pressure regulator (low pressure)	Regulator pressure kPa	329
Fuel pressure regulator (high pressure)	Regulator pressure MPa	5.0

**GASOLINE DIRECT INJECTION SYSTEM DIAGRAM**



X6163CA


**SERVICE SPECIFICATIONS**








Item	Standard value	
Adjustment voltage of throttle position sensor (1st channel) V	0.4 - 0.6	
Adjustment voltage of throttle position sensor (2nd channel) V	4.2 - 4.8	
Throttle position sensor resistance k $\Omega$	0.9 - 2.5	
Adjustment voltage of accelerator pedal position sensors 1 and 2 V	0.985 - 1.085	
Resistance of accelerator pedal position sensors 1 and 2 k $\Omega$	3.5 - 6.5	
Intake air temperature sensor resistance k $\Omega$	at 20°C	2.3 - 3.0
	at 80°C	0.30 - 0.42
Engine coolant temperature sensor resistance k $\Omega$	at 20°C	2.1 - 2.7
	at 80°C	0.26 - 0.36
Fuel pressure	High-pressure side MPa	4 - 6.9
	Low-pressure side kPa	Approximately 329
Injector coil resistance (at 20°C) $\Omega$	0.9 - 1.1	
Oxygen sensor output voltage V (during revving)	0.6 - 1.0	
Oxygen sensor heater resistance (at 20°C) $\Omega$	4.5 - 8.0	
Throttle control servo coil resistance (at 20°C) $\Omega$	0.6 - 1.0	

**SEALANT**

Item	Specified sealant	Remark
Engine coolant temperature sensor	3M Nut Locking Part No.4171 or equivalent	Drying sealant

**SPECIAL TOOLS**

Tools	Number	Name	Use
 B991502	MB991502	MUT-II sub assembly	<ul style="list-style-type: none"> <li>• GDI system check</li> <li>• Take a reading of the diagnosis codes</li> </ul>


Tools	Number	Name	Use
	MB991348, MB991658	Test harness set	<ul style="list-style-type: none"> <li>● Troubleshooting - voltage measurement</li> <li>● Inspection using an analyzer</li> </ul>
 <p style="text-align: right; font-size: small;">B991709</p>	MB991709		
	MB991519	Alternator harness connector	Troubleshooting - voltage measurement
	MD998478	Test harness (3-pin, square)	<ul style="list-style-type: none"> <li>● Troubleshooting - voltage measurement</li> <li>● Inspection using an analyzer</li> </ul>
	MD998464	Test harness (4-pin, square)	Oxygen sensor check
	MB991529	Diagnosis code checking harness	Take a reading of the diagnosis codes <A/T>
	MD998709	Adaptor hose	Fuel pressure measurement
	MD998742	Hose adaptor	
 <p style="text-align: right; font-size: small;">B991637</p>	MB991637	Fuel pressure gauge set	

**TROUBLESHOOTING <M/T>****STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING**

Refer to GROUP 00 - How to Use Troubleshooting/Inspection Service Points.

**NOTE**

When replacing the engine-ECU, replace immobilizer-ECU and ignition key as well at the same time.

**DIAGNOSIS FUNCTION****ENGINE WARNING LAMP (CHECK ENGINE LAMP)**

If an abnormality occurs in any of the following items related to the GDI system, the engine warning lamp will illuminate or flash.

If the lamp remains illuminated or if the lamp illuminates while the engine is running, check the diagnosis code output.

**Engine warning lamp inspection items**

Code No.	Diagnosis item
-	Engine-ECU
P0100	Air flow sensor system
P0105	Barometric pressure sensor system
P0110	Intake air temperature sensor system
P0115	Engine coolant temperature sensor system
P0120★	Throttle position sensor (1st channel) system
P0125	Feedback system
P0130	Oxygen sensor (front) system <sensor 1>
P0135	Oxygen sensor heater (front) system <sensor 1>
P0136	Oxygen sensor (rear) system <sensor 2>
P0141	Oxygen sensor heater (rear) system <sensor 2>
P0170	Abnormal fuel system
P0190★	Abnormal fuel pressure
P0201	No.1 injector system
P0202	No.2 injector system
P0203	No.3 injector system
P0204	No.4 injector system
P0205	No.5 injector system

Code No.	Diagnosis item
P0206	No.6 injector system
P0220★	Accelerator pedal position sensor (1st channel) system
P0225★	Throttle position sensor (2nd channel) system
P0300★	Ignition coil (power transistor) system
P0301	No.1 cylinder misfire detected.
P0302	No.2 cylinder misfire detected.
P0303	No.3 cylinder misfire detected.
P0304	No.4 cylinder misfire detected.
P0305	No.5 cylinder misfire detected.
P0306	No.6 cylinder misfire detected.
P0335	Crank angle sensor system
P0340	Camshaft position sensor system
P0403	EGR valve system
P0420	Catalyst malfunction
P0443	Purge control solenoid valve system
P1200	Injector driver system
P1220★	Electronic-controlled throttle valve system
P1221★	Throttle valve position feedback system
P1222★	Throttle control servo system
P1223★	Communication line system with throttle valve controller
P1225★	Accelerator pedal position sensor (2nd channel) system
P1226★	Throttle valve controller system

## NOTE

- If the engine warning lamp illuminates because of a malfunction of the engine-ECU, communication between MUT-II and the engine-ECU is impossible. In this case, the diagnosis code cannot be read.
- After the engine-ECU has detected a malfunction, the engine warning lamp illuminates when the engine is next turned on and the same malfunction is re-detected. However, for items marked with a "★" in the diagnosis code number column, the engine warning lamp illuminates only on the first detection of the malfunction.  
If diagnosis code P0120, P0220, P0225 or P1225 is set, the engine warning lamp will flash. If the 1st and 2nd channels of the throttle position sensor or the accelerator pedal position sensor fail at the same time, the engine warning lamp will also flash.
- After the engine warning lamp illuminates, it will be switched off under the following conditions.
  - When the engine-ECU monitored the power train malfunction three times\* and met set condition requirements, it detected no malfunction.  
\*: In this case, "one time" indicates from engine start to stop.
  - For misfiring malfunction, when driving conditions (engine speed, engine coolant temperature, etc.) are similar to those when the malfunction was first recorded.

4. Sensor 1 indicates the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.

#### **METHOD OF READING AND ERASING DIAGNOSIS CODES**

Refer to GROUP 00 - How to Use Troubleshooting/Inspection Service Points.

#### **DIAGNOSIS USING DIAGNOSIS 2 MODE**

1. Switch the diagnosis mode of the engine control unit to DIAGNOSIS 2 mode using the MUT-II.
2. Carry out a road test.
3. Take a reading of the diagnosis code and repair the problem location.
4. Turn the ignition switch to OFF and then back to ON again.

#### **NOTE**

By turning the ignition switch to OFF, the ENGINE-ECU will switch the diagnosis mode from DIAGNOSIS 2 mode to DIAGNOSIS 1 mode.

5. Erase the diagnosis codes.

#### **INSPECTION USING MUT-II DATA LIST AND ACTUATOR TESTING**

1. Carry out inspection by means of the data list and the actuator test function. If there is an abnormality, check and repair the chassis harnesses and components.
2. After repairing, re-check using the MUT-II and check that the abnormal input and output have returned to normal as a result of the repairs.
3. Erase the diagnosis code memory.
4. Remove the MUT-II, and then start the engine again and carry out a road test to confirm that the problem has disappeared.

**FREEZE FRAME DATA**

When the engine-ECU detects a malfunction and stores a diagnosis code, it also stores a current status of the engine. This function is called "Freeze frame data." By analyzing this "freeze frame" data with the MUT-II, an effective troubleshooting can be performed.

Data item		Unit
Engine coolant temperature sensor		°C
Engine speed		r/min
Vehicle speed		km/h
Long-term fuel compensation (long-term fuel trim)		%
Short-term fuel compensation (short-term fuel trim)		%
Fuel control condition	Open loop	OL
	Closed loop	CL
	Open loop owing to drive condition	OL-DRV.
	Open loop owing to system malfunction	OL-SYS.
	Closed loop based on one oxygen sensor	CL-H02S
Calculation load value		%
Diagnosis code during data recording		-

**NOTE**

If malfunctions have been detected in multiple systems, store one malfunction only, which has been detected first.

**READINESS TEST STATUS**

The engine-ECU monitors the following main diagnosis items, judges if these items are in good condition or not, and stores its history. This history can be read out by using MUT-II. (If the ECU has judged a item before, the MUT-II displays "Complete.")

In addition, if diagnosis codes are erased or the battery cable is disconnected, this history will also be erased (the memory will be reset).

- Catalyst: P0420
- Oxygen sensor: P0130
- Oxygen sensor heater: P0135, P0141

**FAIL-SAFE FUNCTION REFERENCE TABLE**

When the main sensor malfunctions are detected by the diagnosis function, the vehicle is controlled by means of the pre-set control logic to maintain safe conditions for driving.

Malfunctioning item	Control contents during malfunction
Air flow sensor	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Uses the throttle position sensor signal and engine speed signal (crank angle sensor signal) to take reading of the basic injector drive time and basic ignition timing from the pre-set mapping.</li> </ol>
Intake air temperature sensor	Controls as if the intake air temperature is 25°C.
Throttle position sensor (2nd channel)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Controls the throttle opening angle feedback (half as much as the opening rate in the normal condition) by using signals from the throttle position sensor (1st channel). However, this controlling system is not applied if the throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 - 6 V.</li> <li>3. Refrains from controlling the throttle opening angle feedback if the throttle position sensor (1st channel) is also defective.</li> </ol>
Engine coolant temperature sensor	Controls as if the engine coolant temperature is 80°C. (Moreover, the control system is working until the ignition switch is turned OFF if the sensor signal returns to normal.)
Camshaft position sensor	Cuts the fuel supply once a malfunction is detected. (Only when there has been no occasion of detecting No.1 cylinder top dead centre after the ignition switch is turned ON.)
Vehicle speed sensor	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation. However, the control is cancelled as a certain time passes by with the engine speed of 1,500 r/min or more.</li> <li>2. Suspends lean burn operation during the engine idling.</li> </ol>
Barometric pressure sensor	Controls as if the barometric pressure is 101 kPa.
Detonation sensor	Fixes the ignition timing as that for standard petrol.
Injector	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Suspends the exhaust gas recirculation.</li> </ol>
Ignition coil (incorporating power transistor)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Cuts off the fuel supply to cylinders with an abnormal ignition signal.</li> </ol>
Fuel pressure sensor	<ol style="list-style-type: none"> <li>1. Controls as if the fuel pressure is 5MPa.</li> <li>2. Suspends fuel injection. (when the low pressure is detected and the engine speed is more than 3,000r/min)</li> </ol>
Alternator FR terminal	Refrains from controlling to suppress the alternator output to electrical load. (Operated as a normal alternator)
Accelerator pedal position sensor (2nd channel)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Controls the throttle valve position by using signals from the accelerator pedal position sensor (1st channel). (However, the control system is not applicable if the difference from the accelerator pedal position sensor (1st channel) output voltage is 1.0 V or higher.)</li> <li>3. Suspends the electronic controlled throttle valve system if accelerator pedal position sensor (1st channel) is also defective.</li> </ol>

Malfunctioning item	Control contents during malfunction
Accelerator pedal position sensor (1st channel)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Controls the throttle valve position by using signals from the accelerator pedal position sensor (2nd channel). (However, this control is not applicable if the voltage difference between the accelerator pedal position sensor (1st channel) and accelerator pedal position sensor (2nd channel) is 1.0 V or higher.)</li> <li>3. Also suspends the electronic-controlled throttle valve system when the accelerator pedal position sensor (2nd channel) is defective.</li> </ol>
Throttle position sensor (1st channel)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Controls throttle opening angle feedback by using signals from throttle position sensor (2nd channel). (However, the controlling system is not applied when the throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 - 6 V.)</li> <li>3. Refrains from controlling the throttle opening angle feedback when throttle position sensor (2nd channel) is also defective.</li> </ol>
Electronic-controlled throttle valve system	<ol style="list-style-type: none"> <li>1. Suspends the electronic controlled throttle valve system.</li> <li>2. Suspends lean burn operation.</li> <li>3. Suspends the idle speed feedback control.</li> </ol>
Throttle valve position feedback	<ol style="list-style-type: none"> <li>1. Suspends the electronic controlled throttle valve system.</li> <li>2. Suspends lean burn operation.</li> <li>3. Suspends the engine speed feedback control.</li> </ol> <p>However, if the throttle valve opening angle is significantly wide, this system carries out the following controls.</p> <ol style="list-style-type: none"> <li>1. Always cuts the fuel supply to three cylinders.</li> <li>2. Cuts the fuel supply when the engine speed reaches 3,000 r/min or more.</li> </ol>
Throttle control servo	<ol style="list-style-type: none"> <li>1. Suspends the electronic-controlled throttle valve system.</li> <li>2. Suspends lean burn operation.</li> <li>3. Suspends the engine speed feedback control.</li> </ol>
Communication line between the throttle valve controller and the ECU	<ol style="list-style-type: none"> <li>1. Communication error between the throttle valve controller and the engine-ECU: <ul style="list-style-type: none"> <li>● Suspends lean burn operation.</li> <li>● Cuts the fuel supply when the engine speed reaches 3,000 r/min or more.</li> <li>● Suspends the cruise-control.</li> </ul> </li> <li>2. Communication error between the throttle valve controller and the engine-ECU: <ul style="list-style-type: none"> <li>● Suspends lean burn operation.</li> <li>● Cuts the fuel supply when the engine speed reaches 3,000 r/min or more.</li> <li>● Suspends the cruise-control.</li> <li>● The throttle valve controller controls the throttle valve opening angle by using signals from accelerator pedal position sensor (2nd channel).</li> </ul> </li> </ol>
Throttle valve controller	<ol style="list-style-type: none"> <li>1. Suspends the electronic-controlled throttle valve system.</li> <li>2. Suspends lean burn operation.</li> <li>3. Suspends the engine speed feedback control.</li> </ol>

## NOTE

If the electronic-controlled throttle valve system is suspended, the engine warning lamp will illuminate.

**INSPECTION CHART FOR DIAGNOSIS CODES**

Code No.	Diagnosis item	Reference page
P0100	Air flow sensor system	13A-17
P0105	Barometric pressure sensor system	13A-19
P0110	Intake air temperature sensor system	13A-21
P0115	Engine coolant temperature sensor system	13A-22
P0120★	Throttle position sensor (1st channel) system	13A-25
P0125	Feedback system	13A-27
P0130	Oxygen sensor (front) system <sensor 1>	13A-28
P0135	Oxygen sensor heater (front) system <sensor 1>	13A-30
P0136	Oxygen sensor (rear) system <sensor 2>	13A-31
P0141	Oxygen sensor heater (rear) system <sensor 2>	13A-33
P0170	Abnormal fuel system	13A-34
P0190★	Abnormal fuel pressure	13A-36
P0201	No.1 injector system	13A-38
P0202	No.2 injector system	13A-40
P0203	No.3 injector system	13A-42
P0204	No.4 injector system	13A-44
P0205	No.5 injector system	13A-46
P0206	No.6 injector system	13A-48
P0220★	Accelerator pedal position sensor (1st channel) system	13A-50
P0225★	Throttle position sensor (2nd channel) system	13A-52
P0300★	Ignition coil (power transistor) system	13A-53
P0301	No.1 cylinder misfire detected.	13A-55
P0302	No.2 cylinder misfire detected.	13A-55
P0303	No.3 cylinder misfire detected.	13A-55
P0304	No.4 cylinder misfire detected.	13A-55
P0305	No.5 cylinder misfire detected.	13A-55
P0306	No.6 cylinder misfire detected.	13A-55
P0325	Detonation sensor system	13A-56
P0335	Crank angle sensor system	13A-56
P0340	Camshaft position sensor system	13A-58
P0403	EGR valve system	13A-60
P0420	Catalyst malfunction	13A-61


Code No.	Diagnosis item	Reference page
P0443	Purge control solenoid valve system	13A-62
P0500	Vehicle speed sensor system	13A-63
P1200	Injector driver system	13A-63
P1220★	Electronic-controlled throttle valve system	13A-64
P1221★	Throttle valve position feedback system	13A-65
P1222★	Throttle control servo system	13A-66
P1223★	Communication line with throttle valve controller	13A-67
P1225★	Accelerator pedal position sensor (2nd channel) system	13A-68
P1226★	Throttle valve controller system	13A-69
P1500	Alternator FR terminal system	13A-70
P1610	Immobilizer system	13A-71


## NOTE

1. Do not replace the engine-ECU until a through terminal check reveals there are no short/open circuit.
2. Check that the engine-ECU earth circuit is normal before checking for the cause of the problem.
3. After the engine-ECU has detected a malfunction, a diagnosis code is recorded the next time the engine is started and the same malfunction is re-detected. However, for items marked with a "★", the diagnosis code is recorded on the first detection of the malfunction.
4. Sensor 1 indicates the sensor mounted at a position closest to the engine, and sensor 2 indicates the sensor mounted at the position second closest to the engine.


**INSPECTION PROCEDURE CLASSIFIED BY DIAGNOSIS CODE**


Code No.P0100 Air flow sensor system	Probable cause
Range of Check ● Engine speed: 500 r/min or more Set Conditions ● The sensor output frequency is 3.3 Hz or less for four seconds.	● Malfunction of air flow sensor ● Open or short circuit in air flow sensor circuit or loose connector contact ● Malfunction of engine-ECU







Code No.P0105 Barometric pressure sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Two seconds have passed since the ignition switch is turned ON or the engine starting process is completed.</li> <li>Battery voltage: 8 V or more</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 4.5 V or more for four seconds (equivalent to 114 kPa of barometric pressure)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 0.2 V or less (equivalent to 53 kPa of barometric pressure)</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of barometric pressure sensor</li> <li>Open or short circuit in barometric pressure sensor circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>







Code No.P0110 Intake air temperature sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Two seconds have passed since the ignition switch is turned ON or the engine starting process is completed.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 4.6 V or more for four seconds (equivalent to -45°C of intake air temperature)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 0.2 V or more for four seconds (equivalent to 125°C of intake air temperature)</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of intake air temperature sensor</li> <li>Open or short circuit in intake air temperature sensor or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>






Code No.P0115 Engine coolant temperature sensor system	Probable cause
Range of Check <ul style="list-style-type: none"> <li>Engine: Two seconds after the engine has been started</li> </ul> Set Conditions <ul style="list-style-type: none"> <li>The sensor output voltage is 4.6 V or more for four seconds (equivalent to -45°C of engine coolant temperature)</li> </ul> or <ul style="list-style-type: none"> <li>The sensor output voltage is 0.1 V or less for four seconds (equivalent to 140°C of engine coolant temperature)</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of engine coolant temperature sensor</li> <li>Open or short circuit in the engine coolant temperature sensor circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>
Range of Check <ul style="list-style-type: none"> <li>Engine: After starting</li> </ul> Set Conditions <ul style="list-style-type: none"> <li>The engine coolant temperature has reduced from over 40°C to less than 40°C, and that condition has lasted for five minutes or more.</li> </ul>	







Code No.P0120 Throttle position sensor (1st channel) system	Probable cause
<p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-ECU.                      Range of Check                      • Ignition switch: ON                      Set Conditions                      • The sensor output voltage is 0.2 V or less.                      or                      • The sensor output voltage is 4.85 V or more and the throttle position sensor (2nd channel) output voltage is 2.5V or more.                      or                      • The throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 - 6 V.                      or                      • The opening angle of throttle position sensor (1st channel) is different from its target by 1 V or more.                      or                      • The throttle position sensor (1st channel) output changes within 25 mV when the throttle control servo moves one step.</p>	<ul style="list-style-type: none"> <li>• Malfunction of throttle position sensor</li> <li>• Open or short circuit in the throttle position sensor (1st channel) circuit or loose connector contact</li> <li>• Malfunction of throttle valve controller</li> <li>• Malfunction of engine-ECU</li> </ul>




To the next page




Code No.P0125 Feedback system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>The engine coolant temperature is approx. 80°C or more.</li> <li>During stoichiometric feedback control</li> <li>The vehicle is not being decelerated.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>Oxygen sensor (front) output voltage has been higher or lower than 0.5 V for at least thirty seconds.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of oxygen sensor (front)</li> <li>Open or short circuit in the oxygen sensor (front) circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>




<b>Code No.P0130 Oxygen sensor (front) system &lt;sensor 1&gt;</b>	<b>Probable cause</b>
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Three minutes have been passed since the engine has been started.</li> <li>● The engine coolant temperature is approx. 80°C or more.</li> <li>● Intake air temperature is 20 - 50°C</li> <li>● Engine speed is 1,200 r/min or more</li> <li>● Driving on a level surface at constant speed.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The oxygen sensor (front) output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor (front) inside the engine-ECU.</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of oxygen sensor (front)</li> <li>● Open or short circuit in the oxygen sensor (front) circuit or loose connector contact</li> <li>● Malfunction of engine-ECU</li> </ul>
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Engine speed is 3,000 r/min or less</li> <li>● During driving</li> <li>● During air/fuel ratio feedback control</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The oxygen sensor (front) output frequency is five or less per 12 seconds on average.</li> </ul>	




Code No.P0135 Oxygen sensor heater (front) system <sensor 1>	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>• The engine coolant temperature is approx. 20°C or more.</li> <li>• The oxygen sensor heater (front) remains on.</li> <li>• The engine speed is 50 r/min or more.</li> <li>• Battery voltage is 11 - 16 V.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>• The current, which flows through the oxygen sensor heater (front), is 0.2 A or less or 3.5 A or more for six seconds.</li> </ul>	<ul style="list-style-type: none"> <li>• Malfunction of oxygen sensor heater (front)</li> <li>• Open or short circuit in the oxygen sensor heater (front) circuit or loose connector contact</li> <li>• Malfunction of engine-ECU</li> </ul>




<b>Code No.P0136 Oxygen sensor (rear) system &lt;sensor 2&gt;</b>	<b>Probable cause</b>
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Three minutes have been passed since the engine has been started.</li> <li>● The engine coolant temperature is approx. 80°C or more.</li> <li>● Intake air temperature is 20 - 50°C</li> <li>● Engine speed is 1,200 r/min or more</li> <li>● Driving on a level surface at constant speed.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The oxygen sensor (rear) output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor (rear) inside the engine-ECU.</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of oxygen sensor (rear)</li> <li>● Open or short circuit in the oxygen sensor (rear) circuit or loose connector contact</li> <li>● Malfunction of engine-ECU</li> </ul>
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Two seconds have passed after the ECU detected an open circuit.</li> <li>● When the oxygen sensor (front) is in good condition.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● When the air/fuel ratio is rich, the oxygen sensor (front) output voltage is 0.5 V or more, the oxygen sensor (rear) output voltage is less than 0.1 V, and the oxygen sensor (rear) output voltage fluctuates within 0.078 V.</li> </ul>	




Code No.P0141 Oxygen sensor heater (rear) system <sensor 2>	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>• The engine coolant temperature is approx. 20°C or more.</li> <li>• The oxygen sensor heater (rear) remains on.</li> <li>• The engine speed is 50 r/min or more.</li> <li>• Battery voltage is 11 - 16 V.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>• The current, which flows through the oxygen sensor heater (rear), is 0.2 A or less or 3.5 A or more for six seconds.</li> </ul>	<ul style="list-style-type: none"> <li>• Malfunction of oxygen sensor heater (rear)</li> <li>• Open or short circuit in the oxygen sensor heater (rear) circuit or loose connector contact</li> <li>• Malfunction of engine-ECU</li> </ul>





Code No.P0170 Abnormal fuel system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Engine: Being learning the air-fuel ratio</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>Ten seconds or more have been passed while the fuel injection amount compensation value is too low.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>Ten seconds or more have been passed while the fuel injection amount compensation value is too high.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of fuel supply system</li> <li>Malfunction of oxygen sensor (front)</li> <li>Malfunction of intake air temperature sensor</li> <li>Malfunction of barometric pressure sensor</li> <li>Malfunction of air flow sensor</li> <li>Malfunction of engine-ECU</li> </ul>







Code No.P0190 Abnormal fuel pressure	Probable cause
Range of Check ● Ignition switch: ON Set Conditions ● The sensor output voltage is 4.8V or more, or 0.2 V or less for four seconds.	<ul style="list-style-type: none"> <li>● Malfunction of fuel pressure sensor</li> <li>● Open or short circuit in the fuel pressure sensor circuit or loose connector contact</li> <li>● Malfunction of engine-ECU</li> </ul>
Range of Check ● The following conditions are detected temporarily after the engine has been started. (1) Engine speed: 1,000 r/min or more (2) Fuel pressure: 2 MPa or more ● Engine running Set Conditions ● The fuel pressure is 6.9 MPa or more, or 2 MPa or less for four seconds.	<ul style="list-style-type: none"> <li>● Malfunction of high-pressure fuel pump</li> <li>● Clogging of high-pressure fuel lines</li> </ul>
This diagnosis code will also be output when air is trapped into the high-pressure fuel lines (such as poor fuel level). In that case, the air can be evacuated by operating the engine for at least 15 seconds at 2,000 r/min. After the repair, use the MUT-II to erase the diagnosis code.	<ul style="list-style-type: none"> <li>● Air trapped due to poor fuel level</li> </ul>







Code No.P0201 No.1 injector system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>The engine speed is 4,000 r/min or less.</li> <li>The battery voltage is 10 V or more.</li> <li>The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The injector driver is not transmitting a injector open circuit check signal for four seconds.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of No.1 injector</li> <li>Open or short circuit in the No.1 injector circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>







Code No.P0202 No.2 injector system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>The engine speed is 4,000 r/min or less.</li> <li>The battery voltage is 10 V or more.</li> <li>The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The injector driver is not transmitting a injector open circuit check signal for four seconds.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of No.2 injector</li> <li>Open or short circuit in the No.2 injector circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>







Code No.P0203 No.3 injector system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>The engine speed is 4,000 r/min or less.</li> <li>The battery voltage is 10 V or more.</li> <li>The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The injector driver is not transmitting a injector open circuit check signal for four seconds.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of No.3 injector</li> <li>Open or short circuit in the No.3 injector circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>







Code No.P0204 No.4 injector system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>The engine speed is 4,000 r/min or less.</li> <li>The battery voltage is 10 V or more.</li> <li>The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The injector driver is not transmitting a injector open circuit check signal for four seconds.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of No.4 injector</li> <li>Open or short circuit in the No.4 injector circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>







Code No.P0205 No.5 injector system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>The engine speed is 4,000 r/min or less.</li> <li>The battery voltage is 10 V or more.</li> <li>The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The injector driver is not transmitting a injector open circuit check signal for four seconds.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of No.5 injector</li> <li>Open or short circuit in the No.5 injector circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>







Code No.P0206 No.6 injector system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>• The engine speed is 4,000 r/min or less.</li> <li>• The battery voltage is 10 V or more.</li> <li>• The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>• The injector driver is not transmitting a injector open circuit check signal for four seconds.</li> </ul>	<ul style="list-style-type: none"> <li>• Malfunction of No.6 injector</li> <li>• Open or short circuit in the No.6 injector circuit or loose connector contact</li> <li>• Malfunction of engine-ECU</li> </ul>







Code No.P0220 Accelerator pedal position sensor (1st channel) system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Accelerator pedal position sensor (2nd channel) is normal.</li> <li>Communication between the engine-ECU and the throttle valve controller is normal.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The output voltage of accelerator pedal position sensor (1st channel) is 0.2 V or less for one second.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The output voltage of accelerator pedal position sensor (2nd channel) is 2.5 V or less, and that of accelerator pedal position sensor (1st channel) is 4.5 V or more for one second</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The difference between accelerator pedal position sensor (1st channel) and accelerator pedal position sensor (2nd channel) output voltages is 1.0 V or more (i.e. the throttle opening angle changes slightly).</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The output voltage of accelerator pedal position sensor (1st channel) is 1.1 V or more for one second when the accelerator pedal position switch is turned on.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of accelerator pedal position sensor (1st channel)</li> <li>Open or short circuit in the accelerator pedal position sensor (1st channel) circuit or loose connector contact</li> <li>Accelerator pedal position switch seized ON</li> <li>Malfunction of throttle valve controller</li> <li>Malfunction of engine-ECU</li> </ul>






Code No.0225 Throttle position sensor (2nd channel) system	Probable cause
<p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-ECU.                      Range of Check</p> <ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>The throttle position sensor (1st channel) is normal.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 0.2 V or less for four seconds.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 4.85 V or more for four seconds, and the output voltage of the throttle position sensor (1st channel) is 1.2 V or more.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 - 6 V.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of throttle position sensor (2nd channel)</li> <li>Open or short circuit in the throttle position sensor (2nd channel) circuit or loose connector contact</li> <li>Malfunction of the throttle valve controller</li> <li>Malfunction of the engine-ECU</li> </ul>







Code No.P0300 Ignition coil (power transistor) system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Engine speed is approx. 50 - 4,000 r/min.</li> <li>● Engine is not cranking.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The ignition failure sensor does not send a signal about a certain cylinder for four seconds.</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of the ignition coil</li> <li>● Malfunction of the ignition failure sensor</li> <li>● Malfunction of spark plug</li> <li>● Open or short circuit in the primary ignition circuit or loose connector contact</li> <li>● Malfunction of engine-ECU</li> </ul>




<p><b>Code No.P0301 No.1 cylinder misfire detected.</b>  <b>Code No.P0302 No.2 cylinder misfire detected.</b>  <b>Code No.P0303 No.3 cylinder misfire detected.</b>  <b>Code No.P0304 No.4 cylinder misfire detected.</b>  <b>Code No.P0305 No.5 cylinder misfire detected.</b></p>	<p><b>Probable cause</b></p>
<p>Range of Check</p> <ul style="list-style-type: none"> <li>The engine speed is 500 - 4,500 r/min.</li> <li>While the engine is running except deceleration and sudden acceleration.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The number of misfires exceeds a predetermined number per 200 engine revolutions (Misfire has occurred in only one cylinder).</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The number of misfires exceeds a predetermined number per 100 engine revolutions (Misfire has occurred in only one cylinder).</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of the ignition system</li> <li>Abnormal compression</li> <li>Malfunction of injector</li> <li>Malfunction of engine-ECU</li> </ul>




Code No.P0325 Detonation sensor system	Probable cause
Range of Check ● Engine: Two seconds after the engine has been started Set Conditions ● Changes in sensor output voltage (detonation sensor peak voltage per 1/3 crankshaft rotation) in 200 consecutive cycles are 0.08 V or less.	● Malfunction of the detonation sensor ● Open or short circuit in the detonation sensor circuit or loose connector contact ● Malfunction of engine-ECU




Code No.P0335 Crank angle sensor system	Probable cause
Range of Check ● Engine is cranking Set Conditions ● Sensor output voltage does not change for 4 seconds (no pulse signal input).	● Malfunction of the crank angle sensor. ● Open or short circuit in the crank angle sensor circuit or loose connector contact. ● Malfunction of engine-ECU




<b>Code No.P0340 Camshaft position sensor system</b>	<b>Probable cause</b>
Range of Check ● After the engine was started Set Conditions ● The sensor output voltage does not change for 4 seconds (no pulse signal input).	● Malfunction of the camshaft position sensor ● Open or short circuit in the camshaft position sensor circuit or loose connector contact. ● Malfunction of engine-ECU




Code No.P0403 EGR valve system	Probable cause
Range of Check ● Ignition switch: OFF to ON ● EGR valve is in operation after the engine starting process is complete. Set Conditions ● Off-surge voltage is not generated from the motor coil while the EGR valve control motor is running.	● Malfunction of the EGR valve ● Open or short circuit in the EGR valve circuit or loose connector contact ● Malfunction of engine-ECU




Code No.P0420 Catalyst malfunction	Probable cause
Range of Check ● The engine speed is 3,000 r/min or less. ● During driving ● During air/fuel ratio feedback control Set Conditions ● The ratio between the oxygen sensor (rear) and the oxygen sensor (front) output frequencies reaches 0.8 per 12 seconds on average.	● Malfunction of catalyst ● Malfunction of the oxygen sensor (front) ● Malfunction of the oxygen sensor (rear) ● Malfunction of engine-ECU




Code No.P0443 Purge control solenoid valve system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>Battery voltage is 10 V or more.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The solenoid coil surge voltage (battery voltage + 2 V) is not detected when the purge control solenoid valve is turned from on to off.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of the purge control solenoid valve</li> <li>Open or short circuit in the purge control solenoid valve circuit or loose connector contact</li> <li>Malfunction of engine-ECU</li> </ul>




Code No.P0500 Vehicle speed sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Engine: Two seconds after the engine was started</li> <li>● Idle switch: OFF</li> <li>● Engine speed: 2,500 r/min or more</li> <li>● During high engine load</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The sensor output voltage does not change for 4 seconds (no pulse signal input).</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of the vehicle speed sensor</li> <li>● Open or short circuit in the vehicle speed sensor circuit or loose connector contact</li> <li>● Malfunction of engine-ECU</li> </ul>




Code No.P1200 Injector driver system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Engine speed: 4,000 r/m or less</li> <li>● Battery voltage: 10 V or more</li> <li>● The fuel cut operation and the injector operation (by carrying out the Actuator test) are not in progress.</li> <li>● During high engine load</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● Injector open circuit check signal is not output from the injector driver.</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of the injector driver</li> <li>● Open or short circuit, or loose connector contact</li> <li>● Malfunction of engine-ECU</li> </ul>




Code No.P1220 Electronic-controlled throttle valve system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Error in communication between the engine-ECU and the throttle valve controller</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● Output voltage of throttle position sensor (2nd channel) fluctuates significantly (approx. 1 V or more) from an expected value, based on that of the accelerator pedal position sensor (2nd channel).</li> </ul> <p>Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Error in communication between the throttle valve controller and the engine-ECU</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The output voltage of the throttle position sensor (2nd channel) is significantly different (approx. 1 V) from the throttle valve opening angle (voltage), which the engine-ECU request the throttle valve controller.</li> </ul>	<ul style="list-style-type: none"> <li>● Short in communication line</li> <li>● Malfunction of the engine-ECU</li> <li>● Malfunction of the throttle valve controller</li> </ul>




Code No.P1221 Throttle valve position feedback system	Probable cause
<p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-ECU.                      Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Battery voltage: 10 V or more</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● Failure in the position feedback                      (The engine-ECU detects that the current in the motor is excessive and the opening angle difference between the target value of throttle position sensor (1st channel) and the actual value of throttle position sensor (1st channel) is 2.0 V or more)</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of throttle position sensor (1st channel)</li> <li>● Open or short circuit in the throttle position sensor (1st channel) circuit or loose connector contact</li> <li>● Malfunction of the throttle valve controller</li> </ul>




Code No.P1222 throttle valve control servo system	Probable cause
<p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-ECU.                      Range of Check</p> <ul style="list-style-type: none"> <li>throttle valve control servo relay: ON</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>Short circuit of the throttle valve control servo drive circuit to earth</li> <li>Power is supplied to the throttle valve control servo circuit from other sources.</li> <li>Open circuit in the throttle valve control servo power supply circuit</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of the throttle valve control servo</li> <li>Open circuit in the throttle valve control servo power supply circuit</li> <li>Open or short circuit in the throttle valve control servo circuit or loose connector contact</li> <li>Malfunction of throttle valve controller</li> </ul>




Code No.P1223 Communication line system with the throttle valve controller	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Battery voltage: 8 V or more.</li> <li>● Engine: not cranking</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● System detects an error in communication line between the engine-ECU and the throttle valve controller, and between the throttle valve controller and the engine-ECU.</li> </ul>	<ul style="list-style-type: none"> <li>● Short in communication line</li> <li>● Malfunction of engine-ECU</li> <li>● Malfunction of throttle valve controller</li> </ul>



Code No.P1225 Accelerator pedal position sensor (2nd channel) system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Accelerator pedal position sensor (2nd channel) is normal.</li> <li>Communication between the engine-ECU and the throttle valve controller is normal.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>Output voltage of the accelerator pedal position sensor (2nd channel) is 0.2 V or less for one second</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>Output voltage of the accelerator pedal position sensor (1st channel) is 2.5 V or less, and output voltage of the accelerator pedal position sensor (2nd channel) is 4.5 V or more for one second.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>Difference between the accelerator pedal position sensor (1st and 2nd channels) output voltages exceeds 1.0 V (i.e. when the throttle valve opening angle changes slightly).</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of accelerator pedal position sensor (2nd channel)</li> <li>Open or short circuit in accelerator pedal position sensor (2nd channel) circuit or loose connector contact</li> <li>Malfunction of the throttle valve controller</li> <li>Malfunction of engine-ECU</li> </ul>






Code No.P1226 Throttle valve controller system	Probable cause
Set Conditions • Errors in reading or writing to the throttle valve controller ROM.	• Malfunction of the throttle valve controller

Replace the throttle valve controller.


Code No.P1500 Alternator FR terminal system	Probable cause
Range of Check ● Engine speed: 50 r/min or more Set Conditions ● Input voltage from the alternator FR terminal is system voltage for 20 seconds.	● Open circuit in alternator FR terminal circuit ● Malfunction of engine-ECU



Cord No.P1610 Immobilizer system	Probable cause
Range of Check ● Ignition switch: ON Set Conditions ● Improper communication between the engine-ECU and the immobilizer-ECU	● Open or short circuit, or loose connector contact ● Malfunction of the immobilizer-ECU ● Malfunction of the engine-ECU

NOTE

- (1) If the registered ignition keys are close each other when starting the engine, radio interference may cause this code to be displayed.
- (2) This code may be displayed when registering the key encrypted code.



## INSPECTION CHART FOR TROUBLE SYMPTOMS

Trouble symptom		Inspection procedure No.	Reference page
Communication with MUT-II is impossible.	Communication with all systems is not possible.	1	13A-74
	Communication with engine-ECU only is not possible.	2	13A-75
Engine warning lamp and related parts	The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position.	3	13A-76
	The engine warning lamp remains illuminating and never goes out.	4	13A-76
Starting	No initial combustion (starting impossible)	5	13A-77
	Initial combustion but no complete combustion (starting impossible)	6	13A-79
	Long time to start (improper starting)		
Idling stability (Improper idling)	Unstable idling (Rough idling, hunting)	7	13A-81
	Idling speed is high. (Improper idling speed)	8	13A-83
	Idling speed is low. (Improper idling speed)		
Idling stability (Engine stalls)	When the engine is cold, it stalls at idling. (Die out)	9	13A-84
	When the engine is hot, it stalls at idling. (Die out)	10	13A-85
	The engine stalls when starting the car. (Pass out)	11	13A-87
	The engine stalls when decelerating.	12	13A-88
Driving	Hesitation, sag or stumble	13	13A-89
	Poor acceleration		
	Surge		
	The feeling of impact or vibration when accelerating	14	13A-90
	The feeling of impact or vibration when decelerating	15	13A-91
	Knocking	16	13A-91
Dieseling		17	13A-91
Too high CO and HC concentration when idling		18	13A-92
Low alternator output voltage (approx. 12.3 V)		19	13A-94
Engine idle speed is incorrect while the A/C is on.		20	13A-94
A/C condenser fan is inoperative		21	13A-95
Clutch switch system malfunction		22	13A-96
GDI ECO indicator lamp system	GDI ECO indicator lamp does not illuminate.	23	13A-96
	GDI ECO indicator lamp remains illuminated and does not go off.	24	13A-97

**PROBLEM SYMPTOMS TABLE (FOR YOUR INFORMATION)**


Items		Symptom
Starting	Won't start	The starter is used to crank the engine, but there is no combustion within the cylinders, and the engine won't start.
	Fires up and dies	There is combustion within the cylinders, but then the engine soon stalls.
	Hard starting	Engine starts after cranking a while.
Idling stability	Hunting	Engine speed doesn't remain constant; changes at idle.
	Rough idle	Usually, a judgement can be based upon the movement of the tachometer pointer, and the vibration transmitted to the steering wheel, shift lever, body, etc. This is called rough idle.
	Incorrect idle speed	The engine doesn't idle at the usual correct speed.
	Engine stall (Die out)	The engine stalls when the foot is taken from the accelerator pedal, regardless of whether the vehicles is moving or not.
	Engine stall (Pass out)	The engine stalls when the accelerator pedal is depressed or while it is being used.
Driving	Hesitation, Sag	<p>"Hesitation" is the delay in response of the vehicle speed (engine speed) that occurs when the accelerator is depressed in order to accelerate from the speed at which the vehicle is now traveling, or a temporary drop in vehicle speed (engine speed) during such acceleration. Serious hesitation is called "sag".</p> <p style="text-align: right;">1FU0223</p>
	Poor acceleration	Poor acceleration is inability to obtain an acceleration corresponding to the degree of throttle opening, even though acceleration is smooth, or the inability to reach maximum speed.
	Stumble	<p>Engine speed increase is delayed when the accelerator pedal is initially depressed for acceleration.</p> <p style="text-align: right;">1FU0224</p>

Items		Symptom
Driving	Shock	The feeling of a comparatively large impact or vibration when the engine is accelerated or decelerated.
	Surge	This is repeated surging ahead during constant speed travel or during variable speed travel.
	Knocking	A sharp sound like a hammer striking the cylinder walls during driving and which adversely affects driving.
Stopping	Run on ("Dieseling")	The condition in which the engine continues to run after the ignition switch is turned to OFF. Also called "Dieseling".

## INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


### INSPECTION PROCEDURE 1

Communication with MUT-II is not possible. (Communication with all systems is not possible.)	Probable cause
The cause is probably a defect in the power supply system (including earth) for the diagnosis line.	<ul style="list-style-type: none"> <li>● Malfunction of the connector</li> <li>● Malfunction of the harness wire</li> <li>● Malfunction of MUT-II</li> </ul>



## Inspection procedure 2

MUT-II communication with engine-ECU is impossible.	Probable cause
One of the following causes may be suspected. <ul style="list-style-type: none"> <li>● No power supply to engine-ECU.</li> <li>● Defective earth circuit of engine-ECU.</li> <li>● Defective engine-ECU.</li> <li>● Improper communication line between engine-ECU and MUT-II</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of engine-ECU power supply circuit</li> <li>● Malfunction of engine-ECU</li> <li>● Open circuit between the engine-ECU and diagnosis connector</li> </ul>




## NOTE

On vehicles with center display, if a malfunction cannot be resolved after the procedure above, check the center display and replace if necessary. (Refer to GROUP 54 - Center display.)


Inspection procedure 3

The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position.	Probable cause
Because there is a burnt-out bulb, the engine-ECU causes the engine warning lamp to illuminate for five seconds immediately after the ignition switch is turned to ON. If the engine warning lamp does not illuminate immediately after the ignition switch is turned to ON, one of the malfunctions listed at right has probably occurred.	<ul style="list-style-type: none"> <li>● Burnt-out bulb</li> <li>● Defective warning lamp circuit</li> <li>● Malfunction of the engine-ECU</li> </ul>




Inspection procedure 4


The engine warning lamp remains illuminating and never goes out.	Probable cause
In cases such as the above, the cause is probably that the engine-ECU is detecting a problem in a sensor or actuator, or that one of the malfunctions listed at right has occurred.	<ul style="list-style-type: none"> <li>● Short-circuit between the engine warning lamp and engine-ECU</li> <li>● Malfunction of the engine-ECU</li> </ul>



**Inspection procedure 5**


No initial combustion (starting impossible)	Probable cause
This is caused by incorrect fuel supply into the combustion chamber, and improper ignition circuit. Besides that, foreign material may be contaminated in fuel.	<ul style="list-style-type: none"> <li>● Malfunction of the fuel supply system</li> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the engine-ECU</li> </ul>






Inspection procedure 6


Initial combustion takes place, but does not complete (start impossible), too long time to start (poor start)	Probable cause
This may be caused by improper spark plug ignition (poor spark), improper mixture during engine cranking, improper fuel pressure.	<ul style="list-style-type: none"> <li>● Malfunction of the fuel supply system</li> <li>● Malfunction of the fuel pressure sensor</li> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the electronic-controlled throttle valve system</li> <li>● Malfunction of the engine-ECU</li> </ul>






Inspection procedure 7


Unstable idling (rough idle, hunting)	Probable cause
This malfunction is probably caused by a faulty ignition system, improper air/fuel ratio, a faulty electronic-controlled throttle valve system, improper compression pressure, etc. As many causes can be suspected, diagnose from easier items.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the air/fuel ratio control system</li> <li>● Malfunction of the electronic-control throttle valve system</li> <li>● Improper compression pressure</li> <li>● Air sucking into the air intake system</li> </ul>






**Inspection procedure 8**

Idle speed is high or low (Improper idling)	Probable cause
The cause is probably that the intake air amount during idling is too great or too small.	<ul style="list-style-type: none"> <li>• Malfunction of the electronic-controlled throttle valve system</li> <li>• Malfunction of the throttle body</li> </ul>




Inspection procedure 9


When the engine is cold, it stalls at idling. (Die out)	Probable cause
The cause is probably an incorrect air/fuel ratio or poor intake air amount when the engine is cold.	<ul style="list-style-type: none"> <li>● Malfunction of the electronic-control throttle valve system</li> <li>● Malfunction of the throttle body</li> </ul>



Inspection procedure 10


When the engine is hot, it stalls at idling. (Die out)	Probable cause
<p>The cause is probably an improper air/fuel ratio, faulty electronic-controlled throttle valve system, compression pressure. In addition, if the engine stalls suddenly, another possible cause might be a poor connector contact.</p>	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of air/fuel ratio control system</li> <li>● Malfunction of electronic-controlled throttle valve system</li> <li>● Malfunction of the throttle body</li> <li>● Poor connector contact</li> <li>● Improper compression pressure</li> <li>● Air stuck in the air intake system</li> </ul>






Inspection procedure 11

The engine stalls when starting the car. (Pass out)	Probable cause
The cause is probably poor ignition due to a malfunctioning spark plug (weak spark), or an incorrect air/fuel ratio when the accelerator is depressed.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the EGR valve</li> <li>● Air stuck in the air intake system</li> </ul>




## Inspection procedure 12


The engine stalls when decelerating.	Probable cause
The cause is probably an improper air/fuel ratio due to a faulty EGR system, or poor intake air volume due to a faulty electronic-controlled throttle valve system.	<ul style="list-style-type: none"> <li>● Malfunction of the electronic-controlled throttle valve system</li> <li>● Malfunction of the EGR valve</li> </ul>



Inspection procedure 13


Hesitation, sag, stumble, poor acceleration or surge	Probable cause
The cause is probably a malfunction of the ignition system, electronic-controlled throttle valve system, compression pressure, etc.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the air/fuel ratio control system</li> <li>● Malfunction of the electronic-controlled throttle valve system</li> <li>● Improper compression pressure</li> <li>● Air stuck in the air intake system</li> </ul>






**Inspection procedure 14**

The feeling of impact when accelerating	Probable cause
The cause is probably an ignition leak being generated in line with an increase in the spark plug request voltage during acceleration.	<ul style="list-style-type: none"> <li>• Malfunction of the ignition system</li> </ul>




**Inspection procedure 15**

The feeling of impact when decelerating	Probable cause
The cause is probably insufficient intake air due to a faulty electronic-controlled throttle valve system.	<ul style="list-style-type: none"> <li>Malfunction of the electronic-controlled throttle valve system</li> </ul>



**Inspection procedure 16**

Knocking	Probable cause
The cause is probably incorrect detonation control or improper heat range of the spark plugs.	<ul style="list-style-type: none"> <li>Malfunction of the detonation sensor</li> <li>Improper heat range of the spark plugs</li> </ul>




**Inspection procedure 17**


Run-on (dieseling)	Probable cause
The cause is probably fuel leak from injector(s)	<ul style="list-style-type: none"> <li>Malfunction of the injector</li> </ul>

Replace the injector.

Inspection procedure 18


Too high CO and HC concentration when idling	Probable cause
The cause is probably an incorrect air/fuel ratio	<ul style="list-style-type: none"> <li>• Malfunction of air/fuel ratio control system</li> <li>• Deterioration of the catalyst</li> </ul>






Inspection procedure 19

Low alternator output voltage (approx. 12.3 V)	Probable cause
The cause is probably a malfunction of the alternator or one of the problems listed at right.	<ul style="list-style-type: none"> <li>● Malfunction of the charging system</li> <li>● Open circuit between the alternator G terminal and the engine-ECU</li> <li>● Malfunction of the engine-ECU</li> </ul>




Inspection procedure 20

Idling speed is improper when A/C is operating	Probable cause
If the engine-ECU detects that the air conditioner is on, it activates the throttle control servo to control idle-up operation. The A/C-ECU judges if the load caused by air conditioner operation is high or low, and converts it to voltage signal (high or low voltage) and inputs the signal to the engine-ECU. Based on this voltage signal, the engine-ECU controls the idle-up speed (for high or low load).	<ul style="list-style-type: none"> <li>● Malfunction of the A/C control system</li> <li>● Improper connector contact, open circuit or short-circuited harness wire</li> <li>● Malfunction of the engine-ECU</li> </ul>




**Inspection procedure 21**

A/C condenser fan is inoperative	Probable cause
The fan motor relay is controlled by turning on and off the power transistor in the engine-ECU.	<ul style="list-style-type: none"> <li>● Malfunction of the A/C condenser fan relay.</li> <li>● Malfunction of the condenser fan motor.</li> <li>● Improper connector contact, open circuit or short-circuited harness wire</li> <li>● Malfunction of the engine-ECU</li> </ul>




Inspection procedure 22

Clutch switch system malfunction	Probable cause
The clutch pedal switch sends a signal indicating clutch pedal depression to the engine-ECU. The engine-ECU controls the fuel injection properly according to this signal, thus prevents the fluctuation of the engine speed during shift change.	<ul style="list-style-type: none"> <li>● Malfunction of the clutch switch</li> <li>● Open circuit or short-circuited harness wire in the clutch switch circuit</li> <li>● Malfunction of the engine-ECU</li> </ul>




Inspection procedure 23

GDI ECO indicator lamp does not illuminate.	Probable cause
If the GDI ECO indicator lamp does not illuminate after turning switch, the causes listed in the right column are suspected.	<ul style="list-style-type: none"> <li>● Burned-out GDI ECO indicator lamp bulb</li> <li>● Open circuit or short-circuited harness wire in the GDI ECO indicator lamp circuit</li> <li>● Malfunction of the engine-ECU</li> <li>● Malfunction of the GDI ECO indicator lamp-ECU</li> </ul>




Inspection procedure 24

GDI ECO indicator lamp remains illuminated and does not go off.	Probable cause
If the GDI ECO indicator lamp does not go off during high load operation, the causes listed in the right column are suspected.	<ul style="list-style-type: none"> <li>● Short circuit between the GDI ECO indicator lamp and engine-ECU</li> <li>● Malfunction of the engine-ECU</li> <li>● Malfunction of the GDI ECO indicator lamp-ECU</li> </ul>




Inspection procedure 25

Engine-ECU power supply and earth circuit system	Probable cause
The cause is probably a malfunction of the engine-ECU or one of the problems listed at right.	<ul style="list-style-type: none"> <li>• Open circuit or short-circuited harness wire in the engine-ECU power supply circuit</li> <li>• Open circuit or short-circuited harness wire in the engine-ECU earth circuit</li> <li>• Malfunction of the engine-ECU</li> </ul>




**Inspection procedure 26**

Engine control relay and ignition switch-IG system	Probable cause
When the ignition switch ON signal is input to the engine-ECU, the engine-ECU turns on the engine control relay. This causes system voltage to be supplied to the engine-ECU and to the sensors and actuators.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition switch</li> <li>● Malfunction of the engine control relay</li> <li>● Open circuit or short-circuited harness wire of the engine control relay circuit</li> <li>● Malfunction of the engine-ECU</li> </ul>




**Inspection procedure 27**

Ignition switch-ST system	Probable cause
The ignition switch-ST outputs a HIGH signal to the engine-ECU while the engine is cranking. The engine-ECU uses this signal to carry out functions such as fuel injection control during starting.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition switch</li> <li>● Open circuit or short-circuited harness wire of the ignition switch circuit</li> <li>● Malfunction of the engine-ECU</li> </ul>




Inspection procedure 28

Accelerator pedal position switch system	Probable cause
The accelerator pedal position switch detects that the accelerator pedal is fully closed, and sends a signal to the engine-ECU. The engine-ECU controls idle speed, based on this signal.	<ul style="list-style-type: none"> <li>● Maladjustment of the accelerator cable</li> <li>● Maladjustment of the accelerator pedal position switch</li> <li>● Open circuit or short-circuited harness wire in the accelerator pedal position switch system, or poor connector contact</li> <li>● Malfunction of the engine-ECU</li> </ul>




**Inspection procedure 29**

Fuel pump (low pressure) system	Probable cause
The engine-ECU turns on the fuel pump relay while the engine is cranking or running, and supplies power source to the fuel pump (low pressure).	<ul style="list-style-type: none"> <li>● Malfunction of the fuel pump relay</li> <li>● Malfunction of the fuel pump (low pressure)</li> <li>● Open circuit or short-circuited harness wire in the fuel pump (low pressure) circuit, or poor connector contact</li> <li>● Malfunction of the engine-ECU</li> </ul>




Inspection procedure 30

Power steering fluid pressure switch system	Probable cause
The power steering fluid pressure switch sends a signal to the engine-ECU according to power steering load. Based on this signal, the engine-ECU controls the throttle control servo so that idle speed increases when the power steering is in operation.	<ul style="list-style-type: none"> <li>● Malfunction of the power steering fluid pressure switch</li> <li>● Open circuit or short-circuited harness wire in the power steering fluid pressure switch circuit, or poor connector contact</li> <li>● Malfunction of the engine-ECU</li> </ul>




Inspection procedure 31

A/C switch and A/C relay system	Probable cause
If the engine-ECU receives a 'A/C on' signal, it operates the throttle control servo and A/C compressor magnetic clutch so that idle speed increases.	<ul style="list-style-type: none"> <li>● Malfunction of the A/C control system</li> <li>● Malfunction of the A/C switch</li> <li>● Open circuit or short-circuited harness wire in the A/C switch circuit, or poor connector contact</li> <li>● Malfunction of the engine-ECU</li> </ul>




Inspection procedure 32

Stop lamp switch system	Probable cause
The engine-ECU determines whether the brake pedal is depressed or not, by means of the stop lamp switch input signal.	<ul style="list-style-type: none"> <li>● Malfunction of the stop lamp switch</li> <li>● Open circuit or short-circuited harness wire in the stop lamp circuit, or poor connector contact</li> <li>● Malfunction of the engine-ECU</li> </ul>




**Inspection procedure 33**

Small lamp switch system	Probable cause
The engine-ECU determines whether the small lamp switch is on or off. According to that information, the engine-ECU controls alternator output current when the vehicle is started.	<ul style="list-style-type: none"> <li>• Improper connector contact, open circuit or short-circuited harness wire in the taillamp circuit</li> <li>• Malfunction of the engine-ECU</li> </ul>



**Inspection procedure 34**

Injector driver system	Probable cause
The engine-ECU drives the injector by the drive signal.	<ul style="list-style-type: none"> <li>• Malfunction of the injector driver</li> <li>• Improper connector contact, open circuit or short-circuited harness wire</li> <li>• Malfunction of the engine-ECU</li> </ul>



## DATA LIST REFERENCE TABLE

**Caution**

When shifting the select lever to D range, the brakes should be applied so that the vehicle does not move forward.

## NOTE

\*1: Within four minutes after starting the engine

\*2: In a new vehicle [driven approximately 500 km or less], the injector drive time is sometimes 10% longer than the standard time.

\*3: The accelerator pedal position switch normally turns off when the voltage of the accelerator pedal position sensor (1st channel) is 200 - 600 mV higher than the voltage at the idle position. If the accelerator pedal position switch turns back on after the accelerator pedal position sensor voltage has risen by 100 mV and the throttle valve has opened, the accelerator pedal position switch and the accelerator pedal position sensor (1st channel) need to be adjusted.

Item No.	Check items	Requirements	Normal condition	Inspection procedure No.	Reference page	
11	Oxygen sensor (front)	Engine: After warm-up	Idling	200 mV or less*1	Code No. P0130	13A-28
			Sudden racing	600 - 1,000 mV		
			2,500 r/min	400 mV or less and 600 - 1,000 mV alternates.		
12	Air flow sensor	<ul style="list-style-type: none"> <li>● Engine coolant temperature: 80 - 95°C</li> <li>● Lamps, electric cooling fan and all accessories: OFF</li> <li>● Transmission: Neutral</li> </ul>	Idling	22 - 48 Hz	Code No. P0100	13A-17
			2,500 r/min	60 - 100 Hz		
			Racing	Frequency increases in response to racing.		
13	Intake air temperature sensor	Ignition switch: ON	Intake air temperature: -20°C	-20°C	Code No. P0110	13A-21
			Intake air temperature: 0°C	0°C		
			Intake air temperature: 20°C	20°C		
			Intake air temperature: 40°C	40°C		
			Intake air temperature: 80°C	80°C		

Item No.	Check items	Requirements	Normal condition	Inspection procedure No.	Reference page	
14	Throttle position sensor (2nd channel)	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95°C</li> <li>Ignition switch: ON (Engine stopped)</li> </ul>	Release the accelerator pedal.	4,000 mV or more	Code No. P0225	13A-52
			Depress the accelerator pedal gradually.	Voltage decreases in response to the pedal depression.		
			Depress the accelerator pedal fully.	400 - 600 mV		
16	Power supply voltage	Ignition switch: ON	System voltage	Procedure No.25	13A-98	
18	Cranking signal (Ignition switch - ST)	Transmission: Neutral	Engine: Stopped	OFF	Procedure No.27	13A-99
			Engine: Cranking	ON		
21	Engine coolant temperature sensor	Ignition switch: ON	Engine coolant temperature: -20°C	-20°C	Code No. P0115	13A-22
			Engine coolant temperature: 0°C	0°C		
			Engine coolant temperature: 20°C	20°C		
			Engine coolant temperature: 40°C	40°C		
			Engine coolant temperature: 80°C	80°C		
22	Crank angle sensor	<ul style="list-style-type: none"> <li>Engine: cranking</li> <li>Tachometer: Connected</li> </ul>	Compare the engine speed readings on the tachometer and the MUT-II.	Accord	Code No. P0335	13A-56
			<ul style="list-style-type: none"> <li>Engine: Idling</li> <li>Accelerator pedal position switch: ON</li> </ul>	Engine coolant temperature: -20°C		
		Engine coolant temperature: 0°C		1,100 - 1,300 r/min		
		Engine coolant temperature: 20°C		1,000 - 1,200 r/min		
		Engine coolant temperature: 40°C		900 - 1,100 r/min		
		Engine coolant temperature: 80°C	550 - 650 r/min*1			

Item No.	Check items	Requirements	Normal condition	Inspection procedure No.	Reference page	
25	Barometric pressure sensor	Ignition switch: ON	Altitude: 0 m	101 kPa	Code No. P0105	13A-19
			Altitude: 600 m	95 kPa		
			Altitude: 1,200 m	88 kPa		
			Altitude: 1,800 m	81 kPa		
26	Accelerator pedal position switch	Ignition switch: ON (Depress and release the accelerator pedal several times)	Release the accelerator pedal.	ON	Procedure No.28	13A-100
			Depress the accelerator pedal slightly.	OFF		
27	Power steering fluid pressure switch	Engine: Idling	Steering wheel stationary	OFF	Procedure No.30	13A-102
			Steering wheel turning	ON		
28	A/C switch	Engine: Idling (The A/C compressor is running when the A/C switch is on.)	A/C switch: OFF	OFF	Procedure No.31	13A-100
			A/C switch: ON	ON		
31	Small lamp switch	Engine: Idling	Lighting switch: OFF	OFF	Procedure No.33	13A-104
			Lighting switch: ON	ON		
34	Air flow sensor reset signal	Engine: After having warmed up	Engine is idling	ON	Code No. P0100	13A-17
			3,000 r/min	OFF		
37	Volumetric efficiency	<ul style="list-style-type: none"> <li>● Engine coolant temperature: 80 - 95°C</li> <li>● Lamps, electric cooling fan and all accessories: OFF</li> <li>● Transmission: Neutral</li> </ul>	Engine is idling	20 - 40%	-	-
			2,500 r/min	10 - 30%		
			Engine is suddenly raced	Volumetric efficiency increases in response to racing		
38	Crank angle sensor	<ul style="list-style-type: none"> <li>● Engine: Cranking [reading is possible at 2,000 r/min or less]</li> <li>● Tachometer: Connected</li> </ul>	Engine speeds displayed on the MUT-II and tachometer are identical.	-	-	

Item No.	Check items	Requirements	Normal condition	Inspection procedure No.	Reference page	
41	Injector drive time *2	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95°C</li> <li>Lamps, electric cooling fan and all accessories: OFF</li> <li>Transmission: Neutral</li> </ul>	Idling	0.3 - 0.8 ms*1	-	-
			2,500 r/min	0.4 - 1.0 ms		
			Sudden racing	Increases		
44	Ignition advance	<ul style="list-style-type: none"> <li>Engine: After warm-up</li> <li>Set a timing light.</li> </ul>	Idling	5 - 20° BTDC *1	Code No. P0300	13A-53
			2,500 r/min	15 - 35° BTDC		
49	A/C relay	Engine: After warm-up, idling	A/C switch: OFF	OFF (compressor clutch is not operating)	Procedure No.31	13A-102
			A/C switch: ON	ON (compressor clutch is operating)		
59	Oxygen sensor (rear)	<ul style="list-style-type: none"> <li>Transmission: 2nd gear</li> <li>Drive with throttle widely open</li> </ul>	3,500 r/min	600 - 1,000 mV	Code No. P0136	13A-31
67	Stop lamp switch	Ignition switch: ON	Brake pedal: Depressed	OFF	Procedure No.32	13A-103
			Brake pedal: Released	ON		
68	EGR valve	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95°C</li> <li>Lamps, electric cooling fan and all accessories: OFF</li> <li>Transmission: Neutral</li> </ul>	Idling	2 - 20 STEP	Code No. P0403	13A-60
			2,500 r/min	0 - 10 STEP		
74	Fuel pressure sensor	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95°C</li> <li>Lamps, electric cooling fan and all accessories: OFF</li> <li>Transmission: Neutral</li> </ul>	Engine: Idling	4 - 6.9 MPa	Code No. P0190	13A-36

Item No.	Check items	Requirements	Normal condition	Inspection procedure No.	Reference page	
77	Accelerator pedal position sensor (2nd channel)	Ignition switch: ON	Release the accelerator pedal.	985 - 1085 mV	Code No.P1225	13A-68
			Depress the accelerator pedal gradually.	Increases in response to the pedal depression stroke.		
			Depress the accelerator pedal fully.	4,000 mV or more		
78	Accelerator pedal position sensor (1st channel) *3	Ignition switch: ON	Release the accelerator pedal.	985 - 1085 mV	Code No.P0220	13A-50
			Depress the accelerator pedal gradually.	Increases in response to pedal depression stroke.		
			Depress the accelerator pedal fully.	4,200 - 4,800 mV		
79	Throttle position sensor (1st channel)	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95°C</li> <li>Ignition switch: ON (Engine stopped)</li> </ul>	Release the accelerator pedal.	400 - 800 mV	Code No.0120	13A-25
			Depress the accelerator pedal gradually.	Increases in response to pedal depression stroke.		
			4,600 - 5,200 mV	4,200 - 4,800 mV		
		Engine: After warm-up, idling	No load	450 - 1,000 mV		
		A/C switch: OFF → ON	Increases by 100 - 600 mV.			
99	Fuel injection mode	Engine: After warm up	Idling (after four minutes or more have passed since engine start)	Lean compression	-	-
			2,500 r/min	Stoichiometric metric feedback		
			Sudden racing after idle position	Open loop		


## ACTUATOR TEST REFERENCE TABLE

Item No.	Inspection item	Drive contents	Inspection contents	Normal condition	Inspection procedure No.	Reference page
01	Injectors	Cut fuel to No. 1 injector	Engine: After having warmed up/Engine is idling (Cut the fuel supply to each injector in turn and check cylinders which don't affect idling.)	Idling condition becomes different (becomes unstable).	Code No. P0201	13A-38
02		Cut fuel to No. 2 injector			Code No. P0202	13A-40
03		Cut fuel to No. 3 injector			Code No. P0203	13A-42
04		Cut fuel to No. 4 injector			Code No. P0204	13A-44
05		Cut fuel to No. 5 injector			Code No. P0205	13A-46
06		Cut fuel to No. 6 injector			Code No. P0206	13A-48
07	Fuel pump (low pressure)	Fuel pump operates and fuel is recirculated.	Ignition switch: ON	Sound of operation is heard.	Procedure No. 29	13A-101
08	Purge control solenoid valve	Solenoid valve turns from OFF to ON.	Ignition switch: ON	Sound of operation can be heard when solenoid valve is driven.	Code No. P0443	13A-62
17	Basic ignition timing	Set the engine-ECU to ignition timing adjustment mode	Idling after engine warm up	5° BTDC	-	-
21	Condenser fan	Drive the fan motor	Ignition switch: ON	The fan motor operates	Procedure No.21	13A-95
34	Electronic-controlled throttle valve system	Stop the throttle control servo.	Ignition switch: ON	Throttle valve is opened slightly.	Code No. P1220	13A-64

**CHECK AT THE ENGINE-ECU TERMINALS**

**TERMINAL VOLTAGE CHECK CHART**

**Engine-ECU Connector Terminal Arrangement**



7FU2119

Terminal No.	Check item	Check requirements (engine condition)	Normal condition
1	No.1 injector	Engine: Warm up, and then depress the accelerator pedal suddenly from the idle speed.	Decreases slightly for short time from 9 - 13 V.
9	No.2 injector		
24	No.3 injector		
2	No.4 injector		
10	No.5 injector		
25	No.6 injector		
3	No.1 ignition coil	Engine: 3,000 r/min	0.3 - 3.0 V.
12	No.2 ignition coil		
26	No.3 ignition coil		
4	No.4 ignition coil		
13	No.5 ignition coil		
27	No.6 ignition coil		
5	EGR valve (D)	Ignition switch: Immediately after turning ON	5 - 8 V (fluctuates for approx. three seconds)
6	EGR valve (C)		
32	EGR valve (B)		
34	EGR valve (A)		
8	Alternator G terminal	<ul style="list-style-type: none"> <li>● Engine: Warm up, and then idling</li> <li>● Radiator fan: not operating</li> <li>● Headlamp: OFF → ON</li> <li>● Stop lamp: OFF → ON</li> <li>● Rear defogger switch: OFF → ON</li> </ul>	Voltage increases by 0.2 - 3.5 V
14	GDI ECO indication lamp	Ignition switch: OFF → ON	0 - 3 V (system voltage after five seconds)
		Engine: When the accelerator pedal is suddenly depressed while the engine is idling	System voltage

Terminal No.	Check item	Check requirements (engine condition)		Normal condition
16	Purge control solenoid valve	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95°C</li> <li>Ignition switch: ON</li> </ul>	Engine: stopped	System voltage
			Engine: Start the engine, and then increase engine speed up to 3,500 r/min.	Voltage decreases.
18	Condenser fan relay	Condenser fan is not operating.		System voltage
		Condenser fan is operating.		0 - 3 V
20	Fuel pump relay	Ignition switch: ON	Engine: stopped	System voltage
			Engine: idling	0 - 3 V
21	A/C relay	<ul style="list-style-type: none"> <li>Engine: idling</li> <li>A/C switch: OFF → ON (Compressor is operating)</li> </ul>		System voltage, or changes from momentarily 6 V or more to 0 → 3 V
31	Engine warning lamp	Ignition switch: OFF → ON		0 - 3 V → System voltage (after several seconds)
41	Sensor power supply	Ignition switch: ON		4.5 - 5.5 V
42	Power supply to accelerator pedal position sensor (1st channel)	Ignition switch: ON		4.5 - 5.5 V
43	Crank angle sensor	Engine: Cranking		0.4 - 4.0 V
		Engine: Idling		1.5 - 2.5 V
44	Engine coolant temperature sensor	Ignition switch: ON	Engine coolant temperature: 0 °C	3.2 - 3.5 V
			Engine coolant temperature: 20 °C	2.3 - 2.9 V
			Engine coolant temperature: 40 °C	1.5 - 2.1 V
			Engine coolant temperature: 80 °C	0.4 - 1.0 V
45	Engine ignition signal	Engine: 3,000 r/min		0.3 - 3.0 V

Terminal No.	Check item	Check requirements (engine condition)		Normal condition
47	Power supply	Ignition switch: ON		System voltage
59				
50	Camshaft position sensor	Engine: Cranking		0.4 - 3.0 V
		Engine: Idling		0.5 - 2.0 V
51	Barometric pressure sensor	Ignition switch: ON	Altitude: 0 m	3.7 - 4.3 V
			Altitude: 1,200 m	3.2 - 3.8 V
52	Alternator FR terminal	<ul style="list-style-type: none"> <li>● Engine: Warm up, and then idling</li> <li>● Radiator fan: not operating</li> <li>● Headlamp: OFF → ON</li> <li>● Stop lamp: OFF → ON</li> <li>● Rear defogger: OFF → ON</li> </ul>		Voltage decreases
53	Oxygen sensor (rear)	<ul style="list-style-type: none"> <li>● Transmission: 2nd gear</li> <li>● Engine speed: 3,500 r/min or more</li> <li>● Driving with the throttle valve widely open</li> </ul>		0.6 - 1.0 V
54	Power steering fluid pressure switch	Engine: Warm up, and then idling	Steering wheel stationary	System voltage
			Steering wheel turning	0 - 3 V
55	Injector driver relay	Ignition switch: OFF		0 - 0.1 V
		Ignition switch: ON		0.5 - 1.0 V
56	Throttle valve control servo relay	Ignition switch: OFF		0 - 0.3 V
		Ignition switch: ON		0.5 - 1.0 V
57	Engine control relay	Ignition switch: OFF		0 - 3 V
		Ignition switch: ON		System voltage
60	Back-up power source	Ignition switch: OFF		System voltage
61	Air flow sensor	Engine: Idling		2.2 - 3.2 V
		Engine: 2,500 r/min		
62	Intake air temperature sensor	Ignition switch: ON	Intake air temperature: 0°C	3.2 - 3.8 V
			Intake air temperature: 20°C	2.3 - 2.9 V
			Intake air temperature: 40°C	1.5 - 2.1 V
			Intake air temperature: 80°C	0.4 - 1.0 V

Terminal No.	Check item	Check requirements (engine condition)	Normal condition	
63	Stop lamp switch	Depress the brake pedal.	System voltage	
		Release the brake pedal.	0 - 3 V	
65	A/C switch (2nd channel)	Refer to GROUP 55 - Troubleshooting "Check at the A/C-ECU terminal, engine-ECU output terminals."		
66	Clutch switch	Depress the clutch pedal.	0 - 3 V	
		Release the clutch pedal.	System voltage	
68	Ignition switch-ST	Engine: Cranking	8V or more	
71	Oxygen sensor (front)	Engine: Warm up, and then hold the engine speed at 2,500r/min (Use a digital voltmeter).	0 ↔ 0.8 V alternates.	
76	Air flow sensor reset signal	Engine: Idling	0 - 1 V	
		Engine: 3,000 r/min	6 - 9 V	
78	Throttle position sensor (2nd channel)	Ignition switch: ON	Release the accelerator pedal.	4.5 - 5.5 V
			Depress the accelerator pedal fully.	0.4 - 0.6 V
79	Accelerator pedal position switch	Ignition switch: ON	Release the accelerator pedal.	0 - 1 V
			Depress the accelerator pedal fully.	4V or more
80	Vehicle speed sensor	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Move the vehicle forward.</li> </ul>	0 ↔ system voltage alternates.	
83	A/C switch (1st channel)	Engine: Idling	A/C switch: OFF	0 - 3 V
			A/C switch: ON (Compressor is operating)	System voltage
88	Small lamp switch	Lighting switch: OFF	0 - 3 V	
		Lighting switch: ON (Taillamp: ON)	System voltage	
89	Oxygen sensor heater (front)	Engine: Idling	0 - 3 V	
		Engine: 3,500 r/min	System voltage	
90	Oxygen sensor heater (rear)	Engine: Idling	0 - 3 V	
		Engine: 3,500 r/min	System voltage	
92	Fuel pressure sensor	Engine: Idling	0.3 - 4.7 V	

Terminal No.	Check item	Check requirements (engine condition)		Normal condition
94	Accelerator pedal position sensor (1st channel)	Ignition switch: ON	Release the accelerator pedal.	0.3 - 1.0 V*1
			Depress the accelerator pedal fully.	4.2 - 5.5 V*2
96	Injector open circuit check signal	Engine: Increase engine speed from idle speed to 4,000 r/min.		Decreases slightly (approx. 0.7V) from 4.5 V - 5.0 V.
99	Ignition switch - IG	Ignition switch: ON		System voltage

**NOTE**

Check if the difference in output between \*1 and \*2 is 4 V or more.

### CHECK CHART FOR RESISTANCE AND CONTINUITY BETWEEN TERMINALS

1. Turn the ignition switch to OFF.
2. Disconnect the engine-ECU connector.
3. Measure the resistance and check for continuity between the terminals of the engine-ECU harness-side connector while referring to the check chart.

**NOTE**

- (1) When measuring resistance and checking continuity, a harness for checking contact pin pressure should be used instead of inserting a test probe.
- (2) Checking need not be carried out in the order given in the chart.

**Caution**

**If the terminals that should be checked are mistaken, or if connector terminals are not correctly shorted to earth, damage may be caused to the vehicle wiring, sensors, engine-ECU and/or ohmmeter.**

**Be careful to prevent this!**

4. If the ohmmeter shows any deviation from the standard value, check the corresponding sensor, actuator and related electrical wiring, and then repair or replace.
5. After repair or replacement, recheck with the ohmmeter to confirm that the repair or replacement has corrected the problem.

## Engine-ECU Harness Side Connector Terminal Arrangement

1	9	24
2	10	25
3	11	26
4	12	27
5	13	28
6	14	29
7	15	30
8	16	31
9	17	32
10	18	33
11	19	34
12	20	35
13	21	36
14	22	37
15	23	38
16	24	39
17	25	40
18	26	41
19	27	42
20	28	43
21	29	44
22	30	45
23	31	46
24	32	47
25	33	48
26	34	49
27	35	50
28	36	51
29	37	52
30	38	53
31	39	54
32	40	55
33	41	56
34	42	57
35	43	58
36	44	59
37	45	60
38	46	61
39	47	62
40	48	63
41	49	64
42	50	65
43	51	66
44	52	67
45	53	68
46	54	69
47	55	70
48	56	71
49	57	72
50	58	73
51	59	74
52	60	75
53	61	76
54	62	77
55	63	78
56	64	79
57	65	80
58	66	81
59	67	82
60	68	83
61	69	84
62	70	85
63	71	86
64	72	87
65	73	88
66	74	89
67	75	90
68	76	91
69	77	92
70	78	93
71	79	94
72	80	95
73	81	96
74	82	97
75	83	98
76	84	99
77	85	100


7FU2120

Terminal No.	Check item	Standard value, normal condition (check requirements)
5 - 47	EGR valve (D)	15 - 20 $\Omega$ (at 20°C)
6 - 47	EGR valve (C)	
32 - 47	EGR valve (B)	
34 - 47	EGR valve (A)	
16 - 47	Purge control solenoid valve	36 - 44 $\Omega$ (at 20°C)
44 - 72	Engine coolant temperature sensor	5.1 - 6.5 k $\Omega$ (when engine coolant temperature is 0°C)
		2.1 - 2.7 k $\Omega$ (when engine coolant temperature is 20°C)
		0.9 - 1.3 k $\Omega$ (when engine coolant temperature is 40°C)
		0.26 - 0.36 k $\Omega$ (when engine coolant temperature is 80°C)
46 - Body earth	Earth	Continuity (0 $\Omega$ )
58 - Body earth		
62 - 72	Intake air temperature sensor	5.3 - 6.7 k $\Omega$ (when intake air temperature is 0°C)
		2.3 - 3.0 k $\Omega$ (when intake air temperature is 20°C)
		1.0 - 1.5 k $\Omega$ (when intake air temperature is 40°C)
		0.30 - 0.42 k $\Omega$ (when intake air temperature is 80°C)
79 - 49	Accelerator pedal position switch	Continuity (when the accelerator pedal is released)
		No continuity (when the accelerator pedal is slightly depressed)
89 - 47	Oxygen sensor heater control (front)	4.5 - 8.0 $\Omega$ (at 20°C)
90 - 47	Oxygen sensor heater (rear)	4.5 - 8.0 $\Omega$ (at 20°C)

## CHECK AT THE THROTTLE VALVE CONTROLLER TERMINALS


### TERMINAL VOLTAGE CHECK CHART

#### Throttle Valve Controller Terminal Arrangement



7FU2290

Terminal No.	Check item	Check condition (Engine condition)		Normal condition
1	Throttle control servo (U)	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>Accelerator pedal: From released position to fully depressed position</li> </ul>		Changes
14	Throttle control servo (V)			
15	Throttle control servo (W)			
2	Throttle control servo power supply	Ignition switch: ON		System voltage
5	Power supply	Ignition switch: ON		System voltage
6	Sensor applied voltage	Ignition switch: ON		4.5 - 5.5 V
7	Throttle position sensor (1st channel)	Ignition switch: ON	Release the accelerator pedal.	0.4 - 0.8 V
			Depress the accelerator pedal fully.	4.2 - 4.8 V
18	Backup power supply	Ignition switch: OFF		System voltage
20	Accelerator pedal position sensor (2nd channel)	Ignition switch: ON	Release the accelerator pedal.	0.985 - 1.085 V
			Depress the accelerator pedal fully.	4.0 V or higher
22	Ignition switch-IG	Ignition switch: ON		System voltage



**INSPECTION PROCEDURE USING AN ANALYZER**

**AIR FLOW SENSOR (AFS)**

**Measurement Method**

1. Disconnect the air flow sensor connector, and connect the special tool (test harness: MB991709) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to air flow sensor connector terminal 3.

**Alternate Method (Test harness not available)**


1. Connect the analyzer special patterns pickup to engine-ECU terminal 61.

**Standard Wave Pattern**

**Observation conditions**


Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min	Idle speed

**Standard wave pattern**



7FU1199


**Observation conditions (from conditions above engine speed is increased by racing.)**



7FU0880

**Wave Pattern Observation Points**

Check that cycle time T becomes shorter and the frequency increases when the engine speed is increased.



### Examples of Abnormal Wave Patterns

- Example 1

#### Cause of problem

Sensor interface malfunction

#### Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.


- Example 2

#### Cause of problem

Damaged rectifier or vortex generation column

#### Wave pattern characteristics

Unstable wave pattern with non-uniform frequency. However, when an ignition leak occurs during acceleration, the wave pattern will be distorted temporarily, even if the air flow sensor is normal.



### CAMSHAFT POSITION SENSOR AND CRANK ANGLE SENSOR

#### Measurement Method

1. Disconnect the camshaft position sensor connector and connect the special tool (test harness: MB991709) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to camshaft position sensor terminal 2.
3. Disconnect the crank angle sensor connector and connect the special tool (test harness: MD998478) in between.
4. Connect the analyzer special patterns pickup to crank angle sensor terminal 2.

#### Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-ECU terminal 50. (When checking the camshaft position sensor signal wave pattern.)
2. Connect the analyzer special patterns pickup to engine-ECU terminal 43. (When checking the crank angle sensor signal wave pattern.)

### Standard Wave Pattern

#### Observation conditions

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min	Idle speed

## Standard wave pattern




## NOTE

1. TDC: Top dead centre
2. The time (cycle time)  $T$  is reduced when the engine speed increases

## Wave Pattern Observation Points

Check that cycle time  $T$  becomes shorter when the engine speed increases.



01P0199

## Examples of Abnormal Wave Patterns


- Example 1

**Cause of problem**

Sensor interface malfunction

**Wave pattern characteristics**

Rectangular wave pattern is output even when the engine is not started.



7FU1192


- Example 2

**Cause of problem**

Loose timing belt  
Abnormality in sensor disk

**Wave pattern characteristics**

Wave pattern is displaced to the left or right.



**INJECTORS AND INJECTOR OPEN CIRCUIT CHECK SIGNAL**


**Measurement Method**

1. Connect the analyzer special patterns pickup to terminal 1 (No.1 injector) of the engine-ECU connector.
2. Connect the analyzer special patterns pickup to terminal 96 (injector open circuit check signal) of the engine-ECU connector.
3. After checking terminal 1, check terminal 9 (No.2 injector), terminal 24 (No.3 injector) and terminal 2 (No.4 injector), terminal 10 (No.5 injector), terminal 25 (No.6 injector).


**Standard Wave Pattern  
Observation conditions**

Function	Special pattern
Pattern height	Low
Pattern selector	Display
Engine r/min	Idle speed

**Standard wave pattern**




7FU2123



**Wave Pattern Observation Points**

- Check that the injector drive time is identical to the time displayed on the MUT-II.
- Check that the injector signals become greatly extended but soon return to their normal wave length when the engine is suddenly raced.
- Check that the injector open circuit check signal is synchronized with each rising portion of the injector drive signal.



**IGNITION COIL AND POWER TRANSISTOR**

Power transistor control signal

**Measurement Method**

1. Disconnect the ignition coil connector, and connect the special tool (test harness: MB991658) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to terminal 3 of each ignition coil connector in turn.

**Alternate Method (Test harness not available)**


1. Connect the analyzer special patterns pickup to engine-ECU terminal 3 (No. 1 ignition coil), terminal 12 (No. 2 ignition coil), terminal 26 (No. 3 ignition coil), terminal 4 (No. 4 ignition coil), terminal 13 (No.5 ignition coil), terminal 27 (No.6 ignition coil) respectively.

**Standard Wave Pattern**

**Observation condition**

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min	Approx. 1,200 r/min

**Standard wave pattern**



T: Revolution time corresponding to a crank angle of 180°


T<sub>1</sub>: Time calculated by the engine-ECU

θ: Spark advance angle

**Wave Pattern Observation Points**

Point: Condition of wave pattern build-up section and maximum voltage (Refer to abnormal wave pattern examples 1 and 2.)

Condition of wave pattern build-up section and maximum voltage	Probable cause
Rises from approx. 2V to approx. 4.5V at the top-right	Normal
2V rectangular wave	Open-circuit in ignition primary circuit
Rectangular wave at power voltage	Power transistor malfunction

**Examples of Abnormal Wave Patterns**

- Example 1


Wave pattern during engine cranking

**Cause of problem**

Open-circuit in ignition primary circuit

**Wave pattern characteristics**

Top-right part of the build-up section cannot be seen, and voltage value is approximately 2V too low.



- Example 2


Wave pattern during engine cranking

**Cause of problem**

Malfunction in power transistor

**Wave pattern characteristics**

Power voltage results when the power transistor is ON.



**EGR VALVE (STEPPER MOTOR)**

**Measurement Method**

1. Disconnect the EGR valve connector, and connect the special tool (test harness: MB991658) in between.
2. Connect the analyzer special patterns pickup to the EGR valve-side connector terminal 1, terminal 3, terminal 4 and terminal 6 respectively.

**Alternate Method (Test harness not available)**


1. Connect the analyzer special patterns pickup to engine-ECU terminal 32, connection terminal 34, connection terminal 5, and connection terminal 6 respectively.

**Standard Wave Pattern**

**Observation conditions**

Function	Special patterns
Pattern height	High
Pattern selector	Display
Engine condition	When the engine coolant temperature is 20°C or below, turn the ignition switch from OFF to ON (without starting the engine).
	While the engine is idling, turn the A/C switch to ON.
	Immediately after starting the warm engine

**Standard wave pattern**



**Wave Pattern Observation Points**


Check that the standard wave pattern appears when the EGR control servo is operating.

Point A: Presence or absence of induced electromotive force from the motor turning. (Refer to the abnormal wave pattern.)

Contrast with standard wave pattern	Probable cause
Induced electromotive force does not appear or is extremely small.	Motor is malfunctioning

Point B: Height of coil reverse electromotive force

Contrast with standard wave pattern	Probable cause
Coil reverse electromotive force does not appear or is extremely small.	Short in the coil



**Examples of Abnormal Wave Pattern**


- Example 1

**Cause of problem**

Motor is malfunctioning. (Motor is not operating.)

**Wave pattern characteristics**

Induced electromotive force from the motor turning does not appear.



- Example 2

**Cause of problem**

Open circuit in the line between the EGR valve and the engine-ECU

**Wave pattern characteristics**

Current is not supplied to the motor coil on the open circuit side. (Voltage does not drop to 0 V.)

Furthermore, the induced electromotive force waveform at the normal side is slightly different from the normal waveform.


## TROUBLESHOOTING <A/T>

### STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING

Refer to GROUP 00 - How to Use Troubleshooting/Inspection Service Points.

#### NOTE

When replacing the engine-A/T-ECU, replace immobilizer-ECU as well at the same time.



### DIAGNOSIS FUNCTION

#### ENGINE WARNING LAMP (CHECK ENGINE LAMP)

If an abnormality occurs in any of the following items related to the GDI system, the engine warning lamp will illuminate. If the lamp remains illuminated or if the lamp illuminates while the engine is running, check the diagnosis code output. However, the warning lamp will illuminate as bulb check for five seconds whenever the ignition switch is turned to the ON position.

#### Engine warning lamp inspection items

Air flow sensor	Ignition coil (power transistor)
Barometric pressure sensor	Detonation sensor
Intake air temperature sensor	Crank angle sensor
Engine coolant temperature sensor	Camshaft position sensor
Oxygen sensor	EGR valve
Oxygen sensor heater	Purge control solenoid valve
Fuel system malfunction	Injector driver
Abnormal fuel pressure	Electronic-controlled throttle valve system
Injector	Throttle control servo
Throttle position sensor (1st channel)	Throttle valve controller
Throttle position sensor (2nd channel)	Immobilizer system
Accelerator pedal position sensor (1st channel)	Engine-A/T-ECU
Accelerator pedal position sensor (2nd channel)	-

#### Caution

**If a malfunction occurred inside the engine-A/T-ECU, the engine warning lamp will remain illuminated.**

#### NOTE

The engine warning lamp will flash when the electronic-controlled throttle valve system is suspended by the fail-safe function.

**METHOD OF READING AND ERASING DIAGNOSIS CODES**

Refer to GROUP 00 - How to Use Troubleshooting/Inspection Service Points.

**DIAGNOSIS USING DIAGNOSIS 2 MODE**

1. Switch the diagnosis mode of the engine-A/T-ECU to DIAGNOSIS 2 mode using the MUT-II, and then carry out a road test.
2. Take a reading of the diagnosis code and repair the problem location.
3. Turn the ignition switch to the LOCK (OFF) position, and then back to ON again.

**NOTE**

By turning the ignition switch to the LOCK (OFF) position, the engine-A/T-ECU will switch the DIAGNOSIS 2 mode to DIAGNOSIS 1 mode.

4. Erase the diagnosis codes.

**INSPECTION USING MUT-II DATA LIST AND ACTUATOR TESTING**

1. Carry out inspection by means of the data list and actuator test function. If there is an abnormality, check and repair the chassis harnesses and components.
2. After repairing, re-check using the MUT-II and check that the abnormal input and output have returned to normal as a result of the repairs.
3. Erase the diagnosis code memory.
4. Remove the MUT-II, and then start the engine again and carry out a road test to confirm that the problem has disappeared.

**FAIL-SAFE FUNCTION REFERENCE TABLE**

When the main sensor malfunctions are detected by the diagnosis function, the vehicle is controlled by means of the pre-set control logic to maintain safe conditions for driving.

Malfunctioning item	Control contents during malfunction
Air flow sensor	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Uses the throttle position sensor signal and engine speed signal (crank angle sensor signal) to take reading of the basic injector drive time and basic ignition timing from the pre-set mapping.</li> </ol>
Intake air temperature sensor	Controls as if the intake air temperature is 25°C.
Throttle position sensor (2nd channel)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Controls the throttle opening angle feedback (half as much as the opening rate in the normal condition) by using signals from the throttle position sensor (1st channel). However, this controlling system is not applied if the throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 - 6 V.</li> <li>3. Refrains from controlling the throttle opening angle feedback if the throttle position sensor (1st channel) is also defective.</li> </ol>
Engine coolant temperature sensor	Controls as if the engine coolant temperature is 80°C. (Moreover, the control system is working until the ignition switch is turned OFF if the sensor signal returns to normal.)
Camshaft position sensor	Cuts the fuel supply once a malfunction is detected. (Only when there has been no occasion of detecting No.1 cylinder top dead centre after the ignition switch is turned ON.)
Vehicle speed sensor	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation. However, the control is cancelled as a certain time passes by with the engine speed of 1,500 r/min or more.</li> <li>2. Suspends lean burn operation during the engine idling.</li> </ol>
Barometric pressure sensor	Controls as if the barometric pressure is 101 kPa.
Detonation sensor	Fixes the ignition timing as that for regular gasoline.
Injector	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Suspends the exhaust gas recirculation.</li> </ol>
Ignition coil (incorporating power transistor)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Cuts off the fuel supply to cylinders with an abnormal ignition signal.</li> </ol>
Fuel pressure sensor	<ol style="list-style-type: none"> <li>1. Controls as if the fuel pressure is 5MPa.</li> <li>2. Suspends fuel injection. (when the low pressure is detected and the engine speed is more than 3,000r/min)</li> </ol>
Alternator FR terminal	Refrains from controlling to suppress the alternator output to electrical load. (Operated as a normal alternator)
Accelerator pedal position sensor (2nd channel)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Controls the throttle valve position by using signals from the accelerator pedal position sensor (1st channel). (However, the control system is not applicable if the difference from the accelerator pedal position sensor (1st channel) output voltage is 1.0V or higher.)</li> <li>3. Suspends the electronic controlled throttle valve system if accelerator pedal position sensor (1st channel) is also defective.</li> </ol>

Malfunctioning item	Control contents during malfunction
Accelerator pedal position sensor (1st channel)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Controls the throttle valve position by using signals from the accelerator pedal position sensor (2nd channel). (However, this control is not applicable if the voltage difference between the accelerator pedal position sensor (1st channel) and accelerator pedal position sensor (2nd channel) is 1.0 V or higher.)</li> <li>3. Also suspends the electronic-controlled throttle valve system when the accelerator pedal position sensor (2nd channel) is defective.</li> </ol>
Throttle position sensor (1st channel)	<ol style="list-style-type: none"> <li>1. Suspends lean burn operation.</li> <li>2. Controls throttle opening angle feedback by using signals from throttle position sensor (2nd channel). (However, the controlling system is not applied when the throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 - 6 V.)</li> <li>3. Refrains from controlling the throttle opening angle feedback when throttle position sensor (2nd channel) is also defective.</li> </ol>
Electronic-controlled throttle valve system	<ol style="list-style-type: none"> <li>1. Suspends the electronic controlled throttle valve system.</li> <li>2. Suspends lean burn operation.</li> <li>3. Suspends the idle speed feedback control.</li> </ol>
Throttle valve position feedback	<ol style="list-style-type: none"> <li>1. Suspends the electronic controlled throttle valve system.</li> <li>2. Suspends lean burn operation.</li> <li>3. Suspends the engine speed feedback control.</li> </ol> <p>However, if the throttle valve opening angle is significantly wide, this system carries out the following controls.</p> <ol style="list-style-type: none"> <li>1. Always cuts the fuel supply to three cylinders.</li> <li>2. Cuts the fuel supply when the engine speed reaches 3,000 r/min or more.</li> </ol>
Throttle control servo	<ol style="list-style-type: none"> <li>1. Suspends the electronic-controlled throttle valve system.</li> <li>2. Suspends lean burn operation.</li> <li>3. Suspends the engine speed feedback control.</li> </ol>
Communication line between the throttle valve controller and the ECU	<ol style="list-style-type: none"> <li>1. Communication error between the throttle valve controller and the engine-A/T-ECU: <ul style="list-style-type: none"> <li>● Suspends lean burn operation.</li> <li>● Cuts the fuel supply when the engine speed reaches 3,000 r/min or more.</li> <li>● Suspends the cruise-control.</li> </ul> </li> <li>2. Communication error between the throttle valve controller and the engine-A/T-ECU: <ul style="list-style-type: none"> <li>● Suspends lean burn operation.</li> <li>● Cuts the fuel supply when the engine speed reaches 3,000 r/min or more.</li> <li>● Suspends the cruise-control.</li> <li>● The throttle valve controller controls the throttle valve opening angle by using signals from accelerator pedal position sensor (2nd channel).</li> </ul> </li> </ol>
Throttle valve controller	<ol style="list-style-type: none"> <li>1. Suspends the electronic-controlled throttle valve system.</li> <li>2. Suspends lean burn operation.</li> <li>3. Suspends the engine speed feedback control.</li> </ol>

## NOTE

If the electronic-controlled throttle valve system is suspended, the engine warning lamp will illuminate.

## INSPECTION CHART FOR DIAGNOSIS CODES


Code No.	Diagnosis item	Reference page
11	Oxygen sensor system	13A-131
12	Air flow sensor system	13A-133
13	Intake air temperature sensor system	13A-135
14	Throttle position sensor (2nd channel) system	13A-137
21	Engine coolant temperature sensor system	13A-138
22	Crank angle sensor system	13A-140
23	Camshaft position sensor system	13A-142
24	Vehicle speed sensor system	13A-144
25	Barometric pressure sensor system	13A-145
31	Detonation sensor system	13A-146
41	Injector system	13A-147
44	Ignition coil (incorporating power transistor) system (for No. 1 and No. 4 cylinders)	13A-148
52	Ignition coil (incorporating power transistor) system (for No. 2 and No. 5 cylinders)	13A-148
53	Ignition coil (incorporating power transistor) system (for No. 3 and No. 6 cylinders)	13A-148
54	Immobilizer system	13A-150
56	Abnormal fuel pressure system	13A-151
64	Alternator FR terminal system	13A-153
77	Accelerator pedal position sensor (2nd channel) system	13A-154
78	Accelerator pedal position sensor (1st channel) system	13A-156
79	Throttle position sensor (1st channel) system	13A-158
89	Abnormality in fuel pressure system	13A-160
91	Electronic-controlled throttle valve system	13A-161
92	Throttle valve position feedback system	13A-162
93	Throttle valve control servo system	13A-163
94	Communication line system with throttle valve controller	13A-164
96	Throttle valve controller system	13A-165

## NOTE


Code No. 56 may be also output when air is sucked in high-pressure fuel line due to no fuel supply.


**INSPECTION PROCEDURE CLASSIFIED BY DIAGNOSIS CODE**

<b>Code No.11 Oxygen sensor system</b>	<b>Probable cause</b>
<p>Range of Check</p> <ul style="list-style-type: none"><li>• Three minutes have been passed since the engine has been started.</li><li>• The engine coolant temperature is approx. 80°C or more.</li><li>• Intake air temperature is 20 - 30°C</li><li>• Engine speed is 1,200 r/min or more</li><li>• Driving on a level surface at constant speed.</li></ul> <p>Set Conditions</p> <ul style="list-style-type: none"><li>• The oxygen sensor output voltage is 4.5 V or more when the sensor output voltage is 0.2 V or less and a voltage of 5 V is applied to the oxygen sensor inside the engine-A/T-ECU.</li></ul>	<ul style="list-style-type: none"><li>• Malfunction of oxygen sensor</li><li>• Open or short circuit in the oxygen sensor circuit or loose connector contact</li><li>• Malfunction of engine-A/T-ECU</li></ul>





Code No.12 Air flow sensor system	Probable cause
Range of Check ● Engine speed: 500 r/min or more Set Conditions ● The sensor output frequency is 3.3 Hz or less for four seconds.	● Malfunction of air flow sensor ● Open or short circuit in air flow sensor circuit or loose connector contact ● Malfunction of engine-A/T-ECU







Code No.13 Intake air temperature sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Two seconds have passed since the ignition switch is turned ON or the engine starting process is completed.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 4.6 V or more for four seconds (equivalent to -45°C of intake air temperature)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 0.2 V or more for four seconds (equivalent to 125°C of intake air temperature)</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of intake air temperature sensor</li> <li>Open or short circuit in intake air temperature sensor or loose connector contact</li> <li>Malfunction of engine-A/T-ECU</li> </ul>







Code No.14 Throttle position sensor (2nd channel) system	Probable cause
<p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-A/T-ECU.</p> <p>Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● The throttle position sensor (1st channel) is normal.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The sensor output voltage is 0.2 V or less for four seconds.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>● The sensor output voltage is 4.85 V or more and the throttle position sensor (1st channel) output voltage is 1.2 V or more for four seconds.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>● The throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 - 6 V.</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of throttle position sensor (2nd channel)</li> <li>● Open or short circuit in the throttle position sensor (2nd channel) circuit or loose connector contact</li> <li>● Malfunction of throttle valve controller</li> <li>● Malfunction of engine-A/T-ECU</li> </ul>






Code No.21 Engine coolant temperature sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Engine: Two seconds after the engine has been started</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 4.6 V or more for four seconds (equivalent to -45°C of engine coolant temperature)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 0.1 V or less for four seconds (equivalent to 140°C of engine coolant temperature)</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of engine coolant temperature sensor</li> <li>Open or short circuit in the engine coolant temperature sensor circuit or loose connector contact</li> <li>Malfunction of engine-A/T-ECU</li> </ul>
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Engine: After starting</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The engine coolant temperature has reduced from over 40°C to less than 40°C, and that condition has lasted for five minutes or more.</li> </ul>	







Code No.22 Crank angle sensor system	Probable cause
Range of Check • Engine is cranking Set Conditions • Sensor output voltage does not change for 4 seconds (no pulse signal input).	• Malfunction of the crank angle sensor. • Open or short circuit in the crank angle sensor circuit or loose connector contact. • Malfunction of engine-A/T-ECU




<b>Code No.23 Camshaft position sensor system</b>	<b>Probable cause</b>
Range of Check ● After the engine was started Set Conditions ● The sensor output voltage does not change for 4 seconds (no pulse signal input).	● Malfunction of the camshaft position sensor ● Open or short circuit in the camshaft position sensor circuit or loose connector contact. ● Malfunction of engine-A/T-ECU




Code No.24 Vehicle speed sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Engine: Two seconds after the engine was started</li> <li>● Idle switch: OFF</li> <li>● Engine speed: 2,500 r/min or more</li> <li>● During high engine load</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The sensor output voltage does not change for 4 seconds (no pulse signal input).</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of the vehicle speed sensor</li> <li>● Open or short circuit in the vehicle speed sensor circuit or loose connector contact</li> <li>● Malfunction of engine-A/T-ECU</li> </ul>




Code No.25 Barometric pressure sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Two seconds have passed since the ignition switch is turned ON or the engine starting process is completed.</li> <li>Battery voltage: 8 V or more</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 4.5 V or more for four seconds (equivalent to 114 kPa of barometric pressure)</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 0.2 V or less (equivalent to 53 kPa of barometric pressure)</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of barometric pressure sensor</li> <li>Open or short circuit in barometric pressure sensor circuit or loose connector contact</li> <li>Malfunction of engine-A/T-ECU</li> </ul>







Code No.31 Detonation sensor system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>• Engine: Two seconds after the engine has been started</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>• Changes in sensor output voltage (detonation sensor peak voltage per 1/3 crankshaft rotation) in 200 consecutive cycles are 0.08 V or less.</li> </ul>	<ul style="list-style-type: none"> <li>• Malfunction of the detonation sensor</li> <li>• Open or short circuit in the detonation sensor circuit or loose connector contact</li> <li>• Malfunction of engine-A/T-ECU</li> </ul>



Code No.41 Injector system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>The engine speed is 4,000 r/min or less.</li> <li>The battery voltage is 10 V or more.</li> <li>The fuel cut operation or the injector operation (by carrying out the Actuator Test) is not in progress.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The injector driver is not transmitting a injector open circuit check signal for four seconds.</li> </ul>	<ul style="list-style-type: none"> <li>Malfuction of injector</li> <li>Open or short circuit in the injector circuit or loose connector contact</li> <li>Malfuction of engine-A/T-ECU</li> </ul>






Code No.44, 52, 53 Ignition coil (incorporating power transistor) system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Engine speed is approx. 50 - 4,000 r/min.</li> <li>● Engine is not cranking.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● The ignition failure sensor does not send a signal about a certain cylinder for four seconds. However, except that the ignition failure sensor does not send a signal about all of cylinders.</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of the ignition coil</li> <li>● Malfunction of the ignition failure sensor</li> <li>● Malfunction of spark plug</li> <li>● Open or short circuit in the primary ignition circuit or loose connector contact</li> <li>● Malfunction of engine-A/T-ECU</li> </ul>




Code No.54 Immobilizer system	Probable cause
Range of Check ● Ignition switch: ON Set Conditions ● Improper communication between the engine-A/T-ECU and the immobilizer-ECU	● Open or short circuit, or loose connector contact ● Malfunction of the immobilizer-ECU ● Malfunction of the engine-A/T-ECU


## NOTE

- (1) If the registered ignition keys are close each other when starting the engine, radio interference may cause this code to be displayed.
- (2) This code may be displayed when registering the key encrypted code.




Code No.56 Abnormal fuel pressure	Probable cause
Range of Check ● Ignition switch: ON Set Conditions ● The sensor output voltage is 4.8V or more, or 0.2 V or less for four seconds.	● Malfunction of fuel pressure sensor ● Open or short circuit in the fuel pressure sensor circuit or loose connector contact ● Malfunction of engine-A/T-ECU
Range of Check ● The following conditions are detected temporarily after the engine has been started. (1) Engine speed: 1,000 r/min or more (2) Fuel pressure: 2 MPa or more ● Engine running Set Conditions ● The fuel pressure is 6.9 MPa or more, or 2 MPa or less for four seconds.	● Malfunction of high-pressure fuel pump ● Clogging of high-pressure fuel lines
This diagnosis code will also be output when air is trapped into the high-pressure fuel lines (such as poor fuel level). In that case, the air can be evacuated by operating the engine for at least 15 seconds at 2,000 r/min. After the repair, use the MUT-II to erase the diagnosis code.	● Air trapped due to poor fuel level







Code No.64 Alternator FR terminal system	Probable cause
Range of Check ● Engine speed: 50 r/min or more Set Conditions ● Input voltage from the alternator FR terminal is system voltage for 20 seconds.	● Open circuit in alternator FR terminal circuit ● Malfunction of engine-A/T-ECU





Code No.77 Accelerator pedal position sensor (2nd channel) system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Accelerator pedal position sensor (1st channel) is normal.</li> <li>Communication between the engine-A/T-ECU and the throttle valve controller is normal.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>Output voltage of the accelerator pedal position sensor (2nd channel) is 0.2 V or less for one second</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>Output voltage of the accelerator pedal position sensor (1st channel) is 2.5 V or less, and output voltage of the accelerator pedal position sensor (2nd channel) is 4.5 V or more for one second.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>Difference between the accelerator pedal position sensor (1st and 2nd channels) output voltages exceeds 1.0 V (i.e. when the throttle valve opening angle changes slightly).</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of accelerator pedal position sensor (2nd channel)</li> <li>Open or short circuit in accelerator pedal position sensor (2nd channel) circuit or loose connector contact</li> <li>Malfunction of the throttle valve controller</li> <li>Malfunction of engine-A/T-ECU</li> </ul>







Code No.78 Accelerator pedal position sensor (1st channel) system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Accelerator pedal position sensor (2nd channel) is normal.</li> <li>Communication between the engine-A/T-ECU and the throttle valve controller is normal.</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The output voltage of accelerator pedal position sensor (1st channel) is 0.2 V or less for one second.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The output voltage of accelerator pedal position sensor (2nd channel) is 2.5 V or less, and that of accelerator pedal position sensor (1st channel) is 4.5 V or more for one second</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The difference between accelerator pedal position sensor (1st channel) and accelerator pedal position sensor (2nd channel) output voltages is 1.0 V or more (i.e. the throttle opening angle changes slightly).</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The output voltage of accelerator pedal position sensor (1st channel) is 1.1 V or more for one second when the accelerator pedal position switch is turned on.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of accelerator pedal position sensor (1st channel)</li> <li>Open or short circuit in the accelerator pedal position sensor (1st channel) circuit or loose connector contact</li> <li>Accelerator pedal position switch seized ON</li> <li>Malfunction of throttle valve controller</li> <li>Malfunction of engine-A/T-ECU</li> </ul>







Code No.79 Throttle position sensor (1st channel) system	Probable cause
<p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-A/T-ECU.                      Range of Check</p> <ul style="list-style-type: none"> <li>Ignition switch: ON</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 0.2 V or less.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The sensor output voltage is 4.85 V or more and the throttle position sensor (2nd channel) output voltage is 2.5V or more.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The throttle position sensor (1st channel) and throttle position sensor (2nd channel) combination output voltage is outside 4 - 6V.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The opening angle of throttle position sensor (1st channel) is different from its target by 1V or more.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>The throttle position sensor (1st channel) output changes within 25 mV when the throttle valve control servo moves one step.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of throttle position sensor</li> <li>Open or short circuit in the throttle position sensor (1st channel) circuit or loose connector contact</li> <li>Malfunction of throttle valve controller</li> <li>Malfunction of engine-A/T-ECU</li> </ul>






Code No.89 Abnormal fuel system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Engine: Being learning the air-fuel ratio</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>Ten seconds or more have been passed while the fuel injection amount compensation value is too low.</li> </ul> <p>or</p> <ul style="list-style-type: none"> <li>Ten seconds or more have been passed while the fuel injection amount compensation value is too high.</li> </ul>	<ul style="list-style-type: none"> <li>Malfunction of fuel supply system</li> <li>Malfunction of oxygen sensor</li> <li>Malfunction of intake air temperature sensor</li> <li>Malfunction of barometric pressure sensor</li> <li>Malfunction of air flow sensor</li> <li>Malfunction of engine-A/T-ECU</li> </ul>







Code No.91 Electronic-controlled throttle valve system	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>Error in communication between the engine-A/T-ECU and the throttle valve controller</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>Output voltage of throttle position sensor (2nd channel) fluctuates significantly (approx. 1 V or more) from an expected value, based on that of the accelerator pedal position sensor (2nd channel).</li> </ul> <p>Range of Check</p> <ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>Error in communication between the throttle valve controller and the engine-A/T-ECU</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>The output voltage of the throttle position sensor (2nd channel) is significantly different (approx. 1 V) from the the throttle valve opening angle (voltage), which the engine-A/T-ECU request the throttle valve controller.</li> </ul>	<ul style="list-style-type: none"> <li>Short in communication line</li> <li>Malfunction of the engine-A/T-ECU</li> <li>Malfunction of the throttle valve controller</li> </ul>




Code No.92 Throttle valve position feedback system	Probable cause
<p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-A/T-ECU.</p> <p>Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Battery voltage: 10 V or more</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● Failure in the position feedback</li> </ul> <p>[The engine-A/T-ECU detects that the current in the motor is excessive and the opening angle difference between the target value of throttle position sensor (1st channel) and the actual value of throttle position sensor (1st channel) is 2.0V or more]</p>	<ul style="list-style-type: none"> <li>● Malfunction of throttle position sensor (1st channel)</li> <li>● Open or short circuit in the throttle position sensor (1st channel) circuit or loose connector contact</li> <li>● Malfunction of the throttle valve controller</li> </ul>



Code No.93 Throttle valve control servo system	Probable cause
<p>The throttle valve controller judges a malfunction, and then transmit the result to the engine-A/T-ECU.</p> <p>Range of Check</p> <ul style="list-style-type: none"> <li>● Throttle valve control servo relay: ON</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● Short circuit of the throttle valve control servo drive circuit to earth</li> <li>● Power is supplied to the throttle valve control servo circuit from other sources.</li> <li>● Open circuit in the throttle valve control servo power supply circuit</li> </ul>	<ul style="list-style-type: none"> <li>● Malfunction of the throttle valve control servo</li> <li>● Open circuit in the throttle valve control servo power supply circuit</li> <li>● Open or short circuit in the throttle valve control servo circuit or loose connector contact</li> <li>● Malfunction of throttle valve controller</li> </ul>



Code No.94 Communication line system with the throttle valve controller	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Battery voltage: 8 V or more.</li> <li>● Engine: not cranking</li> </ul> <p>Set Conditions</p> <ul style="list-style-type: none"> <li>● System detects an error in communication line between the engine-A/T-ECU and the throttle valve controller, and between the throttle valve controller and the engine-A/T-ECU.</li> </ul>	<ul style="list-style-type: none"> <li>● Short in communication line</li> <li>● Malfunction of engine-A/T-ECU</li> <li>● Malfunction of throttle valve controller</li> </ul>





<b>Code No.96 Throttle valve controller system</b>	<b>Probable cause</b>
Set Conditions • Errors in reading or writing to the throttle valve controller ROM.	• Malfunction of the throttle valve controller

Replace the throttle valve controller.

## INSPECTION CHART FOR TROUBLE SYMPTOMS

Trouble symptom		Inspection procedure No.	Reference page
Communication with MUT-II is impossible.	Communication with all systems is not possible.	1	13A-169
	Communication with engine-A/T-ECU only is not possible.	2	13A-169
Engine warning lamp and related parts	The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position.	3	13A-170
	The engine warning lamp remains illuminating and never goes out.	4	13A-170
Starting	No initial combustion (starting impossible)	5	13A-171
	Initial combustion but no complete combustion (starting impossible)	6	13A-172
	Long time to start (improper starting)		
Idling stability (Improper idling)	Unstable idling (Rough idling, hunting)	7	13A-174
	Idling speed is high. (Improper idling speed)	8	13A-176
	Idling speed is low. (Improper idling speed)		
Idling stability (Engine stalls)	When the engine is cold, it stalls at idling. (Die out)	9	13A-177
	When the engine is hot, it stalls at idling. (Die out)	10	13A-178
	The engine stalls when starting the car. (Pass out)	11	13A-180
	The engine stalls when decelerating.	12	13A-181
Driving	Hesitation, sag or stumble	13	13A-182
	Poor acceleration		
	Surge		
	The feeling of impact or vibration when accelerating	14	13A-183
	The feeling of impact or vibration when decelerating	15	13A-184
	Knocking	16	13A-184
Dieseling		17	13A-184
Too high CO and HC concentration when idling		18	13A-185
Low alternator output voltage (approx. 12.3 V)		19	13A-186
Engine idle speed is incorrect while the A/C is on (A/C switch 2 signal).		20	13A-187
Fans (radiator fan, A/C condenser fan) are inoperative		21	13A-187
GDI ECO indicator lamp system	GDI ECO indicator lamp does not illuminate.	22	13A-188
	GDI ECO indicator lamp remains illuminated and does not go off.	23	13A-188

**PROBLEM SYMPTOMS TABLE (FOR YOUR INFORMATION)**

Items		Symptom
Starting	Won't start	The starter is used to crank the engine, but there is no combustion within the cylinders, and the engine won't start.
	Fires up and dies	There is combustion within the cylinders, but then the engine soon stalls.
	Hard starting	Engine starts after cranking a while.
Idling stability	Hunting	Engine speed doesn't remain constant; changes at idle.
	Rough idle	Usually, a judgement can be based upon the movement of the tachometer pointer, and the vibration transmitted to the steering wheel, shift lever, body, etc. This is called rough idle.
	Incorrect idle speed	The engine doesn't idle at the usual correct speed.
	Engine stall (Die out)	The engine stalls when the foot is taken from the accelerator pedal, regardless of whether the vehicles is moving or not.
	Engine stall (Pass out)	The engine stalls when the accelerator pedal is depressed or while it is being used.
Driving	Hesitation, Sag	<p>"Hesitation" is the delay in response of the vehicle speed (engine speed) that occurs when the accelerator is depressed in order to accelerate from the speed at which the vehicle is now traveling, or a temporary drop in vehicle speed (engine speed) during such acceleration. Serious hesitation is called "sag".</p> 
	Poor acceleration	Poor acceleration is inability to obtain an acceleration corresponding to the degree of throttle opening, even though acceleration is smooth, or the inability to reach maximum speed.
	Stumble	<p>Engine speed increase is delayed when the accelerator pedal is initially depressed for acceleration.</p> 

1FU0223


1FU0224

Items		Symptom
Driving	Shock	The feeling of a comparatively large impact or vibration when the engine is accelerated or decelerated.
	Surge	This is repeated surging ahead during constant speed travel or during variable speed travel.
	Knocking	A sharp sound like a hammer striking the cylinder walls during driving and which adversely affects driving.
Stopping	Run on ("Dieseling")	The condition in which the engine continues to run after the ignition switch is turned to OFF. Also called "Dieseling".

## INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS


## Inspection procedure 1

Communication with all systems is not possible.	Probable cause
The cause is probably a defect in the power supply system (including earth) for the diagnosis line.	<ul style="list-style-type: none"> <li>• Malfunction of the diagnosis connector</li> <li>• Open circuit or short-circuited between engine-A/T-ECU and diagnosis connector circuit</li> <li>• Malfunction of the MUT-II</li> </ul>



## Inspection procedure 2

Communication with engine-A/T-ECU is not possible.	Probable cause
The cause is probably a defect in the engine-A/T-ECU power supply circuit (including earth).	<ul style="list-style-type: none"> <li>• Open circuit or short-circuited harness wire in the engine-A/T-ECU power supply circuit.</li> <li>• Open circuit between engine-A/T-ECU and diagnosis connector</li> <li>• Malfunction of the engine-A/T-ECU</li> </ul>




## NOTE

On vehicles with multi communication system (MMCS) or RV meter, if a malfunction cannot be resolved after the procedure above, check the multi center display unit or RV meter and replace if necessary. (Refer to GROUP 54 - Clock, multi center display and RV meter.)


**Inspection procedure 3**

The engine warning lamp does not illuminate right after the ignition switch is turned to the ON position.	Probable cause
<p>Because there is a burnt-out bulb, the engine-A/T-ECU causes the engine warning lamp to illuminate for five seconds immediately after the ignition switch is turned to ON.</p> <p>If the engine warning lamp does not illuminate immediately after the ignition switch is turned to ON, one of the malfunction listed at right has probably occurred.</p>	<ul style="list-style-type: none"> <li>• Burnt-out bulb</li> <li>• Open circuit or short-circuit between the engine warning lamp and engine-A/T-ECU.</li> <li>• Malfunction of the engine-A/T-ECU</li> </ul>




**Inspection procedure 4**


The engine warning lamp remains illuminating and never goes out.	Probable cause
<p>In cases such as the above, the cause is probably that the engine-A/T-ECU is detecting a problem in a sensor or actuator, or that one of the malfunctions listed at right has occurred.</p>	<ul style="list-style-type: none"> <li>• Short-circuit between the engine warning lamp and engine-A/T-ECU</li> <li>• Malfunction of the engine-A/T-ECU</li> </ul>



**Inspection procedure 5**


No initial combustion (starting impossible)	Probable cause
In cases such as the above, the cause is probably that a spark plug is defective, or that the supply of fuel to the combustion chamber is defective. In addition, foreign materials (water, kerosene, etc.) may be mixed with the fuel.	<ul style="list-style-type: none"> <li>● Malfunction of the fuel supply system</li> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>






**Inspection procedure 6**


Initial combustion but no complete combustion (starting impossible), long time to start (hard starting)	Probable cause
In such cases as the above, the cause is probably that the spark plugs are generating sparks by the spark are weak, or the initial mixture is not appropriate.	<ul style="list-style-type: none"> <li>• Malfunction of fuel supply system</li> <li>• Malfunction of fuel pressure control solenoid valve</li> <li>• Malfunction of the ignition system</li> <li>• Malfunction of the electronic-controlled throttle valve system</li> <li>• Malfunction of the engine-A/T-ECU</li> </ul>






Inspection procedure 7


Unstable idling (Rough idling, hunting)	Probable cause
The cause is probably a malfunction of the ignition system, air/fuel ratio control system, electronic controlled throttle valve system, compression pressure, etc. As many causes can be suspected, diagnose from easier items.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the air/fuel ratio control system</li> <li>● Malfunction of the electronic-controlled throttle valve system</li> <li>● Poor compression</li> <li>● Air sucking into the air intake system</li> </ul>






## Inspection procedure 8

Idling speed is high or low (Improper idling speed)	Probable cause
The cause is probably that the intake air amount during idling is too great or too small.	<ul style="list-style-type: none"> <li>• Malfunction of the electronic-controlled throttle valve system</li> <li>• Malfunction of the throttle body</li> </ul>




**Inspection procedure 9**


When the engine is cold, it stalls at idling. (Die out)	Probable cause
In such cases as the above, the cause is probably that the air/fuel mixture is inappropriate when the engine is cold, or that the intake air volume is insufficient.	<ul style="list-style-type: none"> <li>● Malfunction of the electronic-controlled throttle valve system</li> <li>● Malfunction of the throttle body</li> </ul>



Inspection procedure 10


When the engine becomes hot, it stalls at idling. (Die out)	Probable cause
<p>In such cases as the above, the cause is probably that ignition system, air/fuel mixture, electronic-controlled throttle valve system, compression pressure is defective. In addition, if the engine suddenly stalls, the cause may also be a defective connector contact.</p>	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the air/fuel ratio control system</li> <li>● Malfunction of the electronic-controlled throttle valve system</li> <li>● Malfunction of the throttle body</li> <li>● Improper connector contact</li> <li>● Drawing air into intake system</li> </ul>






Inspection procedure 11

The engine stalls when starting the car. (Pass out)	Probable cause
In cases such as the above, the cause is probably misfiring due to a weak spark, or an inappropriate air/fuel mixture when the accelerator pedal is depressed.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the EGR valve</li> <li>● Air stuck in the air intake system</li> </ul>




Inspection procedure 12


The engine stalls when decelerating.	Probable cause
The cause is probably an improper air/fuel ratio due to a faulty EGR system, or poor intake air volume due to a faulty electronic-controlled throttle valve system.	<ul style="list-style-type: none"> <li>● Malfunction of the electronic-controlled throttle valve system</li> <li>● Malfunction of the EGR valve</li> </ul>



Inspection procedure 13


Hesitation, sag, stumble, poor acceleration or surge	Probable cause
The cause is probably a malfunction of the ignition system, air/fuel ratio control system, electronic controlled throttle valve system, compression pressure, etc.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> <li>● Malfunction of the air/fuel ratio control system</li> <li>● Malfunction of the electronic-controlled throttle valve system</li> <li>● Improper compression pressure</li> <li>● Air stuck in the air intake system</li> </ul>






**Inspection procedure 14**

The feeling of impact or vibration when accelerating	Probable cause
In cases such as the above, the cause is probably that there is an ignition leak accompanying the increase in the spark plug demand voltage during acceleration.	<ul style="list-style-type: none"> <li>● Malfunction of the ignition system</li> </ul>




**Inspection procedure 15**

The feeling of impact or vibration when decelerating	Probable cause
The cause is probably insufficient intake air due to a faulty electronic-controlled throttle valve system.	<ul style="list-style-type: none"> <li>Malfunction of the electronic-controlled throttle valve system</li> </ul>



**Inspection procedure 16**

Knocking	Probable cause
In case as the above, the cause is probably that the heat value of the spark plug is inappropriate.	<ul style="list-style-type: none"> <li>Malfunction of the detonation sensor</li> <li>Improper heat range of the spark plugs.</li> </ul>




**Inspection procedure 17**


Run-on (Dieseling)	Probable cause
Fuel leakage from injectors is suspected.	<ul style="list-style-type: none"> <li>Malfunction of the injector</li> </ul>

Replace the injector.

Inspection procedure 18


Too high CO and HC concentration when idling	Probable cause
Abnormal air-fuel ratio is suspected.	<ul style="list-style-type: none"> <li>• Malfunction of the air/fuel ratio control system</li> <li>• Deteriorated catalyst</li> </ul>






**Inspection procedure 19**

Low alternator output voltage (approx. 12.3 V)	Probable cause
The cause is probably a malfunction of the alternator or one of the problems listed at right.	<ul style="list-style-type: none"> <li>• Malfunction of the charging system</li> <li>• Open circuit between the alternator G terminal and the engine-A/T-ECU</li> <li>• Malfunction of the engine-A/T-ECU</li> </ul>




**Inspection procedure 20**

Idling speed is improper when A/C is operating (A/C switch 2 signal)	Probable cause
The A/C-ECU judges if load caused by air conditioner is high or low, and converts it to A/C switch 2 signal to send the engine-A/T-ECU it. Based on this signal, the engine-A/T-ECU operates the throttle control servo to control the idle-up speed.	<ul style="list-style-type: none"> <li>● Malfunction of the A/C control system</li> <li>● Open or short circuit, or loose connector contact</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




**Inspection procedure 21**

A/C condenser fan is inoperative	Probable cause
The fan motor relay is controlled by turning on and off the power transistor in the engine-A/T-ECU.	<ul style="list-style-type: none"> <li>● Malfunction of the A/C condenser fan relay.</li> <li>● Malfunction of the A/C condenser fan motor.</li> <li>● Open or short circuit, or loose connector contact</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




**Inspection procedure 22**

GDI ECO indicator lamp does not illuminate.	Probable cause
If the GDI ECO indicator lamp does not illuminate after turning switch, the causes listed in the right column are suspected.	<ul style="list-style-type: none"> <li>● Burned-out GDI ECO indicator lamp bulb</li> <li>● Open circuit or short-circuited harness wire in the GDI ECO indicator lamp circuit</li> <li>● Malfunction of the engine-A/T-ECU</li> <li>● Malfunction of the GDI ECO indicator lamp ECU</li> </ul>




**Inspection procedure 23**

GDI ECO indicator lamp remains illuminated and does not go off.	Probable cause
If the GDI ECO indicator lamp does not go off during high load operation, the causes listed in the right column are suspected.	<ul style="list-style-type: none"> <li>● Short circuit between the GDI ECO indicator lamp and engine-A/T-ECU</li> <li>● Malfunction of the engine-A/T-ECU</li> <li>● Malfunction of the GDI ECO indicator lamp ECU</li> </ul>



Inspection procedure 24


Engine-A/T-ECU power supply and earth circuit system	Probable cause
The cause is probably the malfunction of the engine-A/T-ECU, or the malfunctions listed at right.	<ul style="list-style-type: none"> <li>• Open circuit or short-circuited harness wire in the engine-A/T-ECU power supply circuit.</li> <li>• Open circuit or short-circuited harness wire to earth in the engine-A/T-ECU.</li> <li>• Malfunction of the engine-A/T-ECU</li> </ul>






Inspection procedure 27

Ignition switch-ST and inhibitor switch system	Probable cause
<p>The ignition switch-ST inputs a HIGH signal to the engine-A/T-ECU while the engine is cranking. The engine-A/T-ECU controls fuel injection, etc. during starting based on this input.</p> <p>The inhibitor switch inputs the position of the selector lever to the engine-A/T-ECU. The engine-A/T-ECU uses this signal to carry out idle speed control.</p>	<ul style="list-style-type: none"> <li>● Malfunction of the ignition switch</li> <li>● Malfunction of the inhibitor switch</li> <li>● Open circuit or short-circuited harness wire between the ignition switch and the inhibitor switch, or improper connector contact.</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




Inspection procedure 28

Accelerator pedal position switch system	Probable cause
<p>The accelerator pedal position switch detects that the accelerator pedal is fully closed, and sends a signal to the engine-A/T-ECU. The engine-A/T-ECU uses this signal to carry out idle speed control.</p>	<ul style="list-style-type: none"> <li>• Maladjustment of the accelerator pedal position switch and the accelerator pedal position sensor.</li> <li>• Open circuit or short-circuited harness wire in the accelerator pedal position switch system, or poor connector contact</li> <li>• Malfunction of the engine-A/T-ECU</li> </ul>




Inspection procedure 29

Fuel pump (low pressure) system	Probable cause
The engine-A/T-ECU turns on the fuel pump relay while the engine is cranking or running, and supplies power source to the fuel pump (low pressure).	<ul style="list-style-type: none"> <li>● Malfunction of the fuel pump relay</li> <li>● Malfunction of the fuel pump (low pressure)</li> <li>● Improper connector contact, open circuit or short-circuited harness wire</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




Inspection procedure 30

Power steering fluid pressure switch system	Probable cause
The presence or absence of power steering load is input to the engine-A/T-ECU. Based on this signal, the engine-A/T-ECU controls the throttle control servo so that idle speed increases when the power steering is in operation.	<ul style="list-style-type: none"> <li>● Malfunction of the power steering fluid pressure switch.</li> <li>● Improper connector contact, open circuit or short-circuited harness wire</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




Inspection procedure 31

A/C switch and A/C relay system	Probable cause
When an A/C ON signal is input to the engine-A/T-ECU, the engine-A/T-ECU controls the throttle control servo so that idle speed increases, and also operates the A/C compressor magnetic clutch.	<ul style="list-style-type: none"> <li>● Malfunction of the A/C control system</li> <li>● Malfunction of the A/C switch</li> <li>● Improper connector contact, open circuit or short-circuited harness wire</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




**Inspection procedure 32**

Stop lamp switch system	Probable cause
The engine-A/T-ECU determines whether the brake pedal is depressed or not. The engine-A/T-ECU selects a fuel injection mode by determining the brake operation according to this information.	<ul style="list-style-type: none"> <li>● Malfunction of the stop lamp switch</li> <li>● Improper connector contact, open circuit or short-circuited harness wire</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




**Inspection procedure 33**

Small lamp switch system	Probable cause
The engine-A/T-ECU determines whether the small lamp switch is on or off. According to that information, the engine-A/T-ECU controls alternator output current when the vehicle is started.	<ul style="list-style-type: none"> <li>● Improper connector contact, open circuit or short-circuited harness wire in the taillamp relay circuit.</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




Inspection procedure 34

Injector driver	Probable cause
The engine-A/T-ECU drives the injector by the drive signal.	<ul style="list-style-type: none"> <li>● Malfunction of the injector driver</li> <li>● Improper connector contact, open circuit or short-circuited harness wire</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>




Inspection procedure 35

EGR valve (stepper motor) system	Probable cause
The engine-A/T-ECU controls the EGR valve (stepper motor) in order to control the amount of exhaust gas mixed in the intake air.	<ul style="list-style-type: none"> <li>● Malfunction of the EGR valve</li> <li>● Open circuit or short-circuited harness wire in the EGR valve circuit</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>



**Inspection procedure 36**

Purge control solenoid valve system	Probable cause
The engine-A/T-ECU controls the purge control solenoid valve in order to control the purge air coming from the canister.	<ul style="list-style-type: none"> <li>● Malfunction of the purge control solenoid valve</li> <li>● Open circuit or short-circuited harness wire in the purge control solenoid valve circuit</li> <li>● Malfunction of the engine-A/T-ECU</li> </ul>



## DATA LIST REFERENCE TABLE

## Caution

When shifting the select lever to D range, the brakes should be applied so that the vehicle does not move forward.

## NOTE

- \*1: Injector running time indicates the time where the power voltage is 11 V and the cranking speed is 250 r/min or less. As the engine speed increases and the time passes by, the injector running time decreases.
- \*2: There may be occasions of taking the injector running time approximately 10% longer than usual when a vehicle has not been driven for a long time (mileage is no more than 500 km.)
- \*3: It is normal that the idle switch turns from ON to OFF when accelerator pedal position sensor (1st channel) voltage increases by 200 - 600 mV from the idling position. Moreover, adjust the idle switch and accelerator pedal position sensor if the idle switch keeps turning after the accelerator pedal is depressed.

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
11	Oxygen sensor	Engine: After having warmed up (Air/fuel mixture is made leaner when decelerating, and is made richer when racing.)	When at 4,000 r/min, engine is decelerated	200 mV or less	Code No. 11	13A-131
			Race the engine suddenly.	600 - 1,000 mV		
		Engine: After having warmed up (The oxygen sensor signal is used to check the air/fuel mixture ratio, and control condition by the engine-A/T-ECU.)	Idling (after six minutes)	400 mV or less 600 - 1,000 mV (changes)		
			2,500 r/min			
12	Air flow sensor	<ul style="list-style-type: none"> <li>• Engine coolant temperature: 80 - 95°C</li> <li>• Lamps and all accessories: OFF</li> <li>• Transmission: P range</li> </ul>	Idling	22 - 48 Hz	Code No. 12	13A-133
			2,500 r/min	60 - 100 Hz		
			Racing	Frequency increases in response to racing		
13	Intake air temperature sensor	Ignition switch: ON or with engine running	When intake air temperature is -20°C	-20°C	Code No. 13	13A-135
			When intake air temperature is 0°C	0°C		
			When intake air is 20°C	20°C		
			When intake air is 40°C	40°C		

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
14	Throttle position sensor (2nd channel)	<ul style="list-style-type: none"> <li>Engine: After having warmed up</li> <li>Ignition switch: ON (Engine: Stopped)</li> </ul>	Release the accelerator pedal.	4,000 mV or more	Code No. 14	13A-137
			Depress the accelerator pedal gradually.	Voltage decreases in response to the pedal depression.		
			Depress the accelerator pedal fully.	400 - 600 mV		
16	System voltage	Ignition switch: ON	System voltage	Procedure No. 25	13A-190	
18	Cranking signal (ignition switch: ST)	Ignition switch: ON	Engine: Stopped	OFF	Procedure No.27	13A-191
			Engine: Cranking	ON		
21	Engine coolant temperature sensor	Ignition switch: ON or with engine running	When engine coolant temperature is -20°C	-20°C	Code No. 21	13A-138
			When engine coolant temperature is 0°C	0°C		
			When engine coolant temperature is 20°C	20°C		
			When engine coolant temperature is 40°C	40°C		
22	Crank angle sensor	<ul style="list-style-type: none"> <li>Engine: Cranking</li> <li>Tachometer: Connected</li> </ul>	Compare the tachometer with the MUT-II reading.	Identical	Code No. 22	13A-140
			<ul style="list-style-type: none"> <li>Engine: Idling</li> <li>Idle position switch: ON</li> <li>Within six minutes after engine starting (Only when engine coolant temperature is 80°C)</li> </ul>	When engine coolant temperature is -20°C		
		When engine coolant temperature is 0°C		1,100 - 1,300 r/min		
		When engine coolant temperature is 20°C		1,000 - 1,200 r/min		
		When engine coolant temperature is 40°C		900 - 1,100 r/min		
		When engine coolant temperature is 80°C	550 - 650 r/min			

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
25	Barometric pressure sensor	Ignition switch: ON	At altitude of 0 m	101 kPa	Code No. 25	13A-145
			At altitude of 600 m	95 kPa		
			At altitude of 1,200 m	88 kPa		
			At altitude of 1,800 m	81 kPa		
26	Accelerator pedal position switch	Ignition switch: ON (Depress and release the accelerator pedal several times)	Release the accelerator pedal.	ON	Procedure No.28	13A-192
			Depress the accelerator pedal slightly.	OFF		
27	Power steering fluid pressure switch	Engine: Idling	When steering wheel is turned	ON	Procedure No.30	13A-194
28	A/C switch	Engine: Idling (The A/C compressor is running when the A/C switch is on.)	A/C switch: OFF	OFF	Procedure No.31	13A-194
			A/C switch: ON	ON		
31	Small lamp switch	Engine: Idling	Lighting switch: OFF	OFF	Procedure No.33	13A-195
			Lighting switch: ON	ON		
34	Air flow sensor reset signal	Engine: After having warmed up	Idling	ON	Code No. 12	13A-133
			3,000 r/min	OFF		
37	Volumetric efficiency	<ul style="list-style-type: none"> <li>Engine coolant temperature: 85 - 95°C</li> <li>Lamps and all accessories: OFF</li> <li>Transmission: P range</li> </ul>	Idling	20 - 40%	-	-
			2,500 r/min	10 - 30%		
			Engine is suddenly raced	Volumetric efficiency increases in response to racing		
38	Crank angle sensor	<ul style="list-style-type: none"> <li>Engine: Cranking (reading is possible at 2,000 r/min or less)</li> <li>Tachometer: Connected</li> </ul>	Engine speeds displayed on the MUT-II and tachometer are identical.	-	-	

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
41	Injector drive time*1	<ul style="list-style-type: none"> <li>Engine: Cranking</li> </ul>	When engine coolant temperature is 0°C	120 - 160 ms	Code No. 41	13A-147
			When engine coolant temperature is 20°C	70 - 90 ms		
			When engine coolant temperature is 80°C	20 - 35 ms		
	Injector drive time*2	<ul style="list-style-type: none"> <li>Engine coolant temperature: 85 - 95°C</li> <li>Lamps and all accessories: OFF</li> <li>Transmission: P range</li> <li>Within six minutes after engine starting</li> </ul>	Idling	0.3 - 0.8 ms		
			2,500 r/min	0.4 - 1.0 ms		
			When engine is suddenly raced	Increases		
44	Ignition advance value	<ul style="list-style-type: none"> <li>Engine: After having warmed up</li> <li>Timing lamp is set. (The timing lamp is set in order to check actual ignition timing.)</li> <li>Within six minutes after engine starting</li> </ul>	Idling	12 - 28° BTDC	Code No. 44	13A-148
			2,500 r/min	15 - 35° BTDC		
49	A/C relay	Engine: After having warmed up, idling	A/C switch: OFF	OFF (compressor clutch is not operating)	Procedure No.31	13A-194
			A/C switch: ON	ON (compressor clutch is operating)		
67	Stop lamp switch	Ignition switch: ON	Brake pedal: Depressed	OFF	Procedure No.32	13A-195
			Brake pedal: Released	ON		
68	EGR valve	<ul style="list-style-type: none"> <li>Engine coolant temperature: 85 - 95°C</li> <li>Lamps and all accessories: OFF</li> <li>Transmission: P range</li> </ul>	Idling	2 - 20 STEP	Procedure No.35	13A-196
			2,500 r/min	0 - 10 STEP		
74	Fuel pressure sensor	<ul style="list-style-type: none"> <li>Engine coolant temperature: 85 - 95°C</li> <li>Lamps and all accessories: OFF</li> <li>Transmission: P range</li> </ul>	Engine: Cranking	2 MPa or more	Code No. 56	13A-151
			Engine: Idling	4.0 - 6.9 MPa		

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
77	Accelerator pedal position sensor (2nd channel)	Ignition switch: ON	Release the accelerator pedal.	985 - 1,085 mV	Code No. 77	13A-154
			Depress the accelerator pedal gradually.	Increases in response to the pedal depression stroke.		
			Depress the accelerator pedal fully.	4,000 mV or more		
78	Accelerator pedal position sensor (1st channel)	Ignition switch: ON	Release the accelerator pedal.	985 - 1085 mV	Code No. 78	13A-156
			Depress the accelerator pedal gradually.	Increases in response to the pedal depression stroke.		
			Depress the accelerator pedal fully.	4,000 mV or more		
79	Throttle position sensor (1st channel)	<ul style="list-style-type: none"> <li>Engine: After having warmed up</li> <li>Ignition switch: ON (Engine stopped)</li> </ul>	Release the accelerator pedal.	400 - 800 mV	Code No. 79	13A-158
			Depress the accelerator pedal gradually.	Increases in response to the pedal depression stroke.		
			Depress the accelerator pedal fully.	4,200 - 4,800 mV		
		Engine: Idling after warming-up	No load	450 - 1,000 mV		
		A/C switch: OFF to ON	Increases by 100 - 600 mV			
		Transmission: P to D range	Increases by 0 - 200 mV.			
99	Combustion mode	Engine: After having warmed up	Idling (several minutes after starting)	Compression lean	-	-
			2,500 r/min	Stoichiometric feedback		
			Race the engine suddenly while the engine is idling.	Open loop		

## ACTUATOR TEST REFERENCE TABLE

Item No.	Inspection item	Drive Contents	Inspection contents		Normal condition	Inspection procedure No.	Reference page
01	Injector	Cut fuel to the No.1 injector.	Engine: Idling after warming-up (Cut the fuel supply to each injector in turn and check cylinders which does not affect idling.)		Idling condition becomes different (becomes unstable, or the engine stalls).	Code No. 41	13A-147
02		Cut fuel to the No.2 injector.					
03		Cut fuel to the No.3 injector.					
04		Cut fuel to the No.4 injector.					
05		Cut fuel to the No.5 injector.					
06		Cut fuel to the No.6 injector.					
07	Fuel pump (low-pressure)	Operates the fuel pump (low-pressure) to circulate fuel.	Ignition switch: ON	Pinch the return hose with fingers to feel the pulse of the fuel being circulated.	Pulse is felt.	Procedure No.29	13A-193
				Operating sound can be heard around the fuel tank.	Sound of operation can be heard		
08	Purge control solenoid valve	Solenoid valve turns from OFF to ON.	Ignition switch: ON		Sound of operation can be heard when solenoid valve is driven.	Procedure No.36	13A-197
17	Basic ignition timing	Solenoid valve turns from OFF to ON.	<ul style="list-style-type: none"> <li>● Engine: Idling</li> <li>● Set a timing light.</li> </ul>		5° BTDC	-	-
21	Condenser fan	Drive the fan motor	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● A/C switch: ON</li> </ul>		Fan motor runs	Procedure No.21	13A-187
34	Electronic-controlled throttle valve system	Stop the throttle control servo	Ignition switch: ON		The throttle valve opens slightly	Code No. 91	13A-161

## CHECK AT THE ENGINE-ECU TERMINALS

## TERMINAL VOLTAGE CHECK CHART

Engine-A/T-ECU Connector Terminal Arrangement

107	120	130
106	119	129
105	118	128
	117	127
	116	126
	115	125
	114	124
104	113	123
	112	122
103	111	121
	110	120
102	109	119
	108	118
101	107	117
	106	116
	105	115
	104	114
	103	113
	102	112
	101	111
	100	110
	99	109
	98	108
	97	107
	96	106
	95	105
	94	104
	93	103
	92	102
	91	101
	90	100
	89	99
	88	98
	87	97
	86	96
	85	95
	84	94
	83	93
	82	92
	81	91
	80	90
	79	89
	78	88
	77	87
	76	86
	75	85
	74	84
	73	83
	72	82
	71	81
	70	80
	69	79
	68	78
	67	77
	66	76
	65	75
	64	74
	63	73
	62	72
	61	71
	60	70
	59	69
	58	68
	57	67
	56	66
	55	65
	54	64
	53	63
	52	62
	51	61
	50	60
	49	59
	48	58
	47	57
	46	56
	45	55
	44	54
	43	53
	42	52
	41	51
	40	50
	39	49
	38	48
	37	47
	36	46
	35	45
	34	44
	33	43
	32	42
	31	41
	30	40
	29	39
	28	38
	27	37
	26	36
	25	35
	24	34
	23	33
	22	32
	21	31
	20	30
	19	29
	18	28
	17	27
	16	26
	15	25
	14	24
	13	23
	12	22
	11	21
	10	20
	9	19
	8	18
	7	17
	6	16
	5	15
	4	14
	3	13
	2	12
	1	11
		10
		9
		8
		7
		6
		5
		4
		3
		2
		1

7FU1763

Terminal No.	Check item	Check condition (Engine condition)	Normal condition
1	No.1 injector	While engine is idling after having warmed up, suddenly depress the accelerator pedal.	From 9 - 13 V, momentarily drops slightly
9	No.2 injector		
24	No.3 injector		
2	No.4 injector		
10	No.5 injector		
25	No.6 injector		
3	Oxygen sensor heater	Engine: Idling	0 - 3 V
		Engine: 5,000 r/min	System voltage
6	Injector driver relay	Ignition switch: OFF	0 - 0.1 V
		Ignition switch: ON	0.5 - 1.0 V
8	Alternator G terminal	<ul style="list-style-type: none"> <li>● Engine: Idling after warming-up</li> <li>● Radiator fan: Not operating</li> <li>● Headlamp: off to on</li> <li>● Stop lamp: off to on</li> <li>● Defogger switch: OFF to ON</li> </ul>	The voltage increases by 0.2 - 3.5 V
54	Alternator FR terminal	<ul style="list-style-type: none"> <li>● Engine: Idling after warming-up</li> <li>● Radiator fan: Not operating</li> <li>● Headlamp: off to on</li> <li>● Stop lamp: off to on</li> <li>● Defogger switch: OFF to ON</li> </ul>	The voltage drops
11	No.1 ignition coil	Engine speed: 3,000 r/min	0.3 - 3.0 V
31	No.2 ignition coil		
13	No.3 ignition coil		
30	No.4 ignition coil		
12	No.5 ignition coil		
32	No.6 ignition coil		
14	Throttle control servo relay	Ignition switch: OFF	0 - 0.1 V
		Ignition switch: ON	0.5 - 1.0 V

Terminal No.	Check item	Check condition (Engine condition)	Normal condition	
18	Condenser fan relay	Condenser fan not operating	System voltage	
		Condenser fan operating	0 - 3 V or more	
19	Air flow sensor reset signal	Engine: Idling	0 - 1 V	
		Engine speed: 3,000 r/min	6 - 9 V	
20	A/C relay	<ul style="list-style-type: none"> <li>Engine: Idling</li> <li>A/C switch: OFF to ON (Compressor operating)</li> </ul>	System voltage or changes momentarily 6 V or more to 0 - 3 V	
21	Fuel pump relay	Ignition switch: ON	System voltage	
		Engine: Idling	0 - 3 V	
22	Engine warning lamp	Ignition switch: OFF to ON	System voltage	
23	GDI ECO indication lamp	Ignition switch: OFF to ON	0 - 3 V (system voltage after five seconds)	
		Rev the engine suddenly.	System voltage	
34	Purge control solenoid valve	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95 °C</li> <li>Ignition switch: ON</li> </ul>	Engine: stopped	System voltage
			Engine: After starting, increase the engine speed up to 3,500 r/min	The voltage drops
41	Power supply	Ignition switch: ON	System voltage	
47				
43	Engine ignition signal	Engine speed: 3,000 r/min	0.3 - 3.0 V	
44	Engine coolant temperature sensor	Ignition switch: ON	When engine coolant temperature is 0°C	3.2 - 3.8 V
			When engine coolant temperature is 20°C	2.3 - 2.9 V
			When engine coolant temperature is 40°C	1.3 - 1.9 V
			When engine coolant temperature is 80°C	0.3 - 0.9 V
45	Crank angle sensor	Engine: Cranking	0.4 - 4.0 V	
		Engine: Idling	1.5 - 2.5 V	
46	Power supply voltage applied to accelerator pedal position sensor (1st channel)	Ignition switch: ON	4.5 - 5.5 V	

Terminal No.	Check item	Check condition (Engine condition)		Normal condition
49	Engine control relay	Ignition switch: OFF		0 - 3 V
		Ignition switch: ON		System voltage
51	EGR valve (A)	Ignition switch: OFF to ON		5 - 8 V (Repeatedly changes for approx. 3 seconds)
53	EGR valve (C)			
60	EGR valve (B)			
62	EGR valve (C)			
52	Power steering fluid pressure switch	Engine: Idling after warming-up	When steering wheel is stationary	System voltage
			When steering wheel is turned	0 - 3 V
55	Barometric pressure sensor	Ignition switch: ON	At an altitude of 0 m	3.7 - 4.3 V
			At an altitude of 1,200 m	3.2 - 3.8 V
56	Camshaft position sensor	Engine: Cranking		0.4 - 3.0 V
		Engine: Idling		0.5 - 2.0 V
58	Ignition switch-ST	Engine: Cranking		8 V or more
61	A/C switch 2	Refer to GROUP 55 - Troubleshooting (Check at A/C-ECU or Engine-ECU Terminal).		
63	Injector open circuit check signal	Engine: Increases from idling up to 4,000 r/min		The voltage decreases slightly (approx. 0.7 V) from 4.5 - 5.0 V.
64	Intake air temperature sensor	Ignition switch: ON	When intake air temperature is 0°C	3.2 - 3.8 V
			When intake air temperature is 20°C	2.3 - 2.9 V
			When intake air temperature is 40°C	1.5 - 2.1 V
			When intake air temperature is 80°C	0.4 - 1.0 V
65	Air flow sensor	Engine: Idling		2.2 - 3.2 V
		Engine speed: 2,500 r/min		
66	Backup power supply	Ignition switch: OFF		System voltage
71	Oxygen sensor	Engine: Running at 2,500 r/min after warming-up (Check by using a digital voltmeter.)		Voltages of 0 V and 0.8 V alternate

Terminal No.	Check item	Check condition (Engine condition)		Normal condition
78	Throttle position sensor (2nd channel)	Ignition switch: ON	Release the accelerator pedal.	4.0 V or higher
			Depress the accelerator pedal fully.	0.4 - 0.6 V
79	Accelerator pedal position switch	Ignition switch: ON	Release the accelerator pedal.	0 - 1 V
			Depress the accelerator pedal slightly.	4 V or more
80	Vehicle speed sensor	<ul style="list-style-type: none"> <li>● Ignition switch: ON</li> <li>● Move the vehicle slowly forward</li> </ul>		Voltages of 0 and 8 - 12 V alternate (changes repeatedly)
83	A/C switch 1	Engine: Idling	A/C switch: OFF	0 - 3 V
			A/C switch: ON (Compressor is operating)	System voltage
86	Small lamp switch	Lighting switch: OFF		0 - 3 V
		Lighting switch: Tail light position		System voltage
87	Sensor applied voltage	Ignition switch: ON		4.5 - 5.5 V
93	Fuel pressure sensor	Engine: Idling		0.3 - 4.7 V
95	Accelerator pedal position sensor (1st channel)	Ignition switch: ON	Release the accelerator pedal.	0.985 - 1.085 V
			Depress the accelerator pedal fully.	4.0 V or higher
98	Ignition switch-IG	Ignition switch: ON		System voltage
123	Stop lamp switch	Depress the brake pedal.		System voltage
		Release the brake pedal.		0 - 3 V

**CHECK CHART FOR RESISTANCE AND CONTINUITY  
BETWEEN TERMINALS**

1. Turn the ignition switch to OFF.
2. Disconnect the engine-A/T-ECU connector.
3. Measure the resistance and check for continuity between the terminals of the engine-A/T-ECU harness-side connector while referring to the check chart.

**NOTE**

- (1) When measuring resistance and checking continuity, a harness for checking contact pin pressure should be used instead of inserting a test probe.
- (2) Checking need not be carried out in the order given in the chart.

**Caution**

**If the terminals that should be checked are mistaken, or if connector terminals are not correctly shorted to earth, damage may be caused to the vehicle wiring, sensors, engine-A/T-ECU and/or ohmmeter.**

**Be careful to prevent this!**


4. If the ohmmeter shows any deviation from the standard value, check the corresponding sensor, actuator and related electrical wiring, and then repair or replace.
5. After repair or replacement, recheck with the ohmmeter to confirm that the repair or replacement has corrected the problem.



## CHECK AT THROTTLE VALVE CONTROLLER TERMINALS


### TERMINAL VOLTAGE CHECK CHART

#### Throttle Valve Controller Terminal Arrangement



7FU2290

Terminal No.	Check item	Check condition (Engine condition)		Normal condition
1	Throttle control servo (U)	<ul style="list-style-type: none"> <li>Ignition switch: ON</li> <li>Accelerator pedal: From released position to fully depressed position</li> </ul>		Changes
14	Throttle control servo (V)			
15	Throttle control servo (W)			
2	Throttle control servo power supply	Ignition switch: ON		System voltage
5	Power supply	Ignition switch: ON		System voltage
6	Sensor applied voltage	Ignition switch: ON		4.5 - 5.5 V
7	Throttle position sensor (1st channel)	Ignition switch: ON	Release the accelerator pedal.	0.4 - 0.8 V
			Depress the accelerator pedal fully.	4.2 - 4.8 V
18	Backup power supply	Ignition switch: OFF		System voltage
20	Accelerator pedal position sensor (2nd channel)	Ignition switch: ON	Release the accelerator pedal.	0.985 - 1.085 V
			Depress the accelerator pedal fully.	4.0 V or higher
22	Ignition switch-IG	Ignition switch: ON		System voltage



**INSPECTION PROCEDURE USING AN ANALYZER**

**AIR FLOW SENSOR (AFS)**

**Measurement Method**

1. Disconnect the air flow sensor connector, and connect the special tool (test harness: MB991709) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to air flow sensor connector terminal 3.

**Alternate Method (Test harness not available)**


1. Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 65.

**Standard Wave Pattern**


**Observation conditions**

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min	Idle speed

**Standard wave pattern**




**Observation conditions (from conditions above engine speed is increased by racing.)**



7FU0880

**Wave Pattern Observation Points**

Check that cycle time T becomes shorter and the frequency increases when the engine speed is increased.



**Examples of Abnormal Wave Patterns**

- Example 1

**Cause of problem**

Sensor interface malfunction

**Wave pattern characteristics**

Rectangular wave pattern is output even when the engine is not started.


- Example 2

**Cause of problem**

Damaged rectifier or vortex generation column

**Wave pattern characteristics**

Unstable wave pattern with non-uniform frequency. However, when an ignition leak occurs during acceleration, the wave pattern will be distorted temporarily, even if the air flow sensor is normal.



**CAMSHAFT POSITION SENSOR AND CRANK ANGLE SENSOR**

**Measurement Method**

1. Disconnect the camshaft position sensor connector and connect the special tool (test harness: MB991709) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to camshaft position sensor terminal 2.
3. Disconnect the crank angle sensor connector and connect the special tool (test harness: MD998478) in between.
4. Connect the analyzer special patterns pickup to crank angle sensor terminal 2.

**Alternate Method (Test harness not available)**


1. Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 56. (When checking the camshaft position sensor signal wave pattern.)
2. Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 45. (When checking the crank angle sensor signal wave pattern.)

**Standard Wave Pattern**

**Observation conditions**

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min	Idle speed


## Standard wave pattern



7FU0887

## Wave Pattern Observation Points

Check that cycle time T becomes shorter when the engine speed increases.



### Examples of Abnormal Wave Patterns


- Example 1

#### Cause of problem

Sensor interface malfunction

#### Wave pattern characteristics

Rectangular wave pattern is output even when the engine is not started.



- Example 2


#### Cause of problem

Loose timing belt

Abnormality in sensor disk

#### Wave pattern characteristics

Wave pattern is displaced to the left or right.



**INJECTORS AND INJECTOR OPEN CIRCUIT CHECK SIGNAL**


**Measurement Method**

1. Connect the analyzer special patterns pickup to terminal 1 (No.1 injector) of the engine-A/T-ECU connector.
2. Connect the analyzer special patterns pickup to terminal 63 (injector open circuit check signal) of the engine-ECU connector.
3. After checking terminal 1, check terminal 9 (No.2 injector), terminal 24 (No.3 injector), terminal 2 (No.4 injector), terminal 10 (No.5 injector) and terminal 25 (No.6 injector).


**Standard Wave Pattern Observation conditions**

Function	Special pattern
Pattern height	Low
Pattern selector	Display
Engine r/min	Idle speed

**Standard wave pattern**




7FU2123



**Wave Pattern Observation Points**

- Check that the injector drive time is identical to the time displayed on the MUT-II.
- Check that the injector signals become greatly extended but soon return to their normal wave length when the engine is suddenly raced.
- Check that the injector open circuit check signal is synchronized with each rising portion of the injector drive signal.



**IGNITION COIL AND POWER TRANSISTOR**

Power transistor control signal

**Measurement Method**

1. Disconnect the ignition coil connector, and connect the special tool (test harness: MB991658) in between. (All terminals should be connected.)
2. Connect the analyzer special patterns pickup to terminal 3 of each ignition coil connector in turn.

**Alternate Method (Test harness not available)**


1. Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 11 (No. 1 ignition coil), terminal 31 (No. 2 ignition coil), terminal 13 (No. 3 ignition coil), terminal 30 (No. 4 ignition coil), terminal 12 (No.5 ignition coil) and terminal 32 (No.6 ignition coil) respectively.

**Standard Wave Pattern**

**Observation condition**

Function	Special patterns
Pattern height	Low
Pattern selector	Display
Engine r/min	Approx. 1,200 r/min


**Standard wave pattern**



**Wave Pattern Observation Points**

Point: Condition of wave pattern build-up section and maximum voltage (Refer to abnormal wave pattern examples 1 and 2.)

Condition of wave pattern build-up section and maximum voltage	Probable cause
Rises from approx. 2V to approx. 4.5V at the top-right	Normal
2V rectangular wave	Open-circuit in ignition primary circuit
Rectangular wave at power voltage	Power transistor malfunction

**Examples of Abnormal Wave Patterns**

- Example 1


Wave pattern during engine cranking

**Cause of problem**

Open-circuit in ignition primary circuit

**Wave pattern characteristics**

Top-right part of the build-up section cannot be seen, and voltage value is approximately 2V too low.



- Example 2


Wave pattern during engine cranking

**Cause of problem**

Malfunction in power transistor

**Wave pattern characteristics**

Power voltage results when the power transistor is ON.



## EGR VALVE (STEPPER MOTOR)

### Measurement Method

1. Disconnect the EGR valve connector, and connect the special tool (test harness: MB991658) in between.
2. Connect the analyzer special patterns pickup to the EGR valve-side connector terminal 1, terminal 3, terminal 4 and terminal 6 respectively.

### Alternate Method (Test harness not available)


1. Connect the analyzer special patterns pickup to engine-A/T-ECU terminal 51, connection terminal 60, connection terminal 53, and connection terminal 62 respectively.

## Standard Wave Pattern

### Observation conditions

Function	Special patterns
Pattern height	High
Pattern selector	Display
Engine condition	When the engine coolant temperature is 20°C or below, turn the ignition switch from OFF to ON (without starting the engine).
	While the engine is idling, turn the A/C switch to ON.
	Immediately after starting the warm engine

### Standard wave pattern



**Wave Pattern Observation Points**



Check that the standard wave pattern appears when the EGR control servo is operating.

Point A: Presence or absence of induced electromotive force from the motor turning. (Refer to the abnormal wave pattern.)

Contrast with standard wave pattern	Probable cause
Induced electromotive force does not appear or is extremely small.	Motor is malfunctioning

Point B: Height of coil reverse electromotive force

Contrast with standard wave pattern	Probable cause
Coil reverse electromotive force does not appear or is extremely small.	Short in the coil

**Examples of Abnormal Wave Pattern**

- Example 1

**Cause of problem**

Motor is malfunctioning. (Motor is not operating.)

**Wave pattern characteristics**

Induced electromotive force from the motor turning does not appear.

- Example 2



**Cause of problem**

Open circuit in the line between the EGR valve and the engine-A/T-ECU

**Wave pattern characteristics**

Current is not supplied to the motor coil on the open circuit side. (Voltage does not drop to 0 V.)

Furthermore, the induced electromotive force waveform at the normal side is slightly different from the normal waveform.



## ON-VEHICLE SERVICE

### Caution

- (1) Never attempt to tamper the fixed SAS. The fixed SAS is precisely adjusted at factory.
- (2) Should it be tampered, the full closed position of the throttle valve will be changed. This causes the engine-ECU to learn a wrong position of the throttle valve.

### FUEL PUMP CONNECTOR DISCONNECTION (HOW TO REDUCE FUEL PRESSURE)

When removing the fuel pipe, hose, etc., since fuel pressure in the fuel pipe line is high, do the following operation so as to release fuel pressure in the line and prevent fuel from running out.

1. Remove the fuel filler cap to release pressure in the fuel tank.
2. Remove the fuel pump relay.
3. Connect the MUT-II to the diagnosis connector.

### Caution


**Turn off the ignition switch before disconnecting or connecting the MUT-II.**

4. Turn off the ignition switch.
5. Select "Item No.74" from the MUT-II Data list.
6. Crank the engine for at least two seconds.
7. If the engine is not be started, use the MUT-II to make sure that the fuel pressure is 0.5 MPa or less. Then turn off the ignition switch.
8. If the engine is started, release fuel pressure by the following procedure:
  - (1) Turn off the ignition switch, and then stop the engine.
  - (2) Disconnect one of the ignition coil connectors.
  - (3) Crank the engine for at least two seconds.
  - (4) If the engine is not be started, use the MUT-II to make sure that the fuel pressure is 0.5 MPa or less. Then turn off the ignition switch.
  - (5) If the engine is started, stop it by racing and use the MUT-II to make sure that the fuel pressure is 0.5 MPa or less. Then turn off the ignition switch.
  - (6) Reconnect the ignition coil connector.

### Caution

**Clean the spark plug which corresponds to the disconnected ignition coil connector.**

9. Remove the MUT-II.
10. Install the fuel pump relay.



### FUEL PUMP OPERATION (LOW PRESSURE) CHECK

1. Check the operation of the fuel pump by using the MUT-II to force-drive the fuel pump.
2. If the fuel pump will not operate, check by using the following procedure, and if it is normal, check the drive circuit.
  - (1) Turn the ignition switch to the LOCK (OFF) position.
  - (2) Remove the fuel pump relay. Connect the terminal No.2 of the harness-side connector to the battery. Check if the fuel pump operation sound can be heard at this time.


#### NOTE

As the fuel pump is an in-tank type, the fuel pump sound is hard to hear, so remove the fuel filler cap and check from the tank inlet.

- (3) Check the fuel pressure by pinching the fuel hose with the fingertips.


### THROTTLE BODY (THROTTLE VALVE AREA) CLEANING

1. Start the engine, and warm it up until engine coolant temperature reaches 80°C. Then stop the engine.
2. Remove the air intake hose at the throttle body side.
3. Apply cleaning agent to the throttle valve through the intake port of the throttle valve, and then leave it for approx. five minutes.
4. Start the engine, race it several times, and then let it run at idle for approx. one minute.
5. If carbon deposits are not removed from the throttle valve area, repeat steps (3) and (4).
6. Install the air intake hose.
7. Use the MUT-II or disconnect the negative battery cable from the battery terminal in order to erase a diagnosis code. Wait for at least ten seconds, and then let the engine run at idle again for approx. ten minutes.



### THROTTLE POSITION SENSOR (TPS) ADJUSTMENT

1. Connect the MUT-II to the diagnosis connector.




2. Check the output voltage of throttle position sensor (1st channel) while closing the throttle valve fully with your finger.

**Standard value: 0.4 - 0.6 V**

3. If outside the standard value, loosen the throttle position sensor mounting bolts, and adjust the throttle position sensor by rotating it.
4. Check the output voltage of throttle position sensor (2nd channel) while closing the throttle valve fully with your finger.

**Standard value: 4.2 - 4.8 V**


5. If outside the standard value, replace the throttle position sensor.
6. Turn the ignition switch to the LOCK (OFF) position.
7. Connect the throttle control servo connector.
8. Remove the MUT-II.
9. If a diagnosis code is set, erase it by using the MUT-II or by disconnecting the negative battery cable for ten seconds or more, reconnecting it.
10. Turn the ignition switch to the ON position, and then return it to the LOCK (OFF) position. Then maintain that condition for ten seconds or more.)  
If the negative battery cable is disconnected at step 11, let the engine run at idle for ten minutes.




## ACCELERATOR PEDAL POSITION SENSOR ADJUSTMENT

### Caution

1. **The Accelerator pedal position sensor should not be moved unnecessarily; it has been precisely adjusted by the manufacturer.**
2. **If the adjustment is disturbed for any reason, readjust as follows.**
  1. Remove the accelerator pedal complete.
  2. Connect the MUT-II to the diagnosis connector.



3. Check that the accelerator pedal arm touches the full-closed stopper.
  4. Adjust the pedal arm by the adjusting screw so that clearance "A" (see the illustration) is 0.5 - 0.93 mm.
  5. Hold the adjusting screw with the lock nut.
  6. Turn the ignition switch to the ON position. (but do not start the engine.)
  7. Turn the accelerator pedal position sensor until the output from accelerator pedal position sensor (1st channel) satisfies the standard value.
- Standard value: 0.985 - 1.085 V**
8. Tighten the accelerator pedal position sensor mounting bolts securely.
  9. Install the accelerator pedal complete.




## FUEL PRESSURE TEST

### MEASUREMENT OF FUEL LOW PRESSURE BETWEEN FUEL PUMP (LOW PRESSURE) AND FUEL PUMP (HIGH PRESSURE)

1. Release residual pressure from the fuel pipe line to prevent fuel gush out. (Refer to P.13A-225.)
2. Disconnect the high-pressure fuel hose at the fuel pump (high pressure) side.

#### Caution


**Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.**



3. Remove the union joint and bolt from the special tool (adapter hose) and instead attach the special tool (hose adapter) to the adapter hose.
4. Install the special tool (for measuring the fuel pressure) that was set up in step 3.

<When using the fuel pressure gauge set (special tool)>  
 (1) Install the special tool (for measuring the fuel pressure) between the high-pressure fuel hose and the fuel pump (high pressure).

- (2) Install the fuel pressure gauge set (special tool) on the special tool (for measuring the fuel pressure) putting the gasket between them.
- (3) Connect the lead wire of the fuel pressure gauge set (special tool) to the power supply (cigarette lighter socket) and to the MUT-II.



<When using the fuel pressure gauge>

- (1) Install the fuel pressure gauge on the special tool (for measuring the fuel pressure) putting a suitable O-ring or gasket between them.
  - (2) Install the special tool which was set up in step (1) between the high-pressure fuel hose and the fuel pump (high pressure).
5. Connect the MUT-II to the diagnosis connector.

#### Caution

**Turn off the ignition switch before disconnecting or connecting the MUT-II.**

6. Turn the ignition switch to ON. (But do not start the engine.)
7. Select "Item No.07" from the MUT-II Actuator test to drive the fuel pump (low pressure) at the fuel tank side. Check that there are no fuel leaks from any parts.
8. Finish the actuator test or turn the ignition switch to OFF.
9. Start the engine and run at idle.
10. Measure fuel pressure while the engine is running at idle.

**Standard value: approximately 329 kPa**

11. Check to see that fuel pressure at idle does not drop even after the engine has been raced several times.
12. If fuel pressure is out of the standard value, troubleshoot and repair according to the table below.

Symptom	Probable cause	Remedy
<ul style="list-style-type: none"> <li>● Fuel pressure too low</li> <li>● Fuel pressure drops after racing</li> </ul>	Clogged fuel filter	Replace fuel filter
	Fuel leaking to return side due to poor fuel pressure regulator (low pressure) valve seating or settled spring	Replace fuel pressure regulator (low pressure)
	Low fuel pump (low pressure) delivery pressure	Replace the fuel pump (low pressure)
Fuel pressure too high	Binding valve in fuel pressure regulator (low pressure)	Replace fuel pressure regulator (low pressure)
	Clogged fuel return hose or pipe	Clean or replace hose or pipe

13. Stop the engine and check change of fuel pressure gauge reading. Normal if the reading does not drop within 2 minutes. If it does, observe the rate of drop and troubleshoot and repair according to the table below.


Symptom	Probable cause	Remedy
Fuel pressure drops gradually after engine is stopped	Leaky fuel pressure regulator (low pressure) valve seat	Replace fuel pressure regulator (low pressure)
Fuel pressure drops sharply immediately after engine is stopped	Check valve in fuel pump (low pressure) is held open	Replace the fuel pump (low pressure)

14. Release residual pressure from the fuel pipe line. (Refer to P.13A-225.)
15. Remove the fuel pressure gauge and special tools from the fuel pump (high pressure).

#### Caution

**Cover the hose connection with rags to prevent splash of fuel that could be caused by some residual pressure in the fuel pipe line.**

16. Replace the O-ring at the end of the high-pressure fuel hose with a new one. Furthermore, apply engine oil to the new O-ring before replacement.
17. Fit the high-pressure fuel hose to the fuel pump (high pressure) and tighten the mounting bolt to specified torque.
18. Check for any fuel leaks by following the procedure in step 7.
19. Disconnect the MUT-II.



### MEASUREMENT OF FUEL HIGH PRESSURE BETWEEN FUEL PUMP (HIGH PRESSURE) AND INJECTORS

#### NOTE

Measurement of the fuel pressure between the fuel pump (high pressure) and the injectors should be carried out after checking that the fuel pressure between the fuel pump (low pressure) and the fuel pump (high pressure) is normal.

1. Connect the MUT-II to the diagnosis connector.
2. Disconnect the injector intermediate harness connector.
3. Turn the ignition switch to ON.
4. Select "Item No.74" from the MUT-II Data list.
5. Crank the engine continuously for 2 seconds or more, and visually check that there are no fuel leaks from any parts.

#### Caution

**If any fuel leaks appear, stop cranking immediately and repair the source of the leak.**

6. Check if the fuel pressure is more than 1 MPa immediately after 20 seconds have passed since cranking was finished.


7. If the fuel pressure is lower than 1 MPa, it means that there is likely to be a leak in the high-pressure fuel system, so this system should be checked.
8. Turn the ignition switch to OFF.
9. Connect the injector intermediate harness connector.
10. Start the engine and run at idle.
11. Measure fuel pressure while the engine is running at idle.

**Standard value: 4 - 6.9 MPa**

12. Check to see that fuel pressure at idle does not drop even after the engine has been raced several times.
13. If fuel pressure is out of the standard value, troubleshoot and repair according to the table below.

Symptom	Probable cause	Remedy
<ul style="list-style-type: none"> <li>● Fuel pressure too low</li> <li>● Fuel pressure drops after racing</li> </ul>	Fuel leaking to return side due to poor fuel pressure regulator (high pressure) valve seating or settled spring	Replace fuel pressure regulator (high pressure)
	Low fuel pump (high pressure) delivery pressure	Replace the fuel pump (high pressure)
Fuel pressure too high	Binding valve in fuel pressure regulator (high pressure)	Replace fuel pressure regulator (high pressure)
	Clogged fuel return hose or pipe	Clean or replace hose or pipe

14. Stop the engine and turn the ignition switch to OFF.
15. Disconnect the MUT-II.



## FUEL LEAK CHECK

1. Connect the MUT-II to the diagnosis connector.
2. Disconnect the injector intermediate harness connector.
3. Turn the ignition switch to ON.
4. Select "Item No.74" from the MUT-II Data list.
5. Crank the engine continuously for two seconds or more, and visually check that there are no fuel leaks from any parts.

### Caution

**If any fuel leaks appear, stop cranking immediately and repair the source of the leak.**

6. Crank the engine, and then measure fuel pressure immediately after 20 seconds.

**Limit: Minimum 1 MPa**


### Caution


**If the fuel pressure is less than 1 MPa, there may be a partial fuel leak in the high-pressure fuel system.**

7. Turn off the ignition switch.
8. Reconnect the injector intermediate connector.
9. Remove the MUT-II.

**COMPONENT LOCATION**


Name	Symbol	Name	Symbol
A/C relay	O	Fuel pump relay	H
A/C switch	R	Ignition coil	F
Accelerator pedal position sensor (1st and 2nd channels)	T	Ignition failure sensor	D
		Inhibitor switch <A/T>	X
Air flow sensor (with intake air temperature sensor and barometric pressure sensor)	A	Injectors	F
		Injector driver (L.H.D)	B
Camshaft position sensor	E	Injector driver (R.H.D)	G
Clutch switch <M/T>	S	Injector driver relay	H
Crank angle sensor	K	Oxygen sensor (front)	V
Detonation sensor	L	Oxygen sensor (rear) <M/T>	W
Diagnosis connector	Q	Power steering fluid pressure switch	N
EGR valve	I	Purge control solenoid valve	M
Engine control relay	H	Throttle position sensor	C
Engine coolant temperature sensor	J	Throttle valve controller	U
Engine-A/T-ECU <A/T>	U	Throttle valve control servo	C
Engine-ECU <M/T>	U	Throttle valve control servo relay	H
Engine warning lamp (CHECK ENGINE lamp)	P	Vehicle speed sensor	Y
Fuel pressure sensor	E		





### ENGINE CONTROL RELAY, FUEL PUMP RELAY, INJECTOR DRIVER CONTROL RELAY AND THROTTLE VALVE CONTROL SERVO RELAY CONTINUITY CHECK

Battery voltage	Terminal No.			
	1	2	3	4
Not supplied		○		○
Supplied	○	⊖	○	⊕




### INTAKE AIR TEMPERATURE SENSOR CHECK

1. Disconnect the air flow sensor connector.
2. Measure resistance between terminals 5 and 6.

**Standard value:**

2.3 - 3.0 kΩ (at 20°C)

0.30 - 0.42 kΩ (at 80°C)




3. Measure resistance while heating the sensor using a hair drier.

**Normal condition:**

Temperature (°C)	Resistance (kΩ)
Higher	Smaller

4. If the value deviates from the standard value or the resistance remains unchanged, replace the air flow sensor assembly.




### ENGINE COOLANT TEMPERATURE SENSOR CHECK

**Caution**

Be careful not to touch the connector (resin section) with the tool when removing and installing.

1. Remove the engine coolant temperature sensor.




2. With temperature sensing portion of engine coolant temperature sensor immersed in hot water, check resistance.

**Standard value:**

2.1 - 2.7 k $\Omega$  (at 20°C)

0.26 - 0.36 k $\Omega$  (at 80°C)

3. If the resistance deviates from the standard value greatly, replace the sensor.




4. Apply sealant to threaded portion.

**Specified sealant:**

**3M NUT Locking Part No.4171 or equivalent**

5. Install the engine coolant temperature sensor and tighten it to the specified torque.

**Tightening torque: 29 N·m**



### THROTTLE POSITION SENSOR CHECK

1. Disconnect the throttle position sensor connector.
2. Measure the resistance between throttle position sensor side connector terminal 1 and terminal 3.

**Standard value: 0.9 - 2.5 k $\Omega$**

3. Measure resistance between terminal Nos. 1 and 2 as well as 1 and 4 of the throttle position sensor connector, respectively.

**Normal condition:**

Throttle valve slowly open until fully open from the idle position	Changes smoothly in proportion to the opening angle of the throttle valve
--	---

4. If the resistance is outside the standard value, or if it doesn't change smoothly, replace the throttle position sensor.


**NOTE**

For the throttle position sensor adjustment procedure, refer to P.13A-220.

## ACCELERATOR PEDAL POSITION SENSOR CHECK

1. Disconnect the accelerator pedal position sensor connector.
2. Measure the resistance between accelerator pedal position sensor connector terminal (1) [accelerator pedal position sensor (1st channel) earth] and terminal (2) [accelerator pedal position sensor (1st channel) power supply], and between terminal (7) [accelerator pedal position sensor (2nd channel) earth] and terminal (8) [accelerator pedal position sensor (2nd channel) power supply].

**Standard value: 3.5 - 6.5 k $\Omega$**



3. Measure the resistance between accelerator pedal position sensor connector terminal (2) [accelerator pedal position sensor (1st channel) power supply] and terminal (3) [accelerator pedal position sensor (1st channel) output]; and between terminal (8) [accelerator pedal position sensor (2nd channel) power supply] and terminal (6) [accelerator pedal position sensor (2nd channel) output].


### Normal condition:

When accelerator pedal is gently depressed	Changes comparatively smoothly in proportion to the accelerator pedal depression amount
--	---

4. If the measured values are outside the standard value range, or if the resistance does not change smoothly, replace the accelerator pedal position sensor.

### NOTE

After replacement, adjust the accelerator pedal position sensor. (Refer to P.13A-221.)



## ACCELERATOR PEDAL POSITION SWITCH CHECK

1. Disconnect the accelerator pedal position sensor (1st channel) connector.
2. Check continuity between terminal Nos. 4 (accelerator pedal position switch) and 5 (sensor earth) of the connector.


### Normal condition

Accelerator pedal	Continuity
Depressed	No continuity
Released	Continuity (0 Ω)

3. If defective, replace the accelerator pedal position sensor assembly.

### NOTE


After replacement, adjust the accelerator pedal position sensor and switch. (Refer to P.13A-221.)




## OXYGEN SENSOR CHECK

### <Oxygen sensor (front)>

1. Disconnect the oxygen sensor connector and connect the special tool (test harness) to the connector on the oxygen sensor side.
2. Make sure that there is continuity (4.5 - 8.0 Ω at 20°C) between terminal 2 (red clip of special tool) and terminal 4 (blue clip of special tool) on the oxygen sensor connector.



3. If there is no continuity, replace the oxygen sensor.
4. Warm up the engine until engine coolant is 80°C or higher.



5. Use a jumper wire to connect terminal 1 (red clip) of the oxygen sensor connector to the battery (+) terminal and terminal 3 (blue clip) to the battery (-) terminal.

### Caution

**Be very careful when connecting the jumper wire; incorrect connection can damage the oxygen sensor.**

6. Connect a digital voltage meter between terminal 2 (black clip) and terminal 4 (white clip).

7. While repeatedly racing the engine, measure the oxygen sensor output voltage.



**Standard value:**

Engine	Oxygen sensor output voltage	Remarks
When racing the engine	0.6 - 1.0 V	If you make the air/fuel ratio rich by racing the engine repeatedly, a normal oxygen sensor will output a voltage of 0.6 - 1.0 V.

8. If the sensor is defective, replace the oxygen sensor.

**NOTE**


For removal and installation of the oxygen sensor, refer to GROUP 15 - Exhaust Pipe and Main Muffler.

**<Oxygen sensor (rear) M/T only>**

1. Disconnect the oxygen sensor connector and connect the special tool (test harness set) to the connector on the oxygen sensor side.
2. Make sure that there is continuity ( $4.5 - 8.0 \Omega$  at  $20^\circ\text{C}$ ) between terminal 2 and terminal 4 on the oxygen sensor connector.
3. If there is no continuity, replace the oxygen sensor.

**NOTE**

- (1) If the MUT-II does not display the standard value although no abnormality is found by the above mentioned continuity test and harness check, replace the oxygen sensor (rear).
- (2) For removal and installation of the oxygen sensor, refer to GROUP 15 - Exhaust Pipe and Main Muffler.




## INJECTOR CHECK

1. Disconnect the injector intermediate harness connector.
2. Measure the resistance between each of the terminals.

**Standard value: 0.9 - 1.1  $\Omega$  (at 20°C)**

Injector	Measurement terminal
No.1 cylinder	11 - 12
No.2 cylinder	5 - 6
No.3 cylinder	9 - 10
No.4 cylinder	3 - 4
No.5 cylinder	7 - 8
No.6 cylinder	1 - 2

3. Connect the injector intermediate harness connector.



## THROTTLE VALVE CONTROL SERVO CHECK

### Operation Check

1. Disconnect the air intake hose from the throttle body.
2. Turn on the ignition switch.
3. Check that the throttle valve opens or closes in response to the accelerator pedal depression.


### Check of Coil Resistance

1. Disconnect the throttle valve control servo connector.
2. Measure resistance between the throttle valve control servo connector terminals.

**Standard value:**

Terminals to be measured	Resistance value ( $\Omega$ )
1 - 2	0.6 - 1.0 (at 20°C)
1 - 3	
2 - 3	

3. Check that there is no continuity between the terminals and body.



### CLUTCH SWITCH CHECK

1. Disconnect the connector.
2. Check for continuity between the terminals of the switch.

Measurement conditions	Terminal No.	
	1	2
When clutch pedal is depressed.	○ — ○	○ — ○
When clutch pedal is not depressed.		

### PURGE CONTROL SOLENOID VALVE CHECK

Refer to GROUP 17 - Emission Control System.

### EGR VALVE CHECK


Refer to GROUP 17 - Emission Control System.

# INJECTOR


## REMOVAL AND INSTALLATION

### Pre-removal and Post-installation Operation

- Fuel Line Pressure Reduction <before removal only> (Refer to P.13A-219.)
- Engine Cover Removal and Installation
- Air Intake Hose Removal and Installation (Refer to GROUP 15 - Air Cleaner.)
- Intake Manifold Removal and Installation (Refer to GROUP 15 - Intake Manifold.)
- Fuel Leak Check <after installation only> (Refer to P.13A-225.)



AX0253AA




### Removal steps

- |     |   |     |   |
|-----|---|-----|---|
| ▶F◀ | • Air bleeding from high-pressure fuel line | ▶B◀ | 11. Injector washer                                   |
| ◀A▶ | 1. Fuel pressure sensor connector           | ▶B◀ | 12. Injector holder                                   |
| ▶E◀ | 2. Injector harness                         | ▶B◀ | 13. Delivery pipe assembly and Fuel injector assembly |
| ▶E◀ | 3. Fuel feed pipe                           | ▶B◀ | 14. Insulator   |
| ▶E◀ | 4. Back-up ring A                           | ▶A◀ | 15. Injector gasket                                   |
| ▶E◀ | 5. O-ring                                   | ▶A◀ | 16. Fuel injector assembly                            |
| ▶B▶ | 6. Back-up ring B                           | ▶A◀ | 17. Corrugated washer                                 |
| ▶D▶ | 7. Flange                                   | ▶A◀ | 18. Back-up ring A                                    |
| ▶D▶ | 8. Fuel pressure sensor                     | ▶A◀ | 19. O-ring  |
| ▶C▶ | 9. O-ring                                   | ▶A◀ | 20. Back-up ring B                                    |
| ▶C▶ | 10. Back-up ring                            | ▶A◀ | 21. Delivery pipe                                     |

**REMOVAL SERVICE POINTS****◀A▶ INJECTOR HARNESS DISCONNECTION****Caution**

Disconnect the negative battery cable from its terminal before carrying out this operation.

**◀B▶ FLANGE REMOVAL**

If the fuel pressure sensor is reused, make mating marks on the sensor and the flange.

**NOTE**


The flange secures sealing performance of fuel pressure sensor and installation rigidity by bending to deform the shape at installation. Therefore, make mating marks to install the flange with the right phase and side. In addition, if the fuel pressure sensor is replaced with a new one, replace it together with the flange as a set.

**◀C▶ DELIVERY PIPE ASSEMBLY/FUEL INJECTOR ASSEMBLY REMOVAL**

Remove the delivery pipe assembly with the fuel injector assembly still attached.

**Caution**

Be careful not to drop the fuel injector assembly when removing the delivery pipe assembly.

**INSTALLATION SERVICE POINTS****▶A▶ BACK-UP RING B/O-RING/BACK-UP RING A/CORRUGATED WASHER INSTALLATION**

1. Install the back-up rings and the O-ring as shown in the illustration.

**Caution**


(1) Install the back-up ring B facing its cutaway surface toward the opposite side of the O-ring as shown in the illustration.

(2) Do not confuse back-up ring A with that for the fuel pressure sensor. (External diameter of back-up ring A: 14.8 mm)

2. Apply petroleum jelly to the corrugated washer to prevent it from dropping, and then install it to the direction shown.

**Caution**

The corrugated washer should always be replaced with a new part.



### ►B◄ INJECTOR GASKET/INSULATOR/DELIVERY PIPE ASSEMBLY AND FUEL INJECTOR ASSEMBLY/INJECTOR HOLDER//INJECTOR WASHER INSTALLATION

1. Apply a small amount of fresh engine oil to the O-ring.

#### Caution



**Take care not to let any of the engine oil get inside the delivery pipe assembly.**

2. While being careful not to damage the O-ring, turn the fuel injector assembly to the left and right and connect it to the delivery pipe assembly. After connecting, check that the fuel injector turns smoothly.
3. If the fuel injector does not turn smoothly, the cause may be that the O-ring is getting caught. Remove the fuel injector, check the O-ring for damage and re-connect the fuel injector to the delivery pipe assembly and then re-check.
4. Align the injector mating mark with the delivery pipe mating mark.
5. Install the injector gasket and the insulator to the cylinder head.
6. Install the delivery pipe and fuel injectors assembly to the cylinder head, and then tighten them provisionally.
7. Install the injector holders and washers, and then tighten them to the specified torque.

#### Caution

**Observe the tightening torque.**

8. Working from the centre mounting bolt, tighten the delivery pipe and injector assembly mounting bolts to the specified torque.



### ►C◄ BACK-UP RING B/O-RING INSTALLATION

Install the back-up rings and the O-ring as shown in the illustration.

#### Caution

**Be careful not to confuse this back-up ring with the back-up ring for the injector or back-up ring A for the fuel pipe. (External diameter of the back-up ring: 15.1 mm)**

### ►D◄ FUEL PRESSURE SENSOR/FLANGE INSTALLATION

1. Apply a small amount of fresh engine oil to the O-ring.


#### Caution

Take care not to let any of the engine oil get inside the delivery pipe.

2. Align the mating marks, and then install the sensor to the delivery pipe.

#### Caution

If the fuel pressure sensor is replaced, replace it together with the flange as a set.



### ►E◄ BACK-UP RING B/O-RING/BACK-UP RING A/FUEL PIPE INSTALLATION

1. Install the back-up rings and the O-ring as shown in the illustration.

#### Caution

(1) Install the back-up ring B facing its cutaway surface toward the opposite side of the O-ring as shown in the illustration.

(2) Do not confuse back-up ring A with that for the fuel pressure sensor. (External diameter of back-up ring A: 14.8 mm)

2. Apply a small amount of fresh engine oil to the O-ring.

#### Caution

Take care not to let any of the engine oil get inside the fuel pump (high pressure) and delivery pipe.

3. Insert the fuel pipe into the fuel pump (high-pressure) and the delivery pipe ports squarely. Insert the pipe securely, being careful not to twisting it, and then tighten the mounting bolts to the specified torque.

### ►F◄ AIR BLEEDING FROM THE HIGH-PRESSURE FUEL LINE

1. Run the engine at 2,000 r/min for 15 seconds or more in order to bleed the air.


## NOTE

When removing the fuel pump (high pressure), air may get into the fuel pump (high pressure). If air gets into the fuel pump (high pressure), diagnosis code No.56 for abnormal fuel pressure will be output.

2. Use the MUT-II to check the diagnosis code. If the diagnosis code No.56 for fuel pressure sensor system defect is output, erase it.

**FUEL PUMP (HIGH PRESSURE)****REMOVAL AND INSTALLATION****Pre-removal and Post-installation Operation**

- Fuel Line Pressure Reduction <before removal only> (Refer to P.13A-219.)
- Engine Cover Removal and Installation
- Air Intake Hose Removal and Installation (Refer to GROUP 15 - Air Cleaner.)
- Intake Manifold Removal and Installation (Refer to GROUP 15 - Intake Manifold.)
- Fuel Leak Check <after installation only> (Refer to P.13A-225.)
- Air Bleeding from High Pressure Fuel Line (Refer to P.13A-237.)

**Removal steps**

- ▶D◀ 1. Fuel return hose connection
- ▶C◀ 2. Fuel pressure hose connection
- ▶C◀ 3. O-ring
- ▶B◀ 4. Fuel feed pipe
- ▶B◀ 5. Back-up ring A


- ▶B◀ 6. O-ring
- ▶B◀ 7. Back-up ring B
- ▶A◀ 8. Fuel pump (high pressure)
- ▶A◀ 9. O-ring

**INSTALLATION SERVICE POINTS****▶A◀ FUEL PUMP (HIGH PRESSURE) INSTALLATION**

1. Apply a small amount of fresh engine oil to the fuel pump (high pressure) roller and O-ring.
2. Install temporarily the fuel pump (high pressure) to the cylinder head.

00010734

3. Insert the fuel pump (high-pressure) to the cylinder head ports squarely, and then tighten the mounting bolts temporarily (a little more tightly than finger-tightening). Tightening them to the specified torque should be carried out in later step ►B◄.



#### ►B◄ BACK-UP RING B/O-RING/BACK-UP RING A/FUEL PIPE INSTALLATION

1. Install the back-up rings and the O-ring as shown in the illustration.

##### Caution

- (1) Install the back-up ring B facing its cutaway surface toward the opposite side of the O-ring as shown in the illustration.
- (2) Confirm the outer diameter of the back-up ring A. Take care not to install the back-up ring for the fuel pressure sensor by mistake. (Outer diameter of the back-up ring A: 14.8 mm)


2. Apply a small amount of fresh engine oil to the O-ring.

##### Caution

Take care not to let any of the engine oil get inside the fuel pump (high pressure) or the delivery pipe assembly.

3. Insert the fuel pipe into the fuel pump (high-pressure) and the delivery pipe ports squarely. Insert the pipe securely, being careful not to twisting it, and then tighten the mounting bolts to the specified torque.

**Tightening torque:  $19 \pm 3$  N·m**



4. Tighten the temporarily tightened mounting bolts of the fuel pump (high-pressure) in the shown order to 5.0 N·m.
5. Tighten the bolts to 17 N·m in the order shown in the illustration. The overall difference in tightening torque between the four bolts should be within 2 N·m.

**▶C◀ O-RING/FUEL PRESSURE HOSE INSTALLATION**

1. Apply a small amount of fresh engine oil to the O-ring.

**Caution**

**Take care not to let any of the engine oil get inside the fuel pump (high pressure) or the delivery pipe assembly.**


2. While being careful not to damage the O-ring, turn the fuel pressure hose to the left and right and connect it to the delivery pipe assembly. After connecting, check that the fuel injector turns smoothly.
3. If the fuel pressure hose does not turn smoothly, the cause may be that the O-ring is getting caught. Remove the fuel pressure hose, check the O-ring for damage and re-connect the fuel pressure hose to the delivery pipe assembly and then re-check.

# THROTTLE BODY

## REMOVAL AND INSTALLATION

**Pre-removal and Post-installation Operation**

- Engine Coolant Draining and Supplying (Refer to GROUP 14 - On-vehicle Service.)
- Engine Cover Removal and Installation
- Air Cleaner Removal and Installation (Refer to GROUP 15.)




AX0165CA

**Removal steps**

1. Throttle body stay
2. Throttle control servo connector connection
3. Throttle position sensor connector connection

4. Water hose connection
5. Throttle body assembly
6. Throttle body gasket



03E0217

**INSTALLATION SERVICE POINTS**

**▶A◀ THROTTLE BODY GASKET INSTALLATION**

The projection on the gasket should face upward.


**►B◄ THROTTLE BODY INSTALLATION**

If the throttle body is replaced, initialize the electronic-controlled throttle valve system.

**Initialization**

Turn on the ignition switch, and turn it to the LOCK (OFF) position within one second. Then leave it for at least ten seconds with the ignition switch in the LOCK (OFF) position.


## DISASSEMBLY AND REASSEMBLY



7EN1490

**Disassembly steps**

- ▶◀ 1. Throttle position sensor  
2. Throttle body


**REASSEMBLY SERVICE POINTS****▶◀ THROTTLE POSITION SENSOR**

1. Position the throttle position sensor on the throttle body along the dotted line as shown in the illustration.
2. Rotate the throttle position sensor anticlockwise as shown in the illustration, and then tighten the screws.
3. Measure resistance value between terminal Nos. 1 (sensor power supply) and 2 (throttle position sensor 1st-channel output) as well as 1 (sensor power supply) and 4 (throttle position sensor 2nd channel output).


**Normal condition**

Open the throttle valve slowly from the idle position to full-open position.	Resistance value changes smoothly in response to throttle valve opening angle.
--	--

4. If the resistance value does not change smoothly, replace the throttle position sensor.




## INJECTOR DRIVER REMOVAL AND INSTALLATION



### Removal steps



1. Injector driver
2. Bracket




### REMOVAL SERVICE POINT

#### ◀A▶ INJECTOR DRIVER REMOVAL

Press the injector driver connector in the place shown in the illustration to disconnect the injector driver connector.

#### Caution

1. Disconnect the negative cable from its terminal before carrying out this operation.
2. High-tension current is flowing in the harness between the injector driver and the injector while engine is running, and the injector driver will become hot after the vehicle has been driven, so take care when handling it.

**ENGINE-ECU<M/T>, ENGINE-A/T-ECU<A/T>, THROTTLE VALVE  
CONTROLLER****REMOVAL AND INSTALLATION**

AX1793CA

**Removal steps**

1. Cowl side trim
2. Instrument panel harness and front door harness connection
3. Instrument panel harness and front floor harness connection
4. A/T control relay connector <A/T>
5. A/T control relay <A/T>
6. Engine-ECU <M/T>, Engine□A/T-ECU <A/T> connector

7. Engine-ECU &lt;M/T&gt;, Engine□A/T-ECU &lt;A/T&gt;

8. Throttle valve controller connector

►A◄ 9. Throttle valve controller Instrument panel (Refer to GROUP 52A.)

10. Bracket

**INSTALLATION SERVICE POINT****►A◄ THROTTLE VALVE CONTROLLER INSTALLATION**

If the throttle valve controller is replaced, initialize the electronic-controlled throttle valve system.

**Initialization**

Turn on the ignition switch, and turn it to the LOCK (OFF) position within one second. Then leave it for at least ten seconds with the ignition switch in the LOCK (OFF) position.

---

# Service Bulletins

Click on the applicable bookmark to select the Service Bulletin.

---



# SERVICE BULLETIN

QUALITY INFORMATION ANALYSIS  
OVERSEAS SERVICE DEPT. MITSUBISHI MOTORS CORPORATION

<b>SERVICE BULLETIN</b>		No.: MSB-00E13-001	
		Date: 2001-06-03	<Model> <M/Y>
<b>Subject:</b> AVAILABILITY OF DRIVE CYCLE PATTERNS FOR 2001 MODEL CARS		(EC)GALANT(EA0) (EC)SPACE STAR (EC) SPACE RUNNER/SPACE WAGON(N80, N90) (EC)PAJERO	01-10
<b>Group:</b> FUEL	<b>Draft No.:</b> 00AL602317	SPORT (K80W,K90W) (EC)PAJERO/ MONTERO (V60, V70)	
<b>INFORMATION</b>	INTERNATIONAL CAR ADMINISTRATION OFFICE	 T.MASAKI-MANAGER TECHNICAL SERVICE PLANNING	(EC)CARISMA (EC)PAJERO PININ (H60,H70)

## 1. Description:

On the 2001 model cars equipped with the on-board diagnostics system, the drive cycle patterns have been made available.

Performing the running test of the car using these drive cycle patterns makes it possible to monitor all the diagnosis codes that are required for operation of the car in order to determine if the applicable system is operating properly or not.

## 2. Applicable Manuals:

Manual	Pub. No.	Language	Page(s)
2001 GALANT Workshop Manual Supplement	PWDE9611-B	(English)	4G64-GDI:13I-8
	PWDS9612-B	(Spanish)	4G63-MPI:13A-7
	PWDF9613-B	(French)	6A13-MPI:13A-97
	PWDG9614-B	(German)	
	PWDD9615-B	(Dutch)	
	PWDW9616-B	(Swedish)	
2001 SPACE RUNNER/ SPACE WAGON Workshop Manual Supplement	PWDE9803-C	(English)	4G64-GDI:13A-9
	PWDS9804-C	(Spanish)	4G63-MPI:13D-12
	PWDF9805-C	(French)	
	PWDG9806-C	(German)	
	PWDD9807-C	(Dutch)	
	PWDW9808-C	(Swedish)	
2001 CARISMA Workshop Manual Supplement	PWDE9502-E	(English)	4G93-GDI:13J-8
	PWDS9503-E	(Spanish)	4G92-MPI:13A-7
	PWDF9504-E	(French)	
	PWDG9505-E	(German)	
	PWDD9506-E	(Dutch)	
	PWDW9507-E	(Swedish)	
2001 SPACE STAR Workshop Manual Supplement	CMXE99E1-A	(English)	4G93-GDI:13A-9 4G13-MPI:13B-7
2001 COLT Workshop Manual Supplement	PWME9511-C	(English)	4G13-MPI:13A-7
	PWMS9512-C	(Spanish)	4G93-MPI:13A-88
	PWMF9513-C	(French)	
	PWVG9514-C	(German)	
	PWMD9515-C	(Dutch)	
	PWVW9516-C	(Swedish)	
2001 PAJERO Workshop Manual VOL1	PWJE0001(1/2)	(English)	6G74-GDI:13A-12
2001 MONTERO Workshop Manual VOL1	PWJS0002(1/2)	(Spanish)	
2001 PAJERO/MONTERO Workshop Manual CD-ROM	PWJT0008R	(English)	
		(Spanish)	
		(French)	
		(German)	
2001 PAJERO SPORT Workshop Manual Supplement	PWJE9812-B	(English)	6G72-MPI:13A-8
	PWJS9813-B	(Spanish)	
	PWJF9814-B	(French)	
	PWJG9815-B	(German)	
2001 PAJERO PININ Workshop Manual Supplement	CKRE99E1-A	(English)	4G93-GDI: 13A-9

## DRIVE CYCLE

Performing the running test of the car using the following five drive cycle patterns makes it possible to monitor all the diagnosis codes that are required for operation of the car in order to determine if the applicable system is operating properly or not.

In other words, doing such a drive allows to regenerate any kind of trouble which involves illuminating the Engine Warning Lamp (Check Engine Lamp) and to verify the repair procedure has eliminated the trouble [the Engine Warning Lamp (Check Engine Lamp) is no longer illuminated].

### Caution

**Two technicians should always be in the vehicle when carrying out a test drive.**

### NOTE

Check that the diagnosis code is not output before traveling in the Drive cycle pattern. Erase the diagnosis code if it has been output.

## DRIVE CYCLE PATTERN LIST

PROCEDURE	MONITOR ITEM	DIAGNOSIS CODE
1	Catalytic converter monitor	P0420
	Heated oxygen sensor <front> monitor	P0130
2	Fuel trim monitor	P0170
3	Feed back monitor	P0125
4	Other monitor	P0136, P0201, P0202, P0203, P0204, P0205, P0206, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0325

### NOTE

The vehicle speed sensor (P0500) and the power steering fluid pressure switch (P0551) are used to determine if the system is operating properly or not through use of the Data List function of the MUT-II.


**PROCEDURE 1**

monitor item	<b>CATALYTIC CONVERTER MONITOR (P0420)</b> <b>OXYGEN SENSOR &lt;FRONT&gt; MONITOR (P0130)</b>
Drive cycle pattern	<p>One trip monitor [from start to ignition switch to "LOCK" (OFF) position] will be completed while traveling with the following drive cycle pattern. It will take 10 minutes or more.</p> <p style="text-align: right;">Y6005BY</p>
Inspection conditions	<ul style="list-style-type: none"> <li>• Atmospheric temperature : -10 °C or more</li> <li>• Condition of A/T :Selector lever D range, overdrive switch "ON" position</li> </ul>
Test procedure	<ol style="list-style-type: none"> <li>1. Engine : start</li> <li>2. Accelerate until the vehicle speed is 100 km/h or more.</li> <li>3. Travel for 5 minutes or more while keeping the vehicle speed is 100 km/h or more.</li> <li>4. Decelerate until the vehicle speed is 60 - 80 km/h or less.</li> <li>5. While keeping the accelerator pedal opening degree constant, keep the vehicle speed at 60 - 80 km/h and travel for 5 minutes or more.             <ul style="list-style-type: none"> <li>• Stopping and braking during this operation are permitted.</li> </ul> </li> <li>6. Return the vehicle to the shop, then turn the ignition switch "LOCK" (OFF) position.</li> </ol>


**PROCEDURE 2**

monitor item	<b>FUEL TRIM MONITOR (P0170)</b>
Drive cycle pattern	<p>One trip monitor [from start to ignition switch to "LOCK" (OFF) position] will be completed while traveling with the following drive cycle pattern. It will take 15 minutes or more.</p> <p style="text-align: right;">Y6002BY</p>
Inspection conditions	<ul style="list-style-type: none"> <li>• Engine coolant temperature : 85 °C or more</li> <li>• Atmospheric temperature : -10 °C or more</li> <li>• Condition of A/T :Selector lever D range, overdrive switch "ON" position</li> </ul>
Test procedure	<ol style="list-style-type: none"> <li>1. Engine : start</li> <li>2. Accelerate until the vehicle speed is 80 – 110 km/h.</li> <li>3. While keeping the accelerator pedal opening degree constant, keep the vehicle speed at 80 – 110 km/h and travel for 15 minutes or more.</li> <li>4. Return the vehicle to the shop, then turn the ignition switch "LOCK" (OFF) position.</li> </ol>

**PROCEDURE 3**

monitor item	<b>FEED BACKK MONITOR (P0125)</b>
Drive cycle pattern	<p>One trip monitor [from start to ignition switch to "LOCK" (OFF) position] will be completed while traveling with the following drive cycle pattern. It will take 5 minutes or more.</p>  <p style="text-align: right;">Y6002BY</p>
Inspection conditions	<ul style="list-style-type: none"> <li>● Engine coolant temperature : 85 °C or more</li> <li>● Atmospheric temperature : -10 °C or more</li> <li>● Condition of A/T :Selector lever D range, overdrive switch "ON" position</li> </ul>
Test procedure	<ol style="list-style-type: none"> <li>1. Engine : start</li> <li>2. Accelerate until the vehicle speed is 100 – 120 km/h.</li> <li>3. While keeping the accelerator pedal opening degree constant, keep the vehicle speed at 100 – 120 km/h and travel for 5 minutes or more.</li> <li>4. Return the vehicle to the shop, then turn the ignition switch "LOCK" (OFF) position.</li> </ol>

**PROCEDURE 4**

monitor item	<b>OTHER MONITOR</b>
Diagnosis code No.	P0136, P0201, P0202, P0203, P0204, P0205, P0206, P0300, P0301, P0302, P0303, P0304, P0305, P0306, P0325
Drive cycle pattern	<p>One trip monitor [from start to ignition switch to "LOCK" (OFF) position] will be completed while traveling with the following drive cycle pattern. It will take 6 minutes or more.</p>  <p style="text-align: right;">Y6009BY</p>
Inspection conditions	<ul style="list-style-type: none"> <li>● Engine coolant temperature : 85 °C or more</li> <li>● Atmospheric temperature : -10 °C or more</li> <li>● Condition of A/T :Selector lever D range, overdrive switch "ON" position</li> </ul>
Test procedure	<ol style="list-style-type: none"> <li>1. Engine : start</li> <li>2. Accelerate until the vehicle speed is 60 km/h.</li> <li>3. While keeping the accelerator pedal opening degree constant, keep the vehicle speed at 60 km/h or more and travel for 5 minutes or more.</li> <li>4. Return the vehicle to the shop</li> <li>5. After stopping the vehicle, continue idling for 30 seconds, and then turn the ignition switch to "LOCK" (OFF) position.             <ul style="list-style-type: none"> <li>● A/C switch : OFF</li> <li>● Light and all accessories: OFF</li> <li>● Transmission : Neutral</li> </ul> </li> </ol>

# GASOLINE DIRECT INJECTION (GDI)

## CONTENTS

<b>GENERAL</b> .....	<b>3</b>	<b>GENERAL INFORMATION</b> .....	<b>3</b>
Outline of Change .....	3	General Specifications .....	3



## GENERAL

### OUTLINE OF CHANGE

The engine-ECU <M/T> and engine-A/T-ECU <A/T>, which feature communication port with stability control system, have been introduced. The service procedures for these ECUs are the same as before.

## GENERAL INFORMATION

### GENERAL SPECIFICATIONS

Items		Specifications
Engine-ECU <M/T>	Identification No.	E2T79275 <LHD> E2T79276 <RHD>
Engine-A/T-ECU <A/T>	Identification No.	E2T76290 <LHD> E2T76291 <RHD>

# GASOLINE DIRECT INJECTION (GDI)

## CONTENTS

<b>GENERAL</b> .....	<b>3</b>	<b>TROUBLESHOOTING</b> .....	<b>3</b>
Outline of Changes .....	3	<b>ON-VEHICLE SERVICE</b> .....	<b>7</b>
<b>GENERAL INFORMATION</b> .....	<b>3</b>	Oxygen Sensor Check .....	7



## GENERAL

### OUTLINE OF CHANGES

Due to the changes as shown below, the service procedures regarding the different description from the previous version have been established.

- On M/T, the engine-ECU has been changed as diagnosis code P1603 has been added.
- On A/T, the engine-A/T-ECU has been changed as an on-board diagnosis system has been adopted. The engine warning lamp control, the diagnosis function, the service data output and the actuator test are basically the same as for M/T.
- On A/T, an dual oxygen sensor has been adopted. This sensor is the same as for the previous M/T.

## GENERAL INFORMATION

### GENERAL SPECIFICATIONS

Items		Specifications
Engine-ECU <M/T>	Identification No.	E2T79277 <LHD> E2T79278 <RHD>
Engine-A/T-ECU <A/T>	Identification No.	E2T76292 <LHD> E2T76293 <RHD>

## TROUBLESHOOTING

### DIAGNOSIS FUNCTION

#### ENGINE WARNING LAMP (CHECK ENGINE LAMP)

The following item has been added as diagnosis code P1603 has been added. The other items are the same as before.

#### Engine warning lamp inspection items

Code No.	Diagnosis item
P1603	Battery backup line malfunction


### INSPECTION CHART FOR DIAGNOSIS CODES

Diagnosis code P1603 has been added. The other codes are the same as for the previous M/T.

Code No.	Diagnosis item	Reference page
P1603	Battery backup line malfunction	13A-4

**INSPECTION PROCEDURE CLASSIFIED BY DIAGNOSIS CODE**

Code No. P1603 Battery backup line malfunction	Probable cause
<p>Range of Check</p> <ul style="list-style-type: none"> <li>Starting sequence was completed.</li> <li>The battery voltage is 10 V or more.</li> </ul> <p>Set Condition</p> <ul style="list-style-type: none"> <li>Battery backup line voltage is less than 2 V.</li> </ul>	<ul style="list-style-type: none"> <li>Open or short circuit in the battery back-up line or loose connector contact</li> <li>Malfunction of engine-ECU &lt;M/T&gt;</li> <li>Malfunction of engine-A/T-ECU &lt;A/T&gt;</li> </ul> <p>NOTE: If the engine is started while the ignition-off current draw connector has been pulled off, the engine-ECU &lt;M/T&gt; or the engine-A/T-ECU &lt;A/T&gt; judges that the battery backup line is open, and illuminates the engine warning lamp and stores this diagnosis code.</p>



**DATA LIST REFERENCE TABLE**

The data list has been changed as the engine-ECU and the engine-A/T-ECU have been changed. The other items are the same as for M/T.

Item No.	Inspection item	Inspection contents	Normal condition	Inspection procedure No.	Reference page	
22	Crank angle sensor	<ul style="list-style-type: none"> <li>Engine: Cranking</li> <li>Tachometer: Connected</li> </ul>	Compare the engine speed readings on the tachometer and the MUT-II.	Accord	Code No. P0335	13A-56*
		<ul style="list-style-type: none"> <li>Engine: Idling</li> <li>Idle position switch: ON</li> </ul>	When engine coolant temperature is -20°C	1,300 - 1,500 r/min		
			When engine coolant temperature is 0°C	1,300 - 1,500 r/min		
			When engine coolant temperature is 20°C	1,250 - 1,450 r/min		
			When engine coolant temperature is 40°C	1,100 - 1,300 r/min		
			When engine coolant temperature is 80°C (more than four minutes later after engine has started)	600 - 800 r/min		
A1★	Oxygen sensor	Engine: After having warmed up. (Air/fuel mixture is made leaner when decelerating, and is made richer when racing.)	When at 4,000 r/min, engine is decelerated	200 mV or less	Code No. P0130	13A-28*
			Rev the engine.	600 - 1000 mV		
		Engine: After having warmed up (The oxygen sensor signal is used to check the air/fuel mixture ratio, and control condition is also check by the engine-ECU <M/T> or engine-A/T-ECU <A/T>.)	Engine is idling (more than 4 minutes later after engine has started)	Voltage should alternate between 400 mV or less and 600 - 1,200 mV (more than 4 minutes after the engine has started).		
			2,500 r/min			
24★	Vehicle speed sensor	Drive at 40 km/h	Approximately 40 km/h	Code No. P0500	13A-63*	

Item No.	Inspection item	Inspection contents		Normal condition	Inspection procedure No.	Reference page
81★	Learned value	Engine: Warm, 2,500 r/min without any load (during closed loop lambda control)		-10 - 10 %	Code No. P0170	13A-34*
82★	Closed loop control	Engine: Warm, 2,500 r/min without any load (during closed loop lambda control)		-25 - 25 %	Code No. P0170	13A-34*
87★	Engine load	Engine: After having warmed up	Idling (more than 4 minutes later after the engine has started)	20 - 40 %	-	-
			2,500 r/min	10 - 30 %		
8A★	Throttle position sensor (1st channel) (throttle valve angle)	<ul style="list-style-type: none"> <li>Engine: After having warmed up</li> <li>Ignition switch: ON (Engine: stopped)</li> </ul>	Release the accelerator pedal.	0 - 20 %	Code No. P0120	13A-25*
			Depress the accelerator pedal.	Increase in proportion to the pedal stroke		
			Depress the accelerator pedal fully.	80 - 100 %		

## NOTE

★: will not displayed if service data is selected on the check mode.

\*: Refer to the 2001 PAJERO Workshop Manual (Pub.No. PWJE0001)

**CHECK AT THE ENGINE-ECU TERMINALS****TERMINAL VOLTAGE CHECK CHART <A/T>****Engine-A/T-ECU Connector Terminal Arrangement**

The terminals below have been changed as the engine-A/T-ECU has been changed. The other terminals are the same as before.

Terminal No.	Check item	Check requirements (Engine condition)	Normal condition
3	Oxygen sensor heater (front)	Engine: Idling	0 - 3 V
		Engine: 3,500 r/min	System voltage
26	Oxygen sensor heater (rear)	Engine: Idling	0 - 3 V
		Engine: 3,500 r/min	System voltage
71	Oxygen sensor (front)	Engine: Warmed up, and then hold the engine speed at 2,500 r/min (Use a digital voltmeter)	0 and 0.8 V alternate.
73	Oxygen sensor (rear)	<ul style="list-style-type: none"> <li>● Transmission: 2nd gear</li> <li>● Engine speed: 3,500 r/min or more</li> <li>● Driving with the throttle valve widely open</li> </ul>	0.6 - 1.0 V

**Engine-A/T-ECU Harness-side Connector Terminal Arrangement**

The terminals below have been changed as the engine-A/T-ECU has been changed. The other terminals are the same as before.

Terminal No.	Check item	Standard value, normal condition (check conditions)
3 - 41	Oxygen sensor heater (front)	11 - 18 Ω (at 20°C)
26 - 41	Oxygen sensor heater (rear)	11 - 18 Ω (at 20°C)

**ON-VEHICLE SERVICE****OXYGEN SENSOR CHECK**

On A/T, a dual oxygen sensor has been adopted. Its service procedure is the same as for the previous M/T.

---

## NOTES

## GROUP 13A

# GASOLINE DIRECT INJECTION (GDI)

### GENERAL

#### OUTLINE OF CHANGES

Due to the changes as shown below, the service procedures regarding the different description from the previous version have been established.

- The engine-ECU and the engine-A/T-ECU have been changed.
- The values in the data list have been changed.

### GENERAL INFORMATION

#### GENERAL SPECIFICATIONS

Item		Specification
Engine-ECU <M/T>	Identification No.	E2T79279 <LHD>
Engine-A/T-ECU <A/T>	Identification No.	E2T76298 <LHD> E2T76299 <RHD>

### TROUBLESHOOTING

#### DATA LIST REFERENCE TABLE

Item No.	Check item	Requirements	Normal condition	Inspection procedure No.	Reference page
22	Crank angle sensor	<ul style="list-style-type: none"> <li>● Engine: Cranking</li> <li>● Tachometer: Connected</li> </ul>	Compare the engine speed readings on the tachometer and the MUT-II.	Accord	Code No. P0335 13A-56★
		<ul style="list-style-type: none"> <li>● Engine: Idling</li> <li>● Idle position switch: ON</li> </ul>	When engine coolant temperature is -20°C	1,300 - 1,500 r/min	
			When engine coolant temperature is 0°C	1,300 - 1,500 r/min	
			When engine coolant temperature is 20°C	1,250 - 1,450 r/min	
			When engine coolant temperature is 40°C	1,100 - 1,300 r/min	
			When engine coolant temperature is 80°C (within four minutes after engine has started)	500 - 700 r/min	

Item No.	Check item	Requirements	Normal condition	Inspection procedure No.	Reference page	
37	Volumetric efficiency	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95°C</li> <li>Lamps, electric cooling fan and all accessories: OFF</li> <li>Transmission: Neutral (A/T: P range)</li> </ul>	Engine: idling (Within four minutes after engine has started)	20 - 40 %	-	-
			2,500 r/min	10 - 30 %		
			Engine is suddenly raced	Volumetric efficiency increases in response to racing		
44	Ignition advance	<ul style="list-style-type: none"> <li>Engine: After warm-up</li> <li>Set a timing lamp</li> </ul>	Idling (More than four minutes after engine has started)	5 - 20° BTDC <M/T> 12 - 28° BTDC <A/T>	Code No. P0300	13A-53★
			2,500 r/min	15 - 35° BTDC		
74	Fuel pressure sensor	<ul style="list-style-type: none"> <li>Engine coolant temperature: 80 - 95°C</li> <li>Lamps, electric cooling fan and all accessories: OFF</li> <li>Transmission: Neutral (A/T: P range)</li> </ul>	Engine: Cranking	2 kPa or more	Code No. P0190	13A-36★
			Engine: Idling	4 - 6.9 MPa		

## NOTE

★: Refer to the 2001 PAJERO Workshop Manual (Pub. No. PWJE0001).

---

## NOTES