

Last Modified: 1-29-2016	6.6 D	Doc ID: RM000001DWZ00HX
Model Year Start: 2008	Model: Land Cruiser	Prod Date Range: [08/2007 -]
Title: BRAKE CONTROL / DYNAMIC CONTROL SYSTEMS: VEHICLE STABILITY CONTROL SYSTEM: CALIBRATION; 2008 MY Land Cruiser [08/2007 -]		

CALIBRATION

1. DESCRIPTION

After replacing the relevant VSC components, clear the sensor calibration data and perform calibration.

REPLACEMENT/ADJUSTMENT PART	NECESSARY OPERATION
Master cylinder solenoid (Skid control ECU)	Yaw rate and G sensor zero point calibration
Yaw rate and G sensor	1. Clearing zero point calibration data 2. Yaw rate and G sensor zero point calibration


2. CLEAR ZERO POINT CALIBRATION (SST CHECK WIRE)

After replacing the yaw rate and G sensor, make sure to clear the zero point calibration data in the skid control ECU and perform zero point calibration.


- (a) Turn the engine switch on (IG).

- (b) Using SST, connect and disconnect terminals 12 (TS) and 4 (CG) of the DLC3 4 times or more within 8 seconds.

SST: 09843-18040



- (c) Check that "DIAG VSC OK" is displayed on the multi-information display and check that the ABS warning light outputs the normal system code.



- (d) Using a check wire, perform zero point calibration of the yaw rate and G sensor.

3. PERFORM ZERO POINT CALIBRATION OF YAW RATE AND G SENSOR (SST CHECK WIRE)

After replacing the master cylinder solenoid and/or yaw rate and G sensor, make sure to perform yaw rate and G sensor zero point calibration.

NOTICE:

- While obtaining the zero point, do not vibrate the vehicle by tilting, moving or shaking it. Keep it stationary and do not start the engine.
- Choose a level surface with an inclination of less than 1°.

(a) Procedures for Test Mode:


- (1) Turn the engine switch off.
- (2) Move the shift lever to P.

NOTICE:

DTC C1210/36 and C1336/98 will be stored if the shift lever is not in P .

- (3) Using SST, connect terminals 12 (TS) and 4 (CG) of the DLC3.

SST: 09843-18040




- (4) Check that the steering wheel is centered.
- (5) Turn the engine switch on (IG).
- (6) Keep the vehicle stationary on a level surface for 2 seconds or more.
- (7) Check that "VSC TEST MODE" is displayed on the multi-information display and check that the ABS warning light is blinking in test mode.

NOTICE:

The ABS warning light stays on when obtaining the zero point.

HINT:

- If the ABS warning light does not blink, perform the zero point calibration again.
- The zero point calibration is performed only once after the system enters test mode.
- Calibration cannot be performed again until the stored data is cleared once.



4. CLEAR ZERO POINT CALIBRATION (TECHSTREAM)

After replacing the yaw rate and G sensor, make sure to clear the zero point calibration data in the skid control ECU and perform zero point calibration.

- (a) Connect the Techstream to the DLC3.
- (b) Turn the engine switch on (IG).
- (c) Turn the Techstream on.

(d) Enter the following menus: Chassis / ABS/VSC/TRAC / Utility / Reset Memory.

(e) Using the Techstream, perform zero point calibration of the yaw rate and G sensor.

5. PERFORM ZERO POINT CALIBRATION OF YAW RATE AND G SENSOR (TECHSTREAM)

After replacing the master cylinder solenoid and/or yaw rate and G sensor, make sure to perform yaw rate and G sensor zero point calibration.

NOTICE:

- While obtaining the zero point, do not vibrate the vehicle by tilting, moving or shaking it. Keep it stationary and do not start the engine.
- Choose a level surface with an inclination of less than 1°.

(a) Procedures for Test Mode:

- (1) Turn the engine switch off.
- (2) Move the shift lever to P.

NOTICE:

DTC C1210/36 and C1336/98 will be stored if the shift lever is not in P  .

- (3) Check that the steering wheel is centered.
- (4) Connect the Techstream to the DLC3.
- (5) Turn the engine switch on (IG).
- (6) Turn the Techstream on.
- (7) Enter the following menus: Chassis / ABS/VSC/TRAC / Utility / Test Mode.
- (8) Keep the vehicle stationary on a level surface for 2 seconds or more.
- (9) Check that "VSC TEST MODE" is displayed on the multi-information display and check that the ABS warning light is blinking in test mode.

NOTICE:

The ABS warning light stays on when obtaining the zero point.

HINT:

- If the ABS warning light does not blink, perform the zero point calibration again.
- The zero point calibration is performed only once after the system enters test mode.
- Calibration cannot be performed again until the stored data is cleared once.

Blinking Pattern in TEST MODE:

